
CU-380
Antenna Coupler



**Rockwell
International**

Collins instructions

**CU-380
Antenna Coupler**

**Collins Telecommunications
Products Division
Defense Electronics Operations
Rockwell International
Cedar Rapids, Iowa 52498**

Caution

The material in this manual is subject to change. Before attempting any maintenance operation on the equipment covered in this manual, verify that you have a complete and up-to-date publication applicable to your equipment.

Please be advised that completion of the enclosed Automatic Distribution Service Card and return to Rockwell International ensures you of manual revisions and service bulletin modifications to your equipment. Without the return of this card, Rockwell International bears no responsibility to forward this information to you.

We welcome your comments concerning this instruction book. Although every effort has been made to keep it free of errors, some may occur. When reporting a specific problem, please describe it briefly and include the instruction book part number, the paragraph or figure number, and the page number.

Send your comments to: Logistics
Collins Telecommunications
Products Division
Rockwell International
Cedar Rapids, Iowa 52498

ATTN: Quality Control-Support Engineering 120-120



Rockwell
International

instructions

CU-380 Antenna Coupler (622-3573-001)

Collins Telecommunications Products Division

523-0772190-001211

1 August 1982

Printed in USA

(622-3573-001)

1. DESCRIPTION

1.1 General


The CU-380 Antenna Coupler, a companion antenna coupler for the HF-282/282V, HF-380, and KWM-380 Transceivers, matches various antennas to the 50-ohm impedance of the transceivers. The antenna coupler (refer to figure 1) is specifically designed for use with 2.7-m (9-ft) mobile whip antennas, 4.9-m (16-ft) and 11-m (36-ft) vertical antennas, and 15.2-m (50-ft) and 30.3-m (100-ft) long-wire antennas. Rf power handling capacity is 125 watts, peak and average. The required dc primary power is obtained from the associated transceiver.

The antenna coupler is automatically tuned when a frequency is selected and the transceiver is keyed. The antenna coupler microprocessor uses discriminator outputs to develop the control signals for selecting appropriate impedance matching elements.

The antenna coupler consists of three major circuit cards/subassemblies: rf plate A1 (651-4323-001), rf card A1A1 (646-5871-001), and control A1A2 (646-5867-001).

1.2 Specifications

Equipment specifications are listed in table 1.



TPA-5925-017

CU-380 Antenna Coupler
Figure 1

Table 1. CU-380 Antenna Coupler Equipment Specifications.

CHARACTERISTIC	SPECIFICATION
<p>Electrical</p> <p>Frequency range</p> <p>Input impedance</p> <p>Number of channels</p> <p>Tuning time</p> <p>Rf power input</p> <p> Tune</p> <p> Operate</p> <p>Duty cycle</p> <p>Antenna matching capability</p> <p>Primary power (supplied by transceiver)</p> <p>Control interface</p>	<p>1.6 - 30.0 MHz</p> <p>50 ohm with 2:1 vswr, maximum, when tuned</p> <p>Continuous tuning</p> <p>15 s maximum; receive bypass, 50 ms</p> <p>20 to 35 watts</p> <p>125 watts, pep and average</p> <p>Continuous</p> <p>1.6 to 30 MHz for 15.2- and 30.5-m (50- and 100-ft) long wires; 1.8 to 30 MHz for 11-m (36-ft) vertical; 2.0 to 30 MHz for 4.9-m (16-ft) vertical; 3.5 to 30 MHz for 2.7-m (9-ft) whip</p> <p>12-15 V (13.5 nominal) 2.5 A maximum, 2 A nominal</p> <p>Compatible with HF-282, HF-282V, HF-380, and KWM-380</p>
<p>Environmental</p> <p>Ambient temperature</p> <p>Altitude</p> <p>Vibration</p> <p>Shock</p> <p>Humidity</p>	<p>-20 to +50 °C (-4 to +122 °F), operating</p> <p>0 to 3768 m (0 to 12 000 ft)</p> <p>1.5 g, 5.5 to 55 Hz</p> <p>15 g, 11 milliseconds</p> <p>100% RH - Not recommended for use in salt spray environments</p>
<p>Physical</p> <p>Size (excluding connectors and mounting brackets)</p> <p>Weight</p> <p>Cooling provisions</p> <p>Type of construction</p>	<p>Width - 36.7 cm (14.45 in)</p> <p>Height - 14.2 cm (5.60 in)</p> <p>Length - 31.6 cm (12.45 in)</p> <p>7.28 kg (16.0 pounds), max</p> <p>Natural convection and conduction through mounting surfaces</p> <p>Formed and welded aluminum sheet</p>

Table 1. CU-380 Antenna Coupler Equipment Specifications (Cont).

CHARACTERISTIC	SPECIFICATION
Connectors	
Rf output	#10 stud on conical ceramic standoff insulator
Rf input	SO-239 coaxial connector
Control/power	Terminal lugs

1.3 Associated Equipment

A list of transceivers, antennas, rf and control cables and ground radial kits for use with the antenna coupler is given in table 2.

2. INSTALLATION

2.1 General Requirements

To use a single antenna for different frequencies, a matching circuit is required between the transmitter output and the antenna. This is the function of the antenna coupler.

A number of different types of antennas for both fixed and mobile use are available from Rockwell-Collins. General information is given here for installing the antenna coupler with a long wire for fixed-station use, and with a vertical or whip antenna for either fixed- or mobile-station use.

2.1.1 Long-Wire Antennas

Figure 2 shows a typical long-wire antenna installation. The antenna coupler should be mounted as close as possible to the grounding system. In the installation, note that the wire from the coupler to the section of antenna between insulators is also a part of the antenna. This wire is to be the same size and type as the rest of the antenna and must be considered when determining the length of the antenna.

Make a drip loop in the wire to the antenna where the wire attaches to the antenna coupler rf output.

DO NOT use the coupler output connector as one antenna support. Leave sufficient wire slack between the supporting insulator and the antenna coupler to prevent mechanical stress on the antenna coupler connector.

Be sure the antenna coupler is properly grounded. The recommended ground system is a set of radial wires such as the Rockwell-Collins AC-2820. These radials should be 1/4 wavelength long at the lowest frequency to be used and should be attached to the coupler base. Use a minimum of eight radials. If the ground radials cannot be connected directly to the coupler base, connect them together and attach a ground strap to the common connection. Then connect the ground strap to the antenna coupler ground lug on the side of the case. The ground strap should be approximately 51-mm (2-in) wide and not more than 305-mm (12-in) long.

2.1.2 Fixed Vertical Antennas

A typical fixed-station vertical antenna installation is shown in figure 3. The Rockwell-Collins AC-2810 or AC-2811 is recommended. (The AC-2810 will tune down to 2.0 MHz, and the AC-2811 to 1.8 MHz.) Attach a minimum of eight radial wires, 1/4 wavelength (λ) long at the lowest frequency used, to the antenna mounting base.

$$1/4\lambda = \frac{75}{f(\text{MHz})} \text{ m, or } = \frac{246}{f(\text{MHz})} \text{ ft}$$


where $f(\text{MHz})$ = lowest operating frequency expressed in MHz.

More than eight radial wires should be used if possible, to increase antenna efficiency. Extend the wires straight out from the attaching points at the base and bury them approximately 15 cm (6 in) under the earth's surface. A radial kit, AC-2820, is recommended. The AC-2820 contains 91.5 m (300 ft) of wire for the radials.


The antenna coupler should be mounted adjacent to the antenna base. Using ground strap, connect the antenna coupler ground lug to the antenna ground

Table 2. Equipment Associated With the CU-380 Antenna Coupler.

EQUIPMENT	DESCRIPTION
HF-282 HF Transceiver	1.600 to 29.999 MHz transceiver with 20 programmed fixed-frequency channels; sideband and CW modes; 125-W, pep and average, rf output power; for fixed-station use.
HF-282V HF Transceiver	Similar to HF-282, but for mobile use. Does not have built-in ac power supply.
HF-380 HF Transceiver	Similar to HF-282 but with full, continuous coverage of 1.60000 to 29.99999 MHz frequency range.
KWM-380 HF Transceiver	Similar to HF-380 but with transmit frequencies limited to Amateur Radio Service ("ham") and Military Affiliate Radio Service (MARS) coverage. Receive frequency is continuous coverage from 1.60000 to 29.99999 MHz.
AC-2810 Vertical Antenna Kit	4.9-m (16-ft) vertical antenna
AC-2811 Vertical Antenna Kit	11-m (36-ft) vertical antenna
AC-2814 Long-Wire Antenna kit	15.2-m (50-ft) long-wire antenna
AC-2815 Long-Wire Antenna kit	30.6-m (100-ft) long-wire antenna
AC-2816 Whip Antenna Kit	2.7-m (9-ft) mobile whip antenna with mounting spring and base insulator
AC-2818 Lightning Arrester	Lightning arrester for inserting in rf coaxial cable interconnection
AC-2819 Grounding Kit	Three 1.8-m (6-ft) copper clad steel ground rods with clamps and wire
AC-2820 Radial Kit	91.4 m (300 ft) of wire and lugs
AC-3821 Transceiver-to-Coupler RF Cable	RG-58 coaxial cable assembly terminated with PL-259 connectors. Lengths up to 20 m (66 ft)
AC-3822 Transceiver-to-Coupler RF Cable	RG-213 coaxial cable assembly terminated with PL-259 connectors. Lengths from 10 m (33 ft) to 60 m (200 ft)
AC-3823 Transceiver-to-Coupler RF Cable	Low-loss heliax coaxial cable assembly terminated with uhf series connectors. Lengths from 60 m (200 ft) to 120 m (400 ft)
AC-2832 Transceiver-to-Coupler Control Cable	Multiconductor cable terminated with connector/terminals attached. Lengths up to 60 meters (197 ft)
AC-3809 HF/KWM-380 to Standard Interface Adapter	Adapter unit for interfacing CU-380 to HF-380 or KWM-380 Control Interface Connector



Long-Wire Antenna Installation
Figure 2



Fixed Vertical Antenna Installation
Figure 3


system. Connect the antenna coupler rf output connector to the antenna with #14 AWG, or heavier, stranded wire. Make a drip loop in the wire to the antenna where the wire attaches to the antenna coupler rf output connector.

Note

The antenna proper and the mounting base are insulated from each other. Do not connect any conductive materials between these. Doing so will short out the antenna.

2.1.3 Mobile Whip Antennas

The AC-2816 whip antenna (which tunes down to 3.5 MHz) is for vehicular use and is to be mounted on the vehicle body. Do not mount it on the bumper. The body metal of the vehicle serves the same purpose as the radial wires in a fixed-station whip installation. Figure 4 shows how the antenna is mounted on the vehicle body and connected to the antenna coupler.



TPA-5513-011

**Mobile Whip Antenna Installation
Figure 4**

Mount the antenna coupler as near the antenna mount as practical. Maximum recommended distance away is not over approximately 30 cm (12 in). The coupler-to-antenna rf connection is #14 AWG, or heavier, insulated, stranded wire run in a short, direct path. Leave only enough slack to avoid mechanical stress due to tension or vibration. Make sure there is adequate clearance (approximately 25 mm (1 in)) on all sides of the rf wire up to the antenna base.

Be sure the ground strap between the antenna base and antenna coupler is connected to clean, bare metal of the vehicle body at the antenna base.

2.2 Location

The antenna coupler must be located at the base of the vertical or whip antenna, or at one end of the long-wire antenna, and mounted horizontally (base down) if located out of doors. Although the antenna coupler is housed in a weather resistant case, a protective shelter is recommended for outside installations. A simple cover to protect from direct sunlight, rain, or snow is sufficient.

The antenna coupler is not recommended for use in salt spray environments.

Distance between the antenna coupler and associated transceiver should not be farther away than 120 m (400 ft).

2.3 Interconnections

2.3.1 HF-380, KWM-380 Interface

Use of the antenna coupler with an HF-380 or KWM-380 transceiver requires the AC-3809 HF/KWM-380 to Standard Interface Adapter. The AC-3809 adapts the control interface connector on the transceiver to the connector required by the antenna coupler. The adapter is not required when the HF-282 or HF-282V Transceiver is used.

Connect the AC-3809 input connector to the control interface connector on the rear panel of the HF-380 or KWM-380 transceiver. Connect the transceiver-to-coupler control cable (AC-2832) to the adapter CONTROL B output connector. The control cable is then connected to the antenna coupler as discussed in paragraph 2.3.2.

2.3.2 Interconnecting Cabling

2.3.2.1 Control Cable

For the HF-282 or HF-282V, connect the multipin connector on the AC-2832 control cable directly to J3 on the rear panel of the transceiver. For the HF-380 or KWM-380, connect the multipin connector on the cable to the CONTROL B connector on the AC-3809 adapter, which is connected to the transceiver.

Extend the control cable to the antenna coupler by the most direct route available.

Remove the top cover of the antenna coupler. Loosen the compression nut on the bushing and insert the control cable through the bushing.

Interconnect the cable terminals to the coupler terminal strip as shown in figure 5.

Position the cable to leave a moderate amount of slack in the wires, then tighten the bushing compression nut until it is finger tight plus one-fourth turn.

Replace the antenna coupler cover.

2.3.2.2 RF Coaxial Cable

Caution

For increased protection of equipment from lightning, a lightning arrester should be inserted in the rf coaxial cable interconnection between the antenna coupler and associated transceiver. The Rockwell-Collins AC-2818 Lightning Arrester Kit is recommended.

The rf coaxial cable has a connector on each end to mate with type SO-239 connectors. The rf cable connects directly to coaxial connectors on the transceiver or lightning arrester and the antenna coupler.

Determine the length of rf coaxial cable required. The following list gives recommended cable kits (cable with connectors attached, ready for use) and indicates various lengths available.


RF Cable	Lengths	Increments
AC-3821	1, 3, 10, 20 m (3.3, 10, 33, 66 ft)	
AC-3822	10 - 60 m (33 - 198 ft)	10 m (33 ft)
AC-3823	60 - 200 m (198 - 660 ft)	10 m (33 ft)

Extend the rf coaxial cable by the most direct route available from the lightning arrester to the antenna coupler. Connect the cable to the antenna coupler and to the AC-2818 lightning arrester at the outside of the building. Make a drip loop in the rf cable from the antenna coupler to the lightning arrester where the cable attaches to the lightning arrester. Connect an appropriate length of rf coaxial cable between the transceiver and the lightning arrester connection inside the building.

Refer to instructions supplied with the AC-2818 for proper installation of the lightning arrester.

2.3.2.3 Antenna Coupler-to-Antenna RF Connection

Connect the antenna coupler rf output connector (#10 stud at end of conical ceramic insulator) to the antenna with #14 AWG, or larger diameter, stranded wire. Keep this wire as short as practical, but not



Transceiver-to-Antenna Control Cable Wiring
Figure 5

longer than 30 cm (12 in). Leave a slight amount of slack to prevent stress on the connections.

The wire from the rf output connector radiates rf energy. Make sure there is adequate clearance (approximately 25 mm (1 in)) around the wire for its entire length, from the antenna coupler to the antenna connection.

2.3.2.4 Antenna Coupler to Ground

The antenna coupler must be connected to a good earth ground, if in fixed station use; or vehicle ground, if in mobile station use. Refer to information supplied with the antenna, radial, and grounding kits listed in table 3 (paragraph 5.3).

Connect 12-mm (1/2-in) wide, or larger, braided ground strap directly from the antenna coupler grounding lug (near the nameplate) to the grounding system. Use the shortest path possible for this connection.

In vehicular installations, make sure the ground connections to the vehicle body are made to bare metal. Scrape away any paint or other foreign material necessary to make a good ground connection.

2.4 Installation Checkout

After the installation is complete but before attempting operation of the antenna coupler, check all cables for proper connections, make sure connectors are firmly mated, and ensure that a proper antenna is connected to the antenna coupler rf output.

Check for adequate mechanical support of the interconnecting control and rf coaxial cables. There should be no tension on any of the connectors.

After the electrical and mechanical checks have been made, perform the following operational check.

- a. Turn on power to the transceiver and select an authorized mode and frequency of operation.
- b. Momentarily key the transceiver. (Depress and release the microphone ptt switch or the CW key.)
- c. Listen for a random-beep audio tone (approximately 800 Hz pulsed in a random order) that is output from the transceiver as the transceiver is automatically momentarily keyed in the tune power mode for antenna coupler tuning.
- d. Within 15 seconds from keying the tone should stop, indicating a tuned condition. The trans-

ceiver/antenna coupler is then ready for normal operation. If a rapid, steady beeping of the tone (approximately 10 times per second) is heard, a fault condition exists.

- e. If the fault signal is heard, turn off transceiver power and recheck all connections. If the cabling connections and antenna coupler installation are correct, refer to paragraph 5 and perform the test and troubleshooting procedures on the antenna coupler.

3. OPERATING PROCEDURES

3.1 General

Operation of the antenna is automatically initiated when the associated transceiver is tuned and keyed. The antenna coupler tuning is carried out by a microprocessor which takes control of the transceiver from the time of being keyed until the antenna coupler is tuned. The microprocessor causes the transceiver to be automatically keyed on an intermittent basis as rf is needed to sense the tune-condition of the antenna coupler. When tuning is complete, the microprocessor relinquishes control of the transceiver to permit normal operation.

Since primary power is supplied by the transceiver, the antenna coupler power is on any time the transceiver power is turned on.

3.2 Procedures

The following steps outline the procedures for operating the antenna coupler.

a. Turn On

Turn on the transceiver power switch. This also applies primary power to the antenna coupler.

b. Frequency Selection or Change

Initially select or change the transceiver operating frequency in the normal manner.

c. Antenna Coupler Tuning

Momentarily key the transceiver by depressing and releasing the microphone ptt switch or CW key. The key signal causes the antenna coupler to begin the tuning process. The transmitter is automatically keyed and held at tune-power output, as needed for tuning, until tuning is complete. When complete, the automatic keying function is released.

During tuning, the transceiver sidetone signal (800 Hz) will be heard in random pulses. This is caused by the antenna coupler automatically keying the transmitter for sporadic pulses of rf needed to sense the tuned condition. When tuning is complete, the transmitter key signal from the antenna coupler is turned off, stopping the sidetone output.

If a tuning fault occurs during tune-up, the sidetone becomes a rapid beeping tone occurring at a 10-Hz rate. In the event that this occurs, turn off the transceiver and perform troubleshooting procedures. One possibility of a tuning fault is a "tune hole". This is a very narrow frequency range that, because of the peculiarities of the individual antenna installation, the antenna coupler cannot tune to achieve 2:1, or better, vswr. Making a simple adjustment in the length or orientation of the antenna normally eliminates the tune hole.

d. Transmit/Receive Operation

Once the antenna coupler has completed tuning, there is no change in procedures from those normally used with the transceiver for transmitting and receiving.

Changing the transmitter frequency by 10 kHz or more causes the antenna coupler to switch to the bypass mode. The next time the transmitter is keyed, the antenna coupler checks the vswr and automatically retunes if necessary. Under some conditions, tuning away from the operating frequency by 5 kHz or so then tuning back to the operating frequency can cause the antenna coupler to retune.

e. Turn Off

Turn off the transceiver power switch. This also removes primary power from the antenna coupler.

4. PRINCIPLES OF OPERATION

4.1 General

Antenna coupler tuning is automatically controlled by a microprocessor. Discriminator outputs, analogs of the antenna voltage, impedance, phasing, and vswr are input to the microprocessor to indicate the tuned condition of the antenna/antenna coupler

combination. The microprocessor outputs commands to relay drivers, causing the affected relays to add or remove inductors or capacitors from the rf path to the antenna. When the discriminator circuits sense a nominal 50-ohm, nonreactive antenna/antenna coupler combination, the microprocessor releases control of the transceiver to permit normal transceiver operation.

When the associated transceiver is turned on, the antenna coupler microprocessor resets and generates outputs to cause the tuning elements to be bypassed. Once this is accomplished, the central processor unit (CPU) is placed in the halt mode. This permits rf reception through the untuned antenna/antenna coupler combination.

At the time transceiver is keyed, the microprocessor immediately takes control of the transceiver key line. This is done through the transmit inhibit signal. The CPU next commands a short rf output pulse from the transceiver (at tune power level). Discriminator outputs, developed from the rf signal, are applied through input/output (I/O) circuits to the CPU. Following microprocessor program instructions, a coarse approximation is made to determine the required tuning elements (inductors and capacitors). The CPU commands relays associated with these inductors and capacitors to energize, placing impedances in the rf path. After this is done, the CPU commands another rf output pulse from the transceiver. The resulting discriminator outputs are again processed to determine further tuning needs. The CPU commands additional associated relays to energize or deenergize to achieve a closer approximation to the correct tuned condition. This sequence continues until the antenna coupler senses a tune fault condition, or the antenna/antenna coupler combination presents a nominal 50-ohm, nonreactive load to the transceiver.

When the microprocessor senses the tuned condition, the xmt inh (transmit inhibit), tune, and tune pwr signals are released so normal transceiver operation can occur.

In the event the antenna coupler cannot properly tune with the antenna being used, or if voltage to the antenna exceeds a predetermined level, the microprocessor outputs a tune fault signal.

When the transceiver frequency is changed during the same operating period, keying the transceiver again gives control to the microprocessor. The CPU

commands a short rf pulse from the transceiver to check for a tuned condition. If the frequency change has not been great enough to require additional antenna coupler tuning, the CPU permits immediate normal operation. If tuning is required, the sequence previously described is repeated to tune the antenna/antenna coupler for the new frequency.

In addition to 14-volt primary power to the antenna coupler from the associated transceiver, the antenna requires the following inputs: key—to initiate antenna coupler tuning when a frequency is first selected and the transmitter keyed; strobe—to indicate that a frequency change has occurred at the transceiver; and set bypass—to activate relays that bypass the antenna coupler tuning elements to permit straight-through operation. Outputs from the antenna coupler to the transceiver are the tune, tune power, transmit inhibit, and tune fault signals discussed in the previous paragraphs.

4.2 Functional Theory (Refer to figure 6)

4.2.1 Power-on Reset

Turning on the transceiver applies power to the antenna coupler. This causes a reset circuit in the antenna coupler to output a momentary reset command. The reset command initializes the CPU and the I/O circuits of the microprocessor. Initialization causes the CPU to command the home state, which energizes the antenna coupler bypass relays, then to revert to the halt mode until further inputs are received.

4.2.2 Transceiver Keying

To initiate antenna coupler tuning, the transceiver must be momentarily keyed. The key signal from the transceiver is applied through a logic level comparator to a half logic circuit and to the microprocessor I/O circuits. The halt logic circuit releases the CPU from the halt mode when the key signal is received. With the CPU operating, the microprocessor addresses the I/O port associated with the key signal and applies the signal to the data bus. Once the key signal is sensed, the program instructions cause the microprocessor to output the tune, tune pwr, and xmt inh signals. Tune keeps the transceiver keyed, tune pwr causes the transceiver rf output to be at a low-power (nominally 20- to 35-watt) output, and xmt inh enables or inhibits the transceiver rf output as needed for tuning, even though the transceiver remains keyed (by tune). These signals are output from the coupler through buffer/driver stages.

4.2.3 Discriminator Outputs

As the microprocessor intermittently keys the transceiver, rf power is applied through discriminator circuits in the antenna coupler. The discriminators sense impedance, phase, resistance, and forward and reflected power on the attached antenna. These signals are output to comparators.


The comparators output a forward power signal, as well as combine the forward and reflected power analogs to develop high and low vswr signals. The impedance, phase, and resistance signals are also compared with a ground reference and applied to the microprocessor I/O circuits as logic 1 or logic 0 signals.

4.2.4 Microprocessor

The microprocessor instructions set, contained in a read-only-memory (ROM), directs the operation of the CPU. The CPU outputs addresses, and both inputs and outputs (reads and writes) data. The data, on the data bus, is read from or written into circuits enabled by the address signal on the address bus. Additionally, the CPU performs computations on the input data and outputs the new data to the addressed location.


With the transceiver held keyed (by the tune signal from the antenna coupler), rf power, on command of the xmt inh signal, is coupled through the discriminator circuits. The discriminator outputs are applied to the data bus when the applicable I/O circuit ports are addressed by the CPU. The discriminator output data is compared with the value of data (in the ROM) that indicates a matched condition. From this, the ROM instructions command certain tuning element relays to be energized. When this command is on the data bus, the CPU outputs an address signal. This causes the I/O ports connected to the associated relay drivers to be enabled. The relay drivers enable relays that connect the applicable tuning elements to the rf line.

With the tuning elements in the rf line, the CPU, through the xmt inh signal, again commands a short burst of rf from the transceiver. The discriminator signals (from this rf) are again applied to the data bus. The CPU compares this new data with that for a matched condition. Appropriate commands are again output to the data bus to enable tuning element relays. This operation continues until the discriminator data corresponds to that which indicates an acceptably matched condition between the transceiver and antenna/antenna coupler.



TPA-5402-024

CU-380 Functional Block Diagram
Figure 6 (Sheet 1 of 2)



TPA-5402-024

CU-380 Functional Block Diagram
Figure 6 (Sheet 2)

When the antenna coupler is tuned, the microprocessor instructions cause the tune and tune pwr outputs to unkey the transceiver and remove the tune power restriction from the rf output. The transceiver/antenna coupler combination is then ready for normal operation.

Rf voltage signals from the C25 - C32 tuning capacitors (C2 volt sense) and the output to the antenna (ant volt sense) are rectified and filtered. The resulting dc analog voltages are compared with preset voltages. In the event of excessive voltage sense signals, the comparator outputs a CPU interrupt signal. This halts the tuning operation, causing the transceiver to be unkeyed and a tune fault signal to be output from the antenna coupler. In addition to the tune fault signal, an LED indicator on the antenna coupler control logic card is turned on, indicating a malfunction.

4.2.5 Tuning Elements

The capacitive and inductive tuning elements are switched into or out of the rf signal path by relays. When the relay associated with a capacitor is energized, the capacitor is inserted in the rf path between the rf line and ground. When the relay associated with an inductor is energized, the inductor is shorted so that the rf signal bypasses that inductor. Power for the tuning element relays is switched by relay driver transistors—one driver for each relay. The relay drivers are turned on and off by data signals output by the microprocessor I/O circuits when commanded by the CPU.

5. TESTING/TROUBLESHOOTING

5.1 General

Caution

Control A1A2 contains electrostatic discharge sensitive (ESDS) components. Refer to paragraph 6 for special handling requirements before removing or repairing the card.

To test the entire antenna coupler, perform all of the table 4 (paragraph 5.5). If only one functional area is to be tested, go to that test in the table. Tests are arranged such that each test presumes that circuits checked in the previous tests are operational. If the previous tests have not been performed, do so as part of the troubleshooting procedures.

The tests will isolate a malfunction to the probable major subassembly of the antenna coupler. With reference to the schematic diagram and by standard troubleshooting techniques, a malfunction can be isolated to a specific functional circuit.

Because of the requirements for specialized test equipment, including automatic testers, the discriminator and microprocessor circuits are not considered user-repairable. If a malfunction is isolated to either of these circuits, return the antenna coupler to the factory or authorized repair center for repair.

5.2 Disassembly/Reassembly

5.2.1 Disassembly

Note

Save all hardware removed during disassembly for use in reassembly.

5.2.1.1 Cover

Remove the cover by removing six screws and washers from the top. Lift the cover directly away from the unit.

5.2.1.2 Control A1A2

Disconnect cables from the circuit card. Remove six nuts and washers securing the card to standoff posts. Lift the card up and directly away from the standoff posts.

5.2.1.3 RF Plate A1

Disconnect the control cable from A1A2TB1. Remove four screws securing the rf input connector to the chassis. Remove six screws and washers securing the rf plate to the chassis lips.

Caution

Use care in lifting the rf plate from the chassis. Relays and inductors near the plate edge may be damaged if scraped against the chassis lips.

Lift the rf plate upward a small distance, then tip upward the edge opposite the control cable bushing. Carefully maneuver the rf plate past the chassis lips and lift it free of the housing.

5.2.1.4 RF Card A1A1

Remove the rf card as follows:

- a. At rf card (near C54 (figure 10, item 8)), unsolder bus wire going to relay K29 (figure 10, item 12).
- b. To prevent damage to circuit card, cut short length of bus wire from circuit card to relay K22 (figure 10, item 2).

Note

After removal of the circuit card, unsolder the cut wire ends from the circuit board and the relay. Use a new piece of #12 AWG bus wire the same length as the original piece when reinstalling the circuit card.

- c. At rf card, unsolder bus wire going to C54 (figure 10, item 8).
- d. Remove screw from top of C55 (figure 10, item 49) to disconnect solder lug from bus to C55.
- e. Remove three screws and washers securing edge of circuit card (opposite relays K24 through K28) to standoff posts.
- f. Remove control A1A2. (Refer to paragraph 5.2.1.2.)

Caution

In performing the following step, do not permit the rf plate to rest on inductors on relays.

- g. Turn rf plate over and remove nine screws, lockwashers, and flat washers that secure standoff posts (to which rf card A1A1 is mounted) to rf plate.
- h. Carefully lift rf card and disconnect four ribbon cables from bottom side of card.
- i. Lift rf card away from rf plate.

5.2.1.5 Plate-Mounted Components

Remove rf plate A1 from the chassis. (Refer to paragraph 5.2.1.3.) Remove rf card A1A1 from rf plate. (Refer to paragraph 5.2.1.4.) With the rf card removed, the plate-mounted components are directly accessible for disassembly. Tag, or otherwise identify, all connections to components to be removed. Note lead dress and strap placement.

5.2.2 Reassembly

5.2.2.1 Plate-Mounted Components

Reassemble components removed in paragraph 5.2.1.5 in proper position on rf plate. Secure components to rf plate with hardware removed during disassembly.

Caution

During reassembly, make sure all solder connections in the rf path are smooth. Any sharp edges or points in the rf path may cause arcing.

Refer to identification and notes made during disassembly and reconnect components.

5.2.2.2 RF Card A1A1

Install the rf card as follows:

- a. On bottom of circuit card, connect four ribbon connectors.

Caution

In performing the following step, do not permit the rf plate to rest on inductors or relays.

- b. Position circuit card in place on rf plate. Turn rf plate over and replace nine flat washers, lockwashers, and screws that secure standoff posts (to which circuit card is mounted) to rf plate.
- c. Replace control A1A2. (Refer to paragraph 5.2.2.4.)
- d. Replace three screws and washers securing edge of circuit card (opposite relays K24 through K28) to standoff posts.
- e. Position solder lug in place on C55 (figure 10, item 49) and replace screw securing lug to capacitor.
- f. At rf card, resolder bus wire going to C54 (figure 10, item 8).
- g. Using #12 AWG bus wire, replace and solder wire (removed in step 5.2.1.4.b) between circuit card and relay K22 (figure 10, item 2).
- h. At rf card (near C54 (figure 10, item 8)), resolder bus wire going to K29 (figure 10, item 12).

5.2.2.3 RF Plate A1

Caution

Use care in installing the rf plate in the chassis. Relays and inductors near the plate edge may be damaged if scraped against the chassis lips.

Starting with the rf input connector-edge of the rf plate tipped downward, carefully maneuver the rf plate into place on the chassis lips.

Replace the four screws securing the rf input connector to the chassis. Replace five of the six screws and washers securing the rf plate to the chassis lips. Do not yet install the (sixth) screw and washer in the chassis corner nearest the control cable connector, A1A2TB1.

If control A1A2 is installed, refer to paragraph 2.3.2.1 and install the control cable. Attach the control cable shield wire to the rf plate with the sixth screw and washer used to secure the rf plate to the chassis lips.

5.2.2.4 Control A1A2

Reconnect the ribbon cable connectors to the card. Position the card in place on the rf plate standoff posts. Install six nuts and washers to secure the card to the posts. Refer to paragraph 2.3.2.1 and install the control cable.

5.2.2.5 Cover

Place the cover in position on the chassis and secure to the chassis with the six screws and washers removed in paragraph 5.2.1.1.

5.3 Test Equipment

Table 3 lists the test equipment required to perform the test procedures.

5.4 Test Setup

Connect the test equipment as follows before performing any of the test procedures except test number 4: Rf path relays, inductors, and capacitors. Test 4 does not require a transceiver; only a vector impedance meter is used.

- a. Make sure the transceiver primary power switch is turned off.
- b. Using the AC-2832, or similar control cable, connect the antenna coupler to the transceiver control interface connector. (Refer to figure 5.) The AC-3809 adapter must also be used if the transceiver is an HF-380 or KWM-380.
- c. Using RG-58 coaxial cable with PL-259, or similar, connectors, connect the transceiver rf output connector to the antenna coupler rf input connector.
- d. Using the specially fabricated cable shown in figure 7, connect the antenna coupler rf output connector and ground lug to a 50-ohm, 100-W rf dummy load.
- e. Remove the top of the antenna coupler for access to test points.
- f. Make sure the transceiver is not keyed by any means until instructed to do so in the test procedures.

5.5 Test Procedures

Note

Potentiometers A1A2P61 and A1A2R62 are adjusted during factory test and are not to be readjusted during maintenance shop repair.

Table 4 gives the test procedures. The procedures are written so individual tests can be performed separately. For each test, perform the steps in the PROCEDURES column. The NORMAL INDICATION column gives the expected results. If results are not as expected, perform the troubleshooting procedures given in the IF INDICATION IS ABNORMAL column.


All reference designators in the table refer to the antenna coupler unless otherwise specified.

For test numbers 1 through 5, perform the test setup given in paragraph 5.4, then proceed to table 4. For test number 6, disconnect the antenna coupler from all equipment, remove the antenna coupler cover, then proceed to the test in the table.

Figures 13 through 15 are the interconnect and schematic diagrams of the antenna coupler. Use these as an aid in troubleshooting.

Table 3. Test Equipment Required.

ITEM	MINIMUM SPECIFICATIONS	REPRESENTATIVE TYPE
	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Note</div> Substituted equipment should be equivalent to or exceed listed specifications.	
Dc voltmeter	0 to 15 V dc, 10 kilohms/volt	Fluke 8600A
Rf dummy load	50 ohms, 100 W, 2 to 30 MHz	Bird 8164
Oscilloscope	1 V/div, vertical; 1 ms/div, horizontal	Tektronix 465
Vector impedance meter	10 to 1000 ohms, +90 to -90 degrees, 1.5 to 13 MHz	Hewlett-Packard 4815A
Transceiver	No substitute	Rockwell-Collins HF-282, HF-282V, HF-380, or KWM-380
Control cable	13-wire, shielded cable with type DBM-25P on one end and lugs on the other. Length as required (1 m (3 ft) suggested).	Rockwell-Collins AC-2832
Rf coaxial cable	RG-58 (length practical for shop use), type PL-259, or similar, connectors	Locally fabricate for shop use.
Special rf cable	Refer to figure 7.	Locally fabricate by figure 7 for shop use.
Relay switch box	Refer to figure 8.	Locally fabricate by figure 8 for shop use.




Fabrication Instructions for Special RF Cable, CU-380 RF Output to 50-Ohm RF Dummy Load
Figure 7

PARTS LIST

- 21 SPST TOGGLE SWITCHES
(CPN 266-5321-150)
- 2 BANANA JACKS
(CPN 372-2240-010)
- 457 mm (18 IN), NOMINAL
26-COND RIBBON CABLE
(CPN 424-0307-040)
- 457 mm (18 IN), NOMINAL
34-COND RIBBON CABLE
(CPN 424-0307-010)
- 1 26-PIN RIBBON CONNECTOR
(CPN 372-2634-060)
- 1 34-PIN RIBBON CONNECTOR
(CPN 372-2634-070)
- 1 CHASSIS, SIZE AS DESIRED.

CONSTRUCTION NOTE

MOUNT SWITCHES SO THAT
DOWN-POSITION OF TOGGLE
GIVES SWITCH OPEN OR
CLOSED STATE AS SHOWN
ON SCHEMATIC.



TPA-5942-014

**Fabrication Diagram for Relay Switch Box
Figure 8**

Table 4. CU-380 Antenna Coupler Testing and Troubleshooting.

TEST	PROCEDURE	NORMAL INDICATION	IF INDICATION IS ABNORMAL
1. Primary power	<p>a. Turn on transceiver primary power switch.</p> <p>b. Measure dc voltage between P4-2 (+) and chassis ground.</p> <p>c. Measure dc voltage between P1-1, -2, -3, or -4 (+) and chassis ground.</p> <p>d. Measure dc voltage between P5-1 or -2 (+) and chassis ground.</p> <p>e. Measure dc voltage between P5-5 or -6 (+) and chassis ground.</p> <p>f. If no further tests are to be performed, turn off transceiver primary power and disconnect equipment. Otherwise, go to next test.</p>	<p>+13 \pm1 V</p> <p>+13 \pm1 V</p> <p>+13 \pm1 V</p> <p>+5 \pm0.5 V</p>	<p>Check control cable and connections to transceiver. (Check transceiver.)</p> <p>Check control A1A2.</p> <p>Check control A1A2.</p> <p>Check 5-V regulator on rf plate A1.</p>
2. Transceiver control signals	<p>a. Turn on transceiver primary power switch.</p> <p>b. Connect dc voltmeter between P4-10 (+) and chassis ground.</p> <p>c. Key transceiver and measure dc voltage while keyed.</p> <p>d. Unkey transceiver and remove dc voltmeter.</p> <p>e. Connect oscilloscope vertical input between P4-11 (high) and chassis ground.</p> <p>f. Change transceiver frequency while observing oscilloscope display.</p> <p>g. Disconnect oscilloscope P4-11 and connect it to P4-8.</p> <p>h. Momentarily key transceiver while observing oscilloscope display.</p> <p>i. Disconnect oscilloscope from P4-8 and connect it to P4-12.</p>	<p>0 \pm0.5 V</p> <p>Momentary negative-going pulse, 5-V (nom), 2 \pm1 ms wide. (MHz-increment changes cause two pulses.)</p> <p>Tune signal goes from +5 \pm0.5 V (logic 1) before keying to +0.5 \pm0.5 V (logic 0) while tuning.</p>	<p>Check control A1A2. (Check transceiver.)</p> <p>Check control A1A2. (Check transceiver.)</p> <p>Check control A2A1, rf plate A1, and rf card A1A2.</p>
(Cont)			

Table 4. CU-380 Antenna Coupler Testing and Troubleshooting (Cont).

TEST	PROCEDURE	NORMAL INDICATION	IF INDICATION IS ABNORMAL
<p>2. (Cont)</p> <p>(Cont)</p>	<div style="border: 1px solid black; width: fit-content; margin: 0 auto; padding: 2px; text-align: center;">Note</div> <p>In performing steps j through l, the antenna coupler must be in the tun-mode. If tuning has been completed before the steps are performed or finished, change the transceiver frequency by 100 kHz or more and momentarily key it.</p> <p>j. Momentarily key transceiver while observing oscilloscope display.</p> <p>k. Disconnect oscilloscope from P4-12 and connect it to P4-9.</p> <p>l. Observe oscilloscope display while antenna coupler is tuning.</p> <p>m. With transceiver unkeyed, disconnect rf input from transceiver to antenna coupler.</p> <p>n. Disconnect oscilloscope from P4-9 and connect it to P4-3.</p> <p>o. Change transceiver frequency by 100 kHz or more.</p> <p>p. Momentarily key transceiver while observing oscilloscope display.</p>	<p>Tune pwr signal goes from +5 ±0.5 V (logic 1) before keying to +0.5 ±0.5 V (logic 0) while keyed. Width of logic 0 pulse varies with tune time.</p> <p>Xmt inh signal goes from +0.5 ±0.5 V (logic 0) to +5 ±0.5 V (logic 1) in random order as micro-processor commands rf output from transceiver. (Logic 1 corresponds to transceiver sidetone output signal.)</p> <p>Within 15 seconds after keying, tune fault signal goes from +5 ±0.5 V (logic 1) to +0.5 ±0.5 V (logic 0) for approximately 5 s. (Transceiver sidetone output is rapidly-beeping fault signal.)</p>	<p>Check control A1A2.</p> <p>Check control A1A2.</p>

Table 4. CU-380 Antenna Coupler Testing and Troubleshooting (Cont).

TEST	PROCEDURE	NORMAL INDICATION	IF INDICATION IS ABNORMAL																																										
<p>2. (Cont)</p> <p>3. Discriminator</p>	<p>q. If no further tests are to be performed, turn off transceiver primary power and disconnect equipment. Otherwise, go to next test.</p> <p>a. Turn off transceiver primary power switch and disconnect rf connections to antenna coupler. Remove rf plate from antenna coupler case.</p> <p>b. On rf card, A1A1, remove jumper wire installed adjacent to BNC connector next to (discriminator) shielded area.</p> <p>c. Reconnect rf coax from transceiver to antenna coupler rf input. Connect 50-ohm rf dummy load to P5 through 50-ohm (RG-58) cable.</p> <p>d. Turn on transceiver primary power.</p> <p>e. Tune transceiver to frequencies listed below and measure voltage between chassis ground (-) and indicated pin of A1A1P1 (+) for each frequency. Key transceiver before measuring voltage and unkey before changing frequency.</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 10px auto;"> <p>Note</p> </div> <p>If transceiver does not tune to exact frequency listed, tune to closest frequency.</p> <table style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2"></th> <th colspan="4" style="text-align: center;">Frequency, MHz</th> </tr> <tr> <th colspan="2"></th> <th style="text-align: center;"><u>1.6</u></th> <th style="text-align: center;"><u>8.0</u></th> <th style="text-align: center;"><u>14.0</u></th> <th style="text-align: center;"><u>29.9</u></th> </tr> </thead> <tbody> <tr> <td style="text-align: left;">(Z loading)</td> <td style="text-align: left;">P1-10</td> <td style="text-align: center;">-203 mV</td> <td style="text-align: center;">-202 mV</td> <td style="text-align: center;">-188 mV</td> <td style="text-align: center;">-114 mV</td> </tr> <tr> <td style="text-align: left;">(Phasing)</td> <td style="text-align: left;">P1-11</td> <td colspan="4" style="text-align: center;">varies within -100 to +60 range</td> </tr> <tr> <td style="text-align: left;">(R loading)</td> <td style="text-align: left;">P1-12</td> <td style="text-align: center;">295 mV</td> <td style="text-align: center;">924 mV</td> <td style="text-align: center;">275 mV</td> <td style="text-align: center;">204 mV</td> </tr> <tr> <td style="text-align: left;">(Fwd pwr)</td> <td style="text-align: left;">P1-13</td> <td style="text-align: center;">860 mV</td> <td style="text-align: center;">850 mV</td> <td style="text-align: center;">820 mV</td> <td style="text-align: center;">820 mV</td> </tr> <tr> <td style="text-align: left;">(Refl pwr)</td> <td style="text-align: left;">P1-14</td> <td style="text-align: center;">54 mV</td> <td style="text-align: center;">35 mV</td> <td style="text-align: center;">21 mV</td> <td style="text-align: center;">11 mV</td> </tr> </tbody> </table> <p>f. Turn off transceiver primary power, remove coax cables to antenna coupler, and reconnect jumper removed in step b. Unless test 4 is to be performed next, replace rf plate in antenna coupler case.</p> <p>g. If no further tests are to be performed, disconnect equipment. Otherwise, reconnect rf dummy load to antenna coupler rf output and go to next test.</p>			Frequency, MHz						<u>1.6</u>	<u>8.0</u>	<u>14.0</u>	<u>29.9</u>	(Z loading)	P1-10	-203 mV	-202 mV	-188 mV	-114 mV	(Phasing)	P1-11	varies within -100 to +60 range				(R loading)	P1-12	295 mV	924 mV	275 mV	204 mV	(Fwd pwr)	P1-13	860 mV	850 mV	820 mV	820 mV	(Refl pwr)	P1-14	54 mV	35 mV	21 mV	11 mV	<p>Voltages listed below are nominal.</p>	<p>For P1-10, check or adjust Z discriminator.</p> <p>For P1-11, check or adjust ϕ discriminator.</p> <p>For P1-12, check or adjust R discriminator.</p> <p>For P1-13, check or adjust forward power detector.</p> <p>For P1-14, check or adjust reflected power detector.</p>
		Frequency, MHz																																											
		<u>1.6</u>	<u>8.0</u>	<u>14.0</u>	<u>29.9</u>																																								
(Z loading)	P1-10	-203 mV	-202 mV	-188 mV	-114 mV																																								
(Phasing)	P1-11	varies within -100 to +60 range																																											
(R loading)	P1-12	295 mV	924 mV	275 mV	204 mV																																								
(Fwd pwr)	P1-13	860 mV	850 mV	820 mV	820 mV																																								
(Refl pwr)	P1-14	54 mV	35 mV	21 mV	11 mV																																								

Table 4. CU-380 Antenna Coupler Testing and Troubleshooting (Cont).

TEST	PROCEDURE	NORMAL INDICATION	IF INDICATION IS ABNORMAL
<p>4. Rf path relays, inductors, and capacitors</p>	<p>a. Turn off transceiver primary and disconnect equipment setup.</p> <p>b. Remove rf plate and disconnect ribbon cable connectors from A1A1P1 and P2.</p> <p>c. Connect the locally fabricated relay switch box ribbon cable connectors to A1A1P1 and P2.</p> <p>d. Connect rf vector impedance meter to antenna coupler rf input connector. Disconnect any terminations from antenna coupler rf output connector.</p> <p>e. Apply 12 V dc to relay switch box power input terminals.</p> <p>f. Set relay switch box switches and rf vector impedance meter frequency as shown in the following list. After the test, turn off power, disconnect equipment and reassemble antenna coupler.</p>	<p>Impedance ohms and degrees as indicated in the following list.</p> <p>Impedance changes for each relay change.</p>	<p>Refer to schematic diagram and check components associated with selected relays.</p> <p>Check relay being switched for faulty operation if impedance does not change.</p>

Table 4. CU-380 Antenna Coupler Testing and Troubleshooting (Cont).

TEST	PROCEDURE	RELAY SWITCH BOX	NORMAL INDICATION	IF INDICATION IS ABNORMAL							
				RF VECTOR IMPEDANCE METER							
TEST	K10 K8 K23 K24	K25 K26 K27 K28	K29 K21 K11 K12	K13 K14 K15 K16	K17 K18 K1 K2	K3 K4 K5 K6	K7 K9 K20 K31	K32 K33 K22	FREQ (MHz)	OHMS	DEGREES
INITIAL SETUP	0 0 X X	X X 0 0	X 0 X X	X X X X	X X 0 0	0 0 0 0	0 0 0 0	0 0 0 0	13.0	82	+12
K11	- - - -	- - - -	- - 0 -	- - - -	- - - -	- - - -	- - - -	- - - -	13.0	85	+12
K12	- - - -	- - - -	- - X 0	- - - -	- - - -	- - - -	- - - -	- - - -	13.0	88	+13
K13	- - - -	- - - -	- - - X	0 - - -	- - - -	- - - -	- - - -	- - - -	12.0	86	+16
K14	- - - -	- - - -	- - - -	X 0 - -	- - - -	- - - -	- - - -	- - - -	11.0	88	+19
K15	- - - -	- - - -	- - - -	- X 0 -	- - - -	- - - -	- - - -	- - - -	10.0	98	+26
K16	- - - -	- - - -	- - - -	- - X 0	- - - -	- - - -	- - - -	- - - -	5.0	74	+29
K17	- - - -	- - - -	- - - -	- - - X	0 - - -	- - - -	- - - -	- - - -	3.0	71	+33
K18	- - - -	- - - -	- - - -	- - - -	X 0 - -	- - - -	- - - -	- - - -	2.0	73	+37
K23	- - 0 X	X X X X	0 - - -	- - - -	- X - -	- - - -	- - - -	- - - -	2.0	122	+55
K24	- - X 0	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	2.0	210	+65
K25	- - - X	0 - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	2.0	510	+70
K26	- - - -	X 0 - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	1.5	590	+74
STRAY C	- - - -	- X 0 0	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	2.0	740	-90
K20	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - X -	- - - -	2.0	640	-90
K1	- - - -	- - - -	- - - -	- - - -	- - X -	- - - -	- - 0 -	- - - -	2.0	590	-90
K2	- - - -	- - - -	- - - -	- - - -	- - 0 X	- - - -	- - - -	- - - -	2.0	510	-90
K3	- - - -	- - - -	- - - -	- - - -	- - - 0	X - - -	- - - -	- - - -	2.0	400	-90
K4	- - - -	- - - -	- - - -	- - - -	- - - -	0 X - -	- - - -	- - - -	2.0	305	-90
K5	- - - -	- - - -	- - - -	- - - -	- - - -	- 0 X -	- - - -	- - - -	2.0	200	-90
K6	- - - -	- - - -	- - - -	- - - -	- - - -	- - 0 X	- - - -	- - - -	2.0	130	-90
K7	- - - -	- - - -	- - - -	- - - -	- - - -	- - - 0	X - - -	- - - -	2.0	80	-90
K8	- X - -	- - - -	- - - -	- - - -	- - - -	- - - -	0 - - -	- - - -	2.0	47	-89
K9	- 0 - -	- - - -	- - - -	- - - -	- - - -	- - - -	- X - -	- - - -	2.0	26	-88
K10	X - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- 0 - -	- - - -	2.0	14	-86
INTERNAL R	0 - - -	- - - -	- - X -	- - - -	- - - -	- - - -	- - - -	- - - -	2.0	100	-6
K31	- - - -	- - - -	- - 0 -	- - - -	- - - -	- - - -	- - - X	- - - -	2.0	490	-90
K32	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - 0	X - - -	2.0	390	-90
K33	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	0 X - -	2.0	290	-90
K22	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- - - -	- 0 X	2.0	200	-90

SWITCH SETTINGS:
X = CLOSED
0 = OPEN
- = NO CHANGE FROM PREVIOUS SETTING

6. REPAIR

6.1 *Electrostatic Discharge Sensitive Devices Precautions*

A static charge is produced by friction between, and separation of, dissimilar materials. Potentials of 1 to 20 kilovolts are commonly generated on the human body or insulated surfaces. Voltages of this magnitude can produce both immediate and latent failure in electrostatic discharge sensitive (ESDS) devices.

Note

Dry weather (relative humidity less than 30 percent) multiplies the accumulation of static charges on a surface. In a low-humidity environment, the handling procedures specified are of greater importance and should be adhered to without exception.

6.1.1 *Handling of ESDS Devices*

Caution

Do not use gloves made of nylon or other synthetic material when handling ESDS devices. Excessive static can build up on this type of material. Handle ESDS devices by their case whenever possible. Avoid touching the leads or contacts even though grounded.

The transport of circuit board or module subassemblies containing ESDS devices requires that contact with exposed subassemblies be prevented. Conductive plastic bags, not clear polyvinyl, are well suited to this purpose. After the subassembly containing ESDS devices is installed in the top level unit, normal ESDS devices handling is adequate.

6.1.2 *Testing of Subassemblies Containing ESDS Devices*

Observe the following precautions when testing any subassembly containing ESDS devices.

- a. Remove power from test fixtures of equipment before inserting/removing any ESDS device or subassembly containing an ESDS device.
- b. Ensure all test equipment is well grounded.
- c. Apply dc source power to ESDS device or subassembly containing an ESDS device before applying any signal voltages.

- d. Remove signal voltages from ESDS device or subassembly containing an ESDS device before removing dc source power.
- e. Dielectric strength or insulation resistance checks are not recommended for any ESDS device or subassembly containing an ESDS device.

6.2 *Postcoating*

6.2.1 *General*

The control and rf cards are coated with postcoating material upon completion of manufacture to protect them from damage and humidity. This material is HumiSeal 1B31. The coating must be removed from both sides of the circuit card in the area to be repaired. To restore protection from humidity, repostcoat the circuit card as specified in paragraph 6.3.2.

6.2.2 *HumiSeal 1B31 Removal*

Use small brush or pipe cleaner and apply solvent (Freon TMC or equivalent) to remove the HumiSeal 1B31 postcoating from the component lead and mounting pad on both sides of the circuit card.

6.2.3 *HumiSeal 1B31 Replacement*

- a. After component removal and replacement, apply solvent to resoldered areas on both sides of circuit card. Allow card to air dry 4 hours at room temperature or bake it for 20 minutes at 71 °C (160 °F) before applying postcoating. This prevents bubbles from occurring in newly applied postcoating.

Warning

Postcoating should be performed only in a well-ventilated area.

- b. Use small brush and apply HumiSeal 1B31 liberally (but not excessively) to replaced component and both sides of circuit card (mounting pads, holes, and adjacent areas of board). Ensure that coverage is complete and new coating overlays existing coating on adjacent areas of board.

Note

HumiSeal 1B31 is runny when first applied and somewhat soft when hot. Be careful not to damage postcoating during the drying or cool-down period.

c. If only a small area of the circuit card has been repostcoated, air dry for 4 hours at room temperature. If entire circuit card has been repostcoated, bake it for 45 minutes at 80 to 100 °C (176 to 212 °F).

7. PARTS LIST/DIAGRAMS

7.1 Group Assembly Parts List

7.1.1 Introduction

7.1.1.1 General

The purpose of this parts list is for identification and requisition of parts.

Parts listed meet critical equipment design specification requirements. Use only part numbers specified in this parts list for replacement of parts.

7.1.1.2 Group Assembly Parts List

FIG - ITEM Column — Digits preceding the dash refer to figure numbers. Digits following the dash are item numbers assigned in sequence to correspond with item numbers on the illustrations.

PART NO Column — Listed are MIL standard, vendor, or Collins part numbers. Collins part numbering system consists of 10 digits as follows: a 3-digit family number, a 4-digit serial number, and a 3-digit dash number.

INDENT Column — Items are coded 1, 2, 3, etc, to indicate the relationship to the next higher assembly.

DESCRIPTION Column — Lists the noun name, modifier, descriptive information, federal manufacturer's code, reference designation, attaching part (AP), reference to other figures, and effectivities.

Attaching parts are identified by (AP) following the part or parts they attach.

Effectivities are identified by the following methods: MCN (Manufacturer Control Number) 101 and up; CI (Configuration Identifier) 5-digit number; REV (Revision Identifier) dash (-) denotes original, letter A first change, letter B second change, etc. One of the above identifiers is listed on each chassis and/or replaceable assembly. Service Bulletins are identified by SB 1, SB 2, etc.

USABLE ON CODE Column — Part variations within a group of equipment are indicated by a letter code (A, B, C, etc). Absence of a code indicates part applies to all models.

UNITS PER ASSY Column — Quantities specified are per item number. Letters AR denote the selection of parts as required. Letters RF refer to an assembly completely assembled on a preceding figure and illustration.

7.1.1.3 Numerical Index

PART NUMBER Column — Part numbers are listed in alphanumeric sequence.

FIG - ITEM Column — Digits preceding the dash refer to figure numbers. Digits following the dash are item numbers.

TTL REQ Column — Listed is the total quantity of parts or assemblies covered in the Group Assembly Parts List.

7.1.1.4 Reference Designation Index

REFERENCE DESIGNATION Column — Reference designations are listed in alphanumeric sequence.

FIG - ITEM Column — Digits preceding the dash refer to figure numbers. Digits following the dash are item numbers.

PART NUMBER Column — Part numbers listed are for items that have reference designations assigned.

7.1.1.5 How To Use This Parts List


To locate a part number if the assembly in which the part is used is known, find the figure for the assembly in which the part is used. Locate the part and its index number on the illustration and find the index number on the Group Assembly Parts List page to determine its description and part number.

To locate the illustration for a part if the part number is known, refer to the Numerical Index and find the part number. Turn to the Group Assembly Parts List and find the first figure and index number indicated in the Numerical Index for that part. If this figure shows the part in a section or system of the equipment other than the one desired, refer to the other figure numbers listed in the Numerical Index.

To locate the illustration for a part if the reference designation is known, refer to the Reference Designation Index and find the symbol; turn to the Group Assembly Parts List and find the figure and index number indicated in the index.

7.1.1.6 Electrostatic Sensitive Devices

This equipment contains electrostatic devices (ESDS). Special handling methods and materials must be utilized to prevent equipment damage. Refer to the testing/troubleshooting paragraph for this equipment before assembly/disassembly or repair is performed.



7.1.1.7 Manufacturer's Code, Name, and Address

<u>MFR CODE</u>	<u>MANUFACTURER'S NAME AND ADDRESS</u>
02660	BUNKER RAMO CORP AMPHENOL NORTH AMERICA DIV 2801 S 25TH AVE BROADVIEW IL 60153
05690	BARKER AND WILLIAMSON INC 10 CANAL ST BRISTOL PA 19007
07263	FAIRCHILD CAMERA AND INSTRUMENT CORP SEMICONDUCTOR DIV SUB OF SCHLUMBERGER LTD NORTH AMERICAN SALES MAIL STOP 14-1053 401 ELLIS ST P O DRAWER 7284 MOUNTAIN VIEW CA 94042
13499	ROCKWELL INTERNATIONAL CORP COLLINS TELECOMMUNICATIONS PRODUCTS DIV 855 35TH ST NE P O BOX 728 CEDAR RAPIDS IA 52498
21052	HIGH ENERGY CORP LOWER VALLEY RD PARKESBURG PA 19305
25184	PRECISION RUBBER PRODUCTS CORP HARTMAN DRIVE LEBANON TN 37087
28478	DELTRON CONTROLS DIV DELTRON CORP 2745 S 19TH ST MILWAUKEE WI 53215

MFR CODE MANUFACTURER'S NAME AND ADDRESS

59730	THOMAS AND BETTS CORP HWY 218 S IOWA CITY IA 52240
79807	WROUGHT WASHER MFG INC 2100 S BAY ST MILWAUKEE WI 53207
81349	MILITARY SPECIFICATIONS
83330	SMITH HERMAN H INC 812 SNEDIKER AVE BROOKLYN NY 11207
88044	AERONAUTICAL STANDARD
91886	MICRODOT MANUFACTURING INC MALCO MFG DIV 12 PROGRESS DR MONTGOMERYVILLE PA 18936
96906	MILITARY STANDARD
71400	MCGRAW-EDISON CO BUSSMANN MFG DIV 502 EARTH CITY PLAZA P O BOX 14460 ST LOUIS MO 63178
73905	ITT JENNINGS 970 MC LAUGHLIN AVE SAN JOSE CA 95116
77147	PATTON-MACGUYER CO DIV OF AVID CORP 17 VIRGINIA AVE PROVIDENCE RI 02905
77250	ALLIED PRODUCTS CORP PHEOLL MFG CO DIV 5700 W ROOSEVELT RD CHICAGO IL 60650


7.1.1.8 Reference Designation Prefixes

<u>PREFIX</u>	<u>UNIT PART NUMBER</u>	<u>FIG-ITEM</u>
A1	651-4323-001	2


7.1.1.9 Configuration Identifiers

<u>CI/REV LTR</u>	<u>UNIT PART NUMBER</u>	<u>FIG-ITEM</u>
E	622-3573-001	9
B	651-4323-001	10

7.1.2 Group Assembly Parts List



FRONT VIEW



REAR VIEW


TPA-5557-01 /

**CU-380 Antenna Coupler
Figure 9**

GROUP ASSEMBLY PARTS LIST

FIG-ITEM	PART NO	INDENT	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
9-	622-3573-001		1 COUPLER, ANTENNA-CU 380	1	
1	642-0082-000		2 PLATE,IDENT	1	
	MS51957-14		2 SCREW,MACH SST, 4-40 X 5/16 (96906) 343-0134-000 (AP)	2	
2	651-4363-001		2 COVER	1	
	110-8		2 WASHER,SEALING CD PL STL, 0.234 ID X 0.364 OD (25184) 310-0442-000 (AP)	6	
	MS51957-46		2 SCREW,MACHINE SST, 8-32 X 5/8 (96906) 343-0190-000 (AP)	6	
3	141		2 LOCKNUT,ELEC CN (59730) 019-0098-000	1	
4	2522		2 CONNECTOR, PLUG ELEC (59730) 019-0747-000	1	
5	MS51957-14		2 SCREW,MACH SST, 4-40 X 5/16 (96906) 343-0134-000	4	
6	651-4323-001		2 PLATE,RF A1 (SEE FIG 2)	1	
	MS15795-805		2 WASHER,FLAT CRES, 0.164ID X 0.320 OD (96906) 310-0779-050 (AP)	6	
	MS51957-28		2 SCREW,MACH SST, 6-32 X 3/8 (96906) 343-0169-000 (AP)	6	
7	P343-0368-000		2 SCREW,MACH NP BRS, 1/4-20 X 3/4 (77250) 343-0368-000	1	
	P313-0148-000		2 NUT,PLAIN,HEX NP BRS, 1/4-20 (77250) 313-0148-000 (AP)	2	
	MS35338-101		2 WASHER,SPRING CD PL BRZ, 0.255 ID X 0.489 OD (96906) 310-0102-000 (AP)	2	
8	9548		2 INSULATOR,FEEDT (83330) 190-0266-000	1	
	P313-0056-000		2 NUT,PLAIN,HEX NP BRS, 10-32 (77250) 313-0056-000 (AP)	1	
	MS35338-100		2 WASHER,SPRING CD PL BRZ, 0.194 ID X 0.334 OD (96906) 310-0100-000 (AP)	1	
	AN961-10T		2 WASHER,FLAT TP BRS, 0.203 ID X 0.438 OD (88044) 310-0751-020 (AP)	2	
9	652-0669-002		2 GASKET	1	
10	652-0669-001		2 GASKET	1	
11	651-4526-001		2 PLATE,NON-TURN	1	
12	651-4369-001		2 CONTACT,ELECTRICAL	1	
13	651-4331-001		2 CASE,PRESSED	1	


GROUP ASSEMBLY PARTS LIST



TPA-5556-029

RF Plate A1
Figure 10 (Sheet 1 of 2)

GROUP ASSEMBLY PARTS LIST



TPA-5556-029

RF Plate A1
Figure 10 (Sheet 2)

GROUP ASSEMBLY PARTS LIST

FIG-ITEM	PART NO	INDET	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
10-	651-4323-001	1	RF PLATE A1 [SEE FIG 1-6 FOR NHA]	REF	
1	651-4420-001	2	LEAD,ELECTRICAL	4	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	4007-6HT	2	TERMINAL,LUG (77147) 304-0016-000 (AP)	4	
	MS51957-26	2	SCREW,MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
2	21702-71	2	RELAY,ARMATURE (28478) 970-0500-020 A1K22	1	
3	J1HT50UJ101J502	2	CAPACITOR,FIXED CER DIEI, 100PF, 5%, 5000V (73905) 913-0833-000 A1C29	1	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW,MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
4	J1HT50CG500J502	2	CAPACITOR,FIXED CER DIEI, 50PF, 5%, 5000V (73905) 913-0834-000 A1C26	1	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW,MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
5	J1HT50UJ101J502	2	CAPACITOR,FIXED CER DIEI, 100PF, 5%, 5000V (73905) 913-0833-000 A1C30	1	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW,MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
6	651-4368-001	2	BLOCK,INSULATOR	1	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-29	2	SCREW,MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	2	
7	HT54T109DK	2	CAPACITOR,FXD CER DIEI, 1PF, PORM 0.5PF, 500V (21052) 913-0756-000 A1C53	1	
8	HT54T109DK	2	CAPACITOR,FXD CER DIEI, 1PF, PORM 0.5PF, 500V (21052) 913-0756-000 A1C54	1	
	4040-2HT	2	TERMINAL,LUG (77147) 304-0014-000 (AP)	2	
	MS15795-802	2	WASHER,FLAT CRES, 0.094ID X 0.250 OD (96906) 310-0779-020 (AP)	1	
	P312-0222-000	2	STUD,CONT THD BRS, 2-56 X 3/16 (77250) 312-0222-000 (AP)	1	
	310-0070-000	2	WASHER,LOCK SST, 0.097 ID X 0.165 OD (79807) (AP)	3	
	MS51957-5	2	SCREW,MACH SST, 2-56 X 3/8 (96906) 343-0126-000 (AP)	1	
	MS51957-2	2	SCREW,MACH SST, 2-56 X 3/16 (96906) 343-0123-000 (AP)	1	
9	5960-07	2	CLIP,ELEC (71400) 265-1005-000	1	
	MS35338-138	2	WASHER,LOCK SST, 0.194 ID X 0.334 OD (96906) 310-0284-000 (AP)	1	
	MS51958-60	2	SCREW,MACH SST, 10-32 X 5/16 (96906) 343-0225-000 (AP)	1	
10	2115	2	TERMINAL,LUG (91886) 304-1466-010	2	
11	21702-70	2	RELAY,ARMATURE (28478) 970-0500-010 A1K30	1	
12	21702-70	2	RELAY,ARMATURE (28478) 970-0500-010 A1K29	1	
13	3027-3907-1	2	INDUCTOR (05690) 980-0150-010 A1L13	1	
14	651-4410-001	2	SUPPORT,COIL	1	
	500-8928-001	2	POST (AP)	4	
	MS15795-805	2	WASHER,FLAT CRES, 0.164ID X 0.320 OD (96906) 310-0779-050 (AP)	4	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	8	
	MS51957-29	2	SCREW,MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	8	
15	J1HT50UJ800J502	2	CAPACITOR,FIXED CER DIEI, 80PF, 5%, 5000V (73905) 913-0848-000 A1C31	1	
	MS35338-136	2	WASHER,LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW,MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
16	21702-70	2	RELAY,ARMATURE (28478) 970-0500-010 A1K28	1	
17	J1HT50CG400J502	2	CAPACITOR,FIXED CER DIEI, 40PF, 5%, 5000V (73905) 913-0836-000 A1C25	1	

GROUP ASSEMBLY PARTS LIST

FIG-ITEM	PART NO	INDENT	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
10-	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW, MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
18	21702-70	2	RELAY, ARMATURE (28478) 970-0500-010 A1K26	1	
19	3027-3907-1	2	INDUCTOR (05690) 980-0150-010 A1L11	1	
20	21702-70	2	RELAY, ARMATURE (28478) 970-0500-010 A1K25	1	
21	21702-70	2	RELAY, ARMATURE (28478) 970-0500-010 A1K27	1	
22	3027-3907-1	2	INDUCTOR (05690) 980-0150-010 A1L10	1	
23	21702-70	2	RELAY, ARMATURE (28478) 970-0500-010 A1K24	1	
24	3027-3907-1	2	INDUCTOR (05690) 980-0150-010 A1L9	1	
25	21702-70	2	RELAY, ARMATURE (28478) 970-0500-010 A1K23	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	12	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	12	
26	651-4411-001	2	SUPPORT, COIL	1	
	500-8928-001	2	POST, HEX (AP)	4	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	8	
	MS15795-805	2	WASHER, FLAT CRES, 0.164 ID X 0.320 OD (96906) 310-0779-050 (AP)	4	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	4	
27	651-3868-001	2	PLATE, SHIELD	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	8	
	MS15795-805	2	WASHER, FLAT CRES, 0.164 ID X 0.320 OD (96906) 310-0779-050 (AP)	4	
27	540-9209-000	2	POST HEX	4	
	P312-0075-000	2	STUD, CONT THD STL, 8-32 X 1/2 (77250) 312-0075-000 (AP)	3	
	MS51957-26	2	SCREW, MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	5	
28	83-798	2	CONNECTOR, RCPT ELEC (02660) 357-9005-000 A1J1	1	
	MS51957-14	2	SCREW, MACH SST, 4-40 X 5/16 (96906) 343-0134-000 (AP)	4	
29	651-4367-001	2	BRACKET, CONNECTOR	1	
	MS15795-803	2	WASHER, FLAT CRES, 0.125 ID X 0.250 OD (96906) 310-0779-030 (AP)	2	
	MS51957-14	2	SCREW, MACH SST, 4-40 X 5/16 (96906) 343-0134-000 (AP)	2	
30	651-4324-002	2	ASSEMBLY, CABLE-NO 2	1	
31	651-4324-001	2	ASSEMBLY, CABLE-NO 1	1	
32	651-3550-001	2	ASSEMBLY, CABLE-NO 3	1	
33	651-3851-001	2	ASSEMBLY, CABLE-NO 4	1	
34	646-5871-001	2	CARD, RF A1A1	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	20	
	MS15795-805	2	WASHER, FLAT CRES, 0.164 ID X 0.320 OD (96906) 310-0779-050 (AP)	9	
	540-9225-003	2	POST, HEX (AP)	12	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	20	
35	J1HT50CG500J502	2	CAPACITOR, FIXED CER DIEI, 50PF, 5%, 5000V (73905) 913-0834-000 A1C32	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW, MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
36	21702-71	2	RELAY, ARMATURE (28478) 970-0500-020 A1K31	1	
37	21702-71	2	RELAY, ARMATURE (28478) 970-0500-020 A1K32	1	
38	21702-71	2	RELAY, ARMATURE (28478) 970-0500-020 A1K33	1	
39	J1HT50UJ800J502	2	CAPACITOR, FIXED CER DIEI, 80PF, 5%, 5000V (73905) 913-0848-000 A1C27	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW, MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
40	J1HT50UJ800J502	2	CAPACITOR, FIXED CER DIEI, 80PF, 5%, 5000V (73905) 913-0848-000 A1C28	1	

GROUP ASSEMBLY PARTS LIST

FIG-ITEM	PART NO	INDENT	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
10-	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-26	2	SCREW, MACH SST, 6-32 X 1/4 (96906) 343-0167-000 (AP)	2	
41	646-5867-001	2	CARD, CONTROL A1A2	1	
	P313-0132-000	2	NUT, PLAIN, HEX SST, 4-40 (77250) 313-0132-000 (AP)	6	
	MS35338-135	2	WASHER, LOCK SST, 0.115 ID X 0.209 OD (96906) 310-0279-000 (AP)	12	
	MS15795-803	2	WASHER, FLAT CRES, 0.125 ID X 0.250 OD (96906) 310-0779-030 (AP)	6	
	540-9162-003	2	POST, ELEC-MECH (AP)	6	
	MS51957-18	2	SCREW, MACH STL, 4-40 X 5/8 (96906) 343-0138-000 (AP)	5	
42	651-4379-001	2	PLATE, RELAY	1	
43	3022	2	INDUCTOR (05690) 980-0150-030 A1L13	1	
44	651-3836-001	2	SUPPORT, COIL	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	2	
45	3022	2	INDUCTOR (05690) 980-0150-030 A1L14	1	
46	651-3854-001	2	SUPPORT, COIL	2	
	500-8926-001	2	POST (AP)	4	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	8	
	MS15795-805	2	WASHER, FLAT CRES, 0.164 ID X 0.320 OD (96906) 310-0779-050 (AP)	8	
	MS51957-30	2	SCREW, MACH SST, 6-32 X 1/2 (96906) 343-0171-000 (AP)	4	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	4	
47	3022	2	INDUCTOR (05690) 980-0150-030 A1L15	1	
48	651-3854-001	2	SUPPORT, COIL	1	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS15795-805	2	WASHER, FLAT CRES, 0.164 ID X 0.320 OD (96906) 310-0779-050 (AP)	2	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	2	
49	HT54T109DK	2	CAPACITOR, FXD CER DIE, 1PF, PORM 0.5PF, 500V (21052) 913-0756-000 A1C55	1	
50	HT54T109DK	2	CAPACITOR, FXD CER DIE, 1PF, PORM 0.5PF, 500V (21052) 913-0756-000 A1C56	1	
	4040-2HT	2	TERMINAL, LUG (77147) 304-0014-000 (AP)	1	
	310-0070-000	2	WASHER, LOCK SST, 0.097 ID X 0.165 OD (79807) (AP)	3	
	MS15795-802	2	WASHER, FLAT CRES, 0.094 ID X 0.250 OD (96906) 310-0779-020 (AP)	1	
	P312-0222-000	2	STUD, CONT THD BRS, 2-56 X 3/16 (77250) 312-0222-000 (AP)	1	
	MS51957-2	2	SCREW, MACH SST, 2-56 X 3/16 (96906) 343-0123-000 (AP)	2	
51	651-3846-001	2	COIL A1L20	1	
52	651-3845-001	2	COIL A1L19	1	
53	651-3867-003	2	PAD, RUBBER	1	
54	651-3844-001	2	COIL A1L18	1	
55	651-3843-001	2	COIL A1L17	1	
56	651-3842-001	2	COIL A1L16	1	
57	651-3867-001	2	PAD, RUBBER	1	
58	651-3867-002	2	PAD, RUBBER	1	
59	651-3852-001	2	ASSEMBLY, CABLE-NO 5	1	
60	MS77068-2	2	TERMINAL, LUG (96906) 304-3120-010	1	
	P313-0045-000	2	NUT, PLAIN, HEX SST, 6-32 (77250) 313-0045-000 (AP)	2	
	MS35338-136	2	WASHER, LOCK SST, 0.141 ID X 0.250 OD (96906) 310-0282-000 (AP)	2	
	MS51957-29	2	SCREW, MACH SST, 6-32 X 7/16 (96906) 343-0170-000 (AP)	2	
61	CK06BX104K	2	CAPACITOR, FIXED CER DIE, 0.1UF, 10%, 100VDC (81349) 913-5019-440 A1C51	1	
62	CK06BX684K	2	CAPACITOR, FIXED CER DIE, 0.68UF, 10%, 50VDC (81349) 913-5019-540 A1C52	1	
63	UA78H05SC	2	INTEGRATED CIRCUIT VOLTAGE REGULATOR (ESDS) (07263) 351-1342-010 A1VR1	1	

7.1.3 Numerical Index

PART NUMBER	FIG-ITEM	TTL REQ	PART NUMBER	FIG-ITEM	TTL REQ
AN961-10T	9-8	2	MS51957-26	10-1	
CK06BX104K	10-61	1		10-3	
CK06BX684K	10-62	1		10-4	
HT54T109DK	10-7			10-5	
	10-8			10-15	
	10-49			10-17	
	10-50	4		10-27	
J1HT50CG400J502	10-17	1		10-35	
J1HT50CG500J502	10-4			10-39	
	10-35	2		10-40	23
J1HT50UJ101J502	10-3		MS51957-28	9-6	6
	10-5	2	MS51957-29	10-6	
J1HT50UJ800J502	10-15			10-14	
	10-39			10-25	
	10-40	3		10-26	
MS15795-802	10-8			10-34	
	10-50	2		10-44	
MS15795-803	10-29			10-46	
	10-41	8		10-48	
MS15795-805	9-6			10-60	56
	10-14		MS51957-30	10-46	4
	10-26		MS51957-46	9-2	6
	10-27		MS51957-5	10-8	1
	10-34		MS51958-60	10-9	1
	10-46		MS77068-2	10-60	1
	10-48	37	P312-0075-000	10-27	3
MS35338-100	9-8	1	P312-0222-000	10-8	
MS35338-101	9-7	2		10-50	2
MS35338-135	10-41	12	P313-0045-000	10-60	2
MS35338-136	10-1		P313-0056-000	9-8	1
	10-3		P313-0132-000	10-41	6
	10-4		P313-0148-000	9-7	2
	10-5		P343-0368-000	9-7	1
	10-6		UA78H05SC	10-63	1
	10-14		019-0098-000	9-3	1
	10-15		019-0747-000	9-4	1
	10-17		110-8	9-2	6
	10-25		141	9-3	1
	10-26		190-0266-000	9-8	1
	10-27		2115	10-10	2
	10-34		21702-70	10-11	
	10-35			10-12	
	10-39			10-16	
	10-40			10-18	
	10-44			10-20	
	10-46			10-21	
	10-48			10-23	
	10-60	90		10-25	8
MS35338-138	10-9	1	21702-71	10-2	
MS51957-14	9-1			10-36	
	9-5			10-37	
	10-28			10-38	4
	10-29	12	2522	9-4	1
MS51957-18	10-41	5	265-1005-000	10-9	1
MS51957-2	10-8		3022	10-43	
	10-50	3		10-45	

NUMERICAL INDEX

PART NUMBER	FIG-ITEM	TTL REQ	PART NUMBER	FIG-ITEM	TTL REQ
3022	10-47	3	343-0167-000	10-1	
3027-3907-1	10-13			10-3	
	10-19			10-4	
	10-22			10-5	
	10-24	4		10-15	
304-0014-000	10-8			10-17	
	10-50	3		10-27	
304-0016-000	10-1	4		10-35	
304-1466-010	10-10	2		10-39	
304-3120-010	10-60	1		10-40	23
310-0070-000	10-8		343-0169-000	9-6	6
	10-50	6	343-0170-000	10-6	
310-0100-000	9-8	1		10-14	
310-0102-000	9-7	2		10-25	
310-0279-000	10-41	12		10-26	
310-0282-000	10-1			10-34	
	10-3			10-44	
	10-4			10-46	
	10-5			10-48	
	10-6			10-60	56
	10-14		343-0171-000	10-46	4
	10-15		343-0190-000	9-2	6
	10-17		343-0225-000	10-9	1
	10-25		343-0368-000	9-7	1
	10-26		351-1342-010	10-63	1
	10-27		357-9005-000	10-28	1
	10-34		4007-6HT	10-1	4
	10-35		4040-2HT	10-8	
	10-39			10-50	3
	10-40		500-8926-001	10-46	4
	10-44		500-8928-001	10-14	
	10-46			10-26	8
	10-48		540-9162-003	10-41	6
	10-60	90	540-9209-000	10-27	4
310-0284-000	10-9	1	540-9225-003	10-34	12
310-0442-000	9-2	6	5960-07	10-9	1
310-0751-020	9-8	2	622-3573-001	9-	1
310-0779-020	10-8		642-0082-000	9-1	1
	10-50	2	646-5867-001	10-41	1
310-0779-030	10-29		646-5871-001	10-34	1
	10-41	8	651-3550-001	10-32	1
310-0779-050	9-6		651-3836-001	10-44	1
	10-14		651-3842-001	10-56	1
	10-26		651-3843-001	10-55	1
	10-27		651-3844-001	10-54	1
	10-34		651-3845-001	10-52	1
	10-46		651-3846-001	10-51	1
	10-48	37	651-3851-001	10-33	1
312-0075-000	10-27	3	651-3852-001	10-59	1
312-0222-000	10-8		651-3854-001	10-46	
	10-50	2		10-48	3
313-0045-000	10-60	2	651-3867-001	10-57	1
313-0056-000	9-8	1	651-3867-002	10-58	1
313-0132-000	10-41	6	651-3867-003	10-53	1
313-0148-000	9-7	2	651-3868-001	10-27	1
343-0123-000	10-8		651-4323-001	9-6	1
	10-50	3		10-	REF
343-0126-000	10-8	1	651-4324-001	10-31	1
343-0134-000	9-1		651-4324-002	10-30	1
	9-5		651-4331-001	9-13	1
	10-28		651-4363-001	9-2	1
	10-29	12	651-4367-001	10-29	1
343-0138-000	10-41	5	651-4368-001	10-6	1

NUMERICAL INDEX

PART NUMBER	FIG-ITEM	TTL REQ	PART NUMBER	FIG-ITEM	TTL REQ
651-4369-001	9-12	1			
651-4379-001	10-42	1			
651-4410-001	10-14	1			
651-4411-001	10-26	1			
651-4420-001	10-1	4			
651-4526-001	9-11	1			
652-0669-001	9-10	1			
652-0669-002	9-9	1			
83-798	10-28	1			
913-0756-000	10-7				
	10-8				
	10-49				
	10-50	4			
913-0833-000	10-3				
	10-5	2			
913-0834-000	10-4				
	10-35	2			
913-0836-000	10-17	1			
913-0848-000	10-15				
	10-39				
	10-40	3			
913-5019-440	10-61	1			
913-5019-540	10-62	1			
9548	9-8	1			
970-0500-010	10-11				
	10-12				
	10-16				
	10-18				
	10-20				
	10-21				
	10-23				
	10-25	8			
970-0500-020	10-2				
	10-36				
	10-37				
	10-38	4			
980-0150-010	10-13				
	10-19				
	10-22				
	10-24	4			
980-0150-030	10-43				
	10-45				
	10-47	3			

7.1.4 Reference Designation Index

REFERENCE DESIGNATION	FIG-ITEM	PART NUMBER	REFERENCE DESIGNATION	FIG-ITEM	PART NUMBER
A1	9-6	651-4323-001			
A1	10-	651-4323-001			
A1A1	10-34	646-5871-001			
A1A2	10-41	646-5867-001			
A1C25	10-17	J1HT50CG400J502			
A1C26	10-4	J1HT50CG500J502			
A1C27	10-39	J1HT50UJ800J502			
A1C28	10-40	J1HT50UJ800J502			
A1C29	10-3	J1HT50UJ101J502			
A1C30	10-5	J1HT50UJ101J502			
A1C31	10-15	J1HT50UJ800J502			
A1C32	10-35	J1HT50CG500J502			
A1C51	10-61	CK06BX104K			
A1C52	10-62	CK06BX684K			
A1C53	10-7	HT54T109DK			
A1C54	10-8	HT54T109DK			
A1C55	10-49	HT54T109DK			
A1C56	10-50	HT54T109DK			
A1J1	10-28	83-798			
A1K22	10-2	21702-71			
A1K23	10-25	21702-70			
A1K24	10-23	21702-70			
A1K25	10-20	21702-70			
A1K26	10-18	21702-70			
A1K27	10-21	21702-70			
A1K28	10-16	21702-70			
A1K29	10-12	21702-70			
A1K30	10-11	21702-70			
A1K31	10-36	21702-71			
A1K32	10-37	21702-71			
A1K33	10-38	21702-71			
A1L10	10-22	3027-3907-1			
A1L11	10-19	3027-3907-1			
A1L13	10-13	3027-3907-1			
A1L13	10-43	3022			
A1L14	10-45	3022			
A1L15	10-47	3022			
A1L16	10-56	651-3842-001			
A1L17	10-55	651-3843-001			
A1L18	10-54	651-3844-001			
A1L19	10-52	651-3845-001			
A1L20	10-51	651-3846-001			
A1L9	10-24	3027-3907-1			
A1VR1	10-63	UA78H05SC			


7.2 Padmaster Parts List

7.2.1 Introduction

Caution

This equipment contains electrostatic discharge sensitive (ESDS) devices. Special handling methods and materials must be used to prevent equipment damage. Refer to the testing/troubleshooting paragraph for the equipment before assembly/disassembly or repair is performed. ESDS items are identified in the description column of the parts list by (ESDS).

All parts list illustrations containing ESDS items are shown with the following symbol:



This paragraph assists in identification and requisition of parts. A parts location illustration, schematic diagram, parts list tabulation, and modification history are included. The parts location illustration is a design engineering drawing that shows exact component placement on the circuit cards.

Use the reference designator indicated on the schematic and parts location diagram to locate parts in the parts list tabulation. The description, Collins part number, usable on code, manufacturer's code and manufacturer's part number are listed for each reference designator.

7.2.2 Parts List

REF DES Column — Reference designators of each part/subassembly are listed in alphanumeric sequence. These are the reference designators shown on the parts location drawing and schematic diagram.

DESCRIPTION Column — Lists the noun name, modifier, descriptive information, and modification.

Modifications are identified by an alphanumeric identifier assigned to each design change. These identifiers are referenced in the DESCRIPTION column of the parts list in parentheses and on the schematic diagram inside an arrow that points to the change. Each change relates to the revision identifier

(REV) stamped on the circuit card/subassembly and is listed in the EFFECTIVITY column of the modification history. NA (not applicable) in the REVISION IDENT column indicates a documentation change only. The change does not affect the circuit card/subassembly components.

COLLINS PART NUMBER Column — Lists the Collins part number for each item in the parts list.

USABLE ON CODE Column — Part variations within a group of equipment are indicated by a letter code (A, B, C, etc). Absence of a code indicates part applies to all models.

MFR CODE Column — Lists the manufacturer's code from which selected parts can be procured.

MFR PART NUMBER Column — Lists the manufacturer's part number for the selected parts.

Listed below are manufacturer's names and addresses for the manufacturer's codes found in this parts list.

<u>MFR CODE</u>	<u>MANUFACTURER'S NAME AND ADDRESS</u>
00779	AMP INC P O BOX 3608 HARRISBURG PA 17105
00853	SANGAMO WESTON INC SANGAMO CAPACITOR DIV SANGAMO RD P O BOX 128 PICKENS SC 29671
01121	ALLEN-BRADLEY CO 1201 SOUTH 2ND ST MILWAUKEE WI 53204
01295	TEXAS INSTRUMENTS INC SEMICONDUCTOR GROUP 13500 N CENTRAL EXPRESSWAY P O BOX 225012 M/S 49 DALLAS TX 75265
02735	RCA CORP SOLID STATE DIVISION ROUTE 202 SOMERVILLE NJ 08876
03508	GENERAL ELECTRIC CO SEMI-CONDUCTOR PRODUCTS DEPT W GENESEE ST AUBURN NY 13021
04713	MOTOROLA INC SEMICONDUCTOR GROUP 5005 E MCDOWELL RD PHOENIX AZ 85008

<u>MFR CODE</u>	<u>MANUFACTURER'S NAME AND ADDRESS</u>
07263	FAIRCHILD CAMERA AND INSTRUMENT CORP SEMICONDUCTOR DIV SUB OF SCHLUMBERGER LTD NORTH AMERICAN SALES MAIL STOP 14-1053 401 ELLIS ST P O DRAWER 7284 MOUNTAIN VIEW CA 94042
12998	QUALITY NAME PLATE INC MILL ROAD EAST GLASTONBURY CT 06025
13499	ROCKWELL INTERNATIONAL CORP COLLINS TELECOMMUNICATIONS PRODUCTS DIV 855 35TH ST NE P O BOX 728 CEDAR RAPIDS IA 52498
14099	SEMTECH CORP 652 MITCHELL ROAD NEWBURY PARK CA 91320
14433	ITT SEMICONDUCTOR DIV WEST PALM BEACH FL
14936	GENERAL INSTRUMENT CORP DISCRETE SEMI CONDUCTOR DIV 600 W JOHN ST HICKSVILLE NY 11802
15238	ITT SEMICONDUCTORS A DIVISION OF INTERNATIONAL TELEPHONE AND TELEGRAPH CORP 500 BROADWAY P O BOX 168 LAWRENCE MA 01841
19647	CADDOCK ELECTRONICS INC 1717 CHICAGO AVE RIVERSIDE CA 92507
28480	HEWLETT-PACKARD CO CORPORATE HQ 3000 HANOVER ST PALO ALTO CA 94304
31039	NATIONAL SCREW PRODUCTS CO INC 14401 W 11 MILE RD P O BOX 3815 OAK PARK MI 48237
34335	ADVANCED MICRO DEVICES 901 THOMPSON PL SUNNYVALE CA 94086
34649	INTEL CORP 3585 SW 198TH AVE ALOHA OR 97005
56289	SPRAGUE ELECTRIC CO 87 MARSHALL ST NORTH ADAMS MA 01247
71785	TRW INC TRW CINCH CONNECTORS DIV 1501 MORSE AVE ELK GROVE VILLAGE IL 60007


<u>MFR CODE</u>	<u>MANUFACTURER'S NAME AND ADDRESS</u>
73899	JFD ELECTRONICS COMPONENTS CORP 112 MOTT ST OCEANSIDE NY 11572
75037	MINNESOTA MINING AND MFG CO ELECTRO PRODUCTS DIV 3M CENTER ST PAUL MN 55101
80294	BOURNS INSTRUMENTS INC 6135 MAGNOLIA AVE RIVERSIDE CA 92506
81349	MILITARY SPECIFICATIONS
81350	JOINT ARMY NAVY
81483	INTERNATIONAL RECTIFIER 9220 SUNSET BLVD P O BOX 2321 TERMINAL ANNEX LOS ANGELES CA 90054
93790	CORNELL-DUBILIER ELECTRONICS DIV FEDERAL PACIFIC ELECTRIC CO 1605 RODNEY FRENCH BLVD NEW BEDFORD MA 02741
94696	MAGNECRAFT ELECTRIC CO 5575 N LYNCH AVE CHICAGO IL 60630
96906	MILITARY STANDARD

7.2.3 Equipment Covered

Listed below are the circuit cards/subassemblies with the latest effectivity covered by these instructions.

<u>CIRCUIT CARD/ SUBASSEMBLY</u>	<u>COLLINS PART NUMBER</u>	<u>LATEST EFFECTIVITY</u>
Rf card	646-5871-001	D
Control	646-5867-001	D

MP1



MP2



TPA-5614-018


Control
Figure 11 (Sheet 1 of 2)

PARTS LIST

REF DES	DESCRIPTION	COLLINS PART NUMBER	USABLE ON CODE	MFR CODE	MFR PART NUMBER
CR1,CR2	CONTROL A1A2 (ESDS)	646-5867-001			
CR3,CR4	SEMICONV DEVICE	353-2607-000		15238	1N645
CR5-CR40	SEMICONV DEVICE (ESDS)	353-3691-010		28480	1N5711
CR41	DIODE,LIGHT EMI	353-4442-020		14033	1N4002
CR42	SEMICONV DEVICE (ESDS)	353-0293-040		14936	MV5053
CR43	SEMICONV DEVICE (ESDS)	353-3691-010		28480	1N5711
CR44-	SEMICONV DEVICE (ESDS)	353-3718-040		14099	1N5550
CR46	SEMICONV DEVICE (ESDS)	353-3691-010		28480	1N5711
CR47	SEMICONV DEVICE (ESDS)	353-3718-040		14099	1N5550
CR48-	SEMICONV DEVICE (ESDS)	353-3691-010		28480	1N5711
CR51	NOT USED				
C1,C2	CAPACITOR,FXD MICA DIEL, 27PF, 2%, 500V	912-2773-000		81349	CM05ED270G03
C3,C4	CAPACITOR,FXD ELCTLT, 10UF, P100%M20%, 16VDC	183-1471-250		56289	50001066016BA5
C5	CAPACITOR,FXD CER DIEL, 0.1UF, 10%, 50VDC	913-5019-320		81349	CK05BX104K
C6	CAPACITOR,FXD AL ELCTLT, 68UF, P75%M10%, 25V	183-1510-030		56289	50006866025CB5
C7	CAPACITOR,FXD CER DIEL, 0.1UF, 10%, 50VDC	913-5019-320		81349	CK05BX104K
C8	CAPACITOR,FXD AL ELCTLT, 68UF, P75%M10%, 25V	183-1510-030		56289	50006866025CB5
C9	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C10	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C11,C12	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C13	NOT USED				
C14-C16	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C17	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C18	NOT USED				
C19,C20	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C21	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C22	NOT USED				
C23	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C24,C25	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C26	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C27	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C28	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C29,C30	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C31	CAPACITOR,FXD ELCTLT, 10UF, P100%M20%, 16VDC	183-1471-250		56289	50001066016BA5
C32-C35	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C36	CAPACITOR,FXD ELCTLT, 10UF, P100%M20%, 16VDC	183-1471-250		56289	50001066016BA5
C37-C90	CAPACITOR,FXD CER DIEL, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C91-C98	CAPACITOR,FXD CER DIEL, 1000PF, 10%, 200V	913-4018-000		81349	CK05BX102K
C99	CAPACITOR,FXD CER DIEL, 0.1UF, 10%, 50VDC	913-5019-320		12998	280-2745-040
MP1	LABEL,PRESS SENS (ESDS)	280-2745-040		12998	280-2745-040
MP2	CONTACT,ELECTRICAL (QTY 7)	372-2601-040		75037	3429-2303
P1	HEADER,PCB	372-0084-130		75037	3431-2303
P2	HEADER,PCB	372-0084-140		00779	87478-7
P3	HOUSING,CONN,EL	372-0043-480		71785	353-18-14-001
P4	TERMINAL STRIP	367-0022-000		00779	87478-2
P5	HOUSING,CONN,EL	372-0043-330		04713	MPS2222A
Q1-Q10	TRANSISTOR	352-5501-010		352-5501-010	
Q11-Q46	TRANSISTOR	352-5501-010		352-5501-010	
R1	RESISTOR,FXD CHPSN, 15K, 10%, 1/4W	745-0791-000		81349	RCR07G153KS
R2	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR07G103KS
R3	RESISTOR,FXD CHPSN, 0.1MEGO, 10%, 1/4W	745-0821-000		81349	RCR07G104KS
R4	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000		81349	RCR07G472KS
R5	RESISTOR,FXD CHPSN, 270 OHMS, 10%, 1/4W	745-0728-000		81349	RCR07G271KS
R6	RESISTOR,FXD CHPSN, 15 OHMS, 10%, 1/4W	745-0683-000		81349	RCR07G150KS
R7	RESISTOR,FXD CHPSN, 150 OHMS, 10%, 1/4W	745-0719-000		81349	RCR07G151KS
R8	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR07G103KS
R9	RESISTOR,FXD CHPSN, 22K, 10%, 1/4W	745-0797-000		81349	RCR07G223KS
R10	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000		81349	RCR07G472KS
R11	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R12	NOT USED				
R13	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R14	RESISTOR,FXD FILM, 51.1 OHMS, 1%, 1/8W	705-0934-000		81349	RN55D51R1F
R15	RESISTOR,FXD FILM, 18.7K, 1%, 1/8W	705-1057-000		81349	RN55D1872F
R16	RESISTOR,FXD CHPSN, 2.7MEGO, 10%, 1/4W	745-0872-000		81349	RCR07G275KS
R17	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR07G103KS
R18	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R19	RESISTOR,FXD FILM, 402 OHMS, 1%, 1/8W	705-0977-000		81349	RN55D4020F
R20	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR07G103KS
R21	RESISTOR,FXD FILM, 18.7K, 1%, 1/8W	705-1057-000		81349	RN55D1872F
R22	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000		81349	RCR07G472KS
R23	RESISTOR,FXD CHPSN, 2.7MEGO, 10%, 1/4W	745-0872-000		81349	RCR07G275KS
R24	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R25	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000		81349	RCR07G472KS
R26	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R27,R28	RESISTOR,FXD FILM, 10K, 1%, 1/8W	705-1044-000		81349	RN55D1002F
R29	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R30	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000		81349	RCR07G472KS
R31	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R32	RESISTOR,FXD CHPSN, 2.7MEGO, 10%, 1/4W	745-0872-000		81349	RCR07G275KS
R33	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R34	RESISTOR,FXD FILM, 17.8K, 1%, 1/8W	705-1056-000		81349	RN55D1782F
R35	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R36	RESISTOR,FXD CHPSN, 1MEGO, 10%, 1/4W	745-0857-000		81349	RCR07G105KS
R37	RESISTOR,FXD FILM, 115K, 1%, 1/8W	705-1095-000		81349	RN55D1153F
R38	RESISTOR,FXD FILM, 2.74K, 1%, 1/8W	705-1017-000		81349	RN55D2741F
R39	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R40	RESISTOR,FXD FILM, 301K, 1%, 1/8W	705-1115-000		81349	RN55D3013F
R41	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000		81349	RN55D1001F
R42	RESISTOR,FXD FILM, 51.1 OHMS, 1%, 1/8W	705-0934-000		81349	RN55D51R1F
R43	RESISTOR,FXD FILM, 6.98K, 1%, 1/8W	705-3605-400		81349	RN55D6981F
R44	RESISTOR,FXD CHPSN, 1MEGO, 10%, 1/4W	745-0857-000		81349	RCR07G105KS

PARTS LIST (Cont)

REF DES	DESCRIPTION	COLLINS PART NUMBER	USABLE ON CODE	MFR CODE	MFR PART NUMBER
R45,R46	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000			81349 RCR07G472KS
R47	RESISTOR,FXD CHPSN, 1MEGO, 10%, 1/4W	745-0857-000			81349 RCR07G105KS
R48	RESISTOR,FXD FILM, 14.7K, 1%, 1/8W	705-1052-000			81349 RN55D1472F
R49	RESISTOR,FXD FILM, 3.92K, 1%, 1/8W	705-3605-280			81349 RN55D3921F
R50	RESISTOR,FXD FILM, 301K, 1%, 1/8W	705-1115-000			81349 RN55D3013F
R51	RESISTOR,FXD FILM, 51.1 OHMS, 1%, 1/8W	705-0934-000			81349 RN55D51R1F
R52	RESISTOR,FXD FILM, 6.98K, 1%, 1/8W	705-3605-400			81349 RN55D6981F
R53	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000			81349 RN55D1001F
R54	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000			81349 RN55D1001F
R55	RESISTOR,FXD FILM, 14.7K, 1%, 1/8W	705-1052-000			81349 RN55D1472F
R56	RESISTOR,FXD CHPSN, 1MEGO, 10%, 1/4W	745-0857-000			81349 RCR07G105KS
R57	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000			81349 RN55D1001F
R58	RESISTOR,FXD CHPSN, 680 OHMS, 10%, 1/4W	745-0743-000			81349 RCR07G681KS
R59	RESISTOR,FXD FILM, 1K, 1%, 1/8W	705-0996-000			81349 RN55D1001F
R60	RESISTOR,FXD CHPSN, 4.7K, 10%, 1/4W	745-0773-000			81349 RCR07G472KS
R61,R62	RESISTOR,VARIABLE NON-WW,20K, 10%	382-0052-470			80294 3292W-CE8-RC203
R63-R66	RESISTOR,FXD CHPSN, 22K, 10%, 1/4W	745-0797-000			81349 RCR07G223KS
R67	RESISTOR,FXD FILM, 1.78K, 1%, 1/8W	705-1008-000			81349 RN55D1781F
R68	NOT USED				
R69	RESISTOR,FXD FILM, 51.1 OHMS, 1%, 1/8W	705-0934-000			81349 RN55D51R1F
R70	RESISTOR,FXD CHPSN, 1K, 10%, 1/4W	745-0749-000			81349 RCR07G102KS
R71	RESISTOR,FXD CHPSN, 270 OHMS, 10%, 1/4W	745-0728-000			81349 RCR07G271KS
R72	RESISTOR,FXD CHPSN, 1K, 10%, 1/4W	745-0749-000			81349 RCR07G102KS
R73	RESISTOR,FXD CHPSN, 270 OHMS, 10%, 1/4W	745-0728-000			81349 RCR07G271KS
U1	INTEGRATED CIRCUIT MEMORY (ESDS)	351-8872-010			34649 D2732
U2	MICROPROCESSOR (ESDS)	351-8676-020			04713 HC6802CP
U3,U4	INTEGRATED CIRCUIT BUFFER/LINE DRIVER	351-1841-020			01295 SN54LS244J
U5	INTEGRATED CIRCUIT TRANSCIEVER,OCTAL BUS(ESDS)	351-1849-010			01295 SN54LS245J
U6	INTEGRATED CIRCUIT MEMORY (ESDS)	351-8872-010			34649 D2732
U7-U9	INTEGRATED CIRCUIT MEMORY (ESDS)	351-8439-050			34649 HD8255A
U10-U12	INTEGRATED CIRCUIT BUFFER (ESDS)	351-8197-010			02735 CD4049UBF
U13	INTEGRATED CIRCUIT BUFFER/LINE DRIVER	351-1841-020			01295 SN54LS244J
U14	INTEGRATED CIRCUIT LOGIC GATE	351-1523-050			04713 SN54LS10J
U15	INTEGRATED CIRCUIT COMPARATOR	351-1122-030			01295 LM139J
U16,U17	INTEGRATED CIRCUIT LOGIC GATE	351-1923-050			04713 SN54LS10J
U18	INTEGRATED CIRCUIT LOGIC GATE	351-1523-100			04713 SN54LS27J
U19	MICROCIRCUIT DECODER	351-1526-010			04713 SN54LS138J
U20	INTEGRATED CIRCUIT LOGIC GATE	351-1523-020			04713 SN54LS02J
U21,U22	INTEGRATED CIRCUIT MEMORY (ESDS)	351-8413-080			34335 AM91L14E0M
U23,U24	INTEGRATED CIRCUIT AMPLIFIER,QUAD OPRTNL	351-1141-020			34335 LM2240
U25-U30	RESISTOR NETWORK DUAL-IN-LINE, 22K, 2%, 125V	350-4027-510			01121 314B223
U31-U34	RESISTOR NETWORK DUAL-IN-LINE, 220K, 2%, 125V	350-4027-990			01121 314A224
U35,U36	RESISTOR NETWORK DUAL-IN-LINE, 4.7K, 2%, 125V	350-4027-070			01121 314B472
U37	RESISTOR NETWORK DUAL-IN-LINE, 150 OHMS, 2%, 125V	350-4027-010			01121 314B151
U38	RESISTOR NETWORK DUAL-IN-LINE, 10K, 2%, 125V	350-4027-120			01121 314A103
U39	MICROCIRCUIT (ESDS)	351-8208-010			07263 40508DM
U40	INTEGRATED CIRCUIT MOS (ESDS)	351-8160-030			31039 SCL4013BC
U41	INTEGRATED CIRCUIT MOS (ESDS)	351-8160-080			31039 SCL4011BC
U42	INTEGRATED CIRCUIT COMPARATOR	351-1122-030			01295 LM139J
U43	INTEGRATED CIRCUIT MOS (ESDS)	351-8160-080			31039 SCL4011BC
U44	INTEGRATED CIRCUIT MOS (ESDS)	351-8160-030			31039 SCL4013BC
U45,U46	RESISTOR NETWORK DUAL-IN-LINE, 220K, 2%, 125V	350-4027-990			01121 314A224
VR1	SEMICONV DEVICE	353-2704-000			81483 1N748A
Y1	CRYSTAL UNIT,QTZ 4.000000MHZ	289-7082-020			81349 CR6404-00000MHZ




TPA-5603-018

RF Card
Figure 12 (Sheet 1 of 2)

PARTS LIST

REF DES	DESCRIPTION	COLLINS PART NUMBER	USABLE ON CODE	MFR CODE	MFR PART NUMBER
CR1	RF CARD A1A1	646-5871-001			
CR2,CR3	SEMICONV DEVICE	353-3338-000		81350	JANIN914
CR4-CR6	DIODE 1N914 (MATCHED PAIR)	637-1960-001			637-1960-001
CR7,CR8	SEMICONV DEVICE	353-3338-000		81350	JANIN914
CR9	DIODE 1N914 (MATCHED PAIR)	637-1960-001			637-1960-001
CR10	SEMICONV DEVICE	353-3404-000		03508	1N3064
CR11	NOT USED				
C1	SEMICONV DEVICE	353-3404-000		03508	1N3064
C2	CAPACITOR,VAR GL DIEI, 1 TO 8.5PF, 750V	922-3031-020		73899	VCJ1849
C3	CAPACITOR,FXD MICA DIEI, 82PF, 5%, 50V	912-4141-350		93790	CD5EY820J0
C4	CAPACITOR,VAR GL DIEI, 1 TO 8.5PF, 750V	922-3031-020		73899	VCJ1849
C5	CAPACITOR,FXD MICA DIEI, 390PF, 5%, 500V	912-2858-000		81349	CH05FD391J03
C6	CAPACITOR,VAR GL DIEI, 1 TO 8.5PF, 750V	922-3031-020		73899	VCJ1849
C7,C8	CAPACITOR,FXD MICA DIEI, 390PF, 5%, 50V	912-4141-510		93790	CD5FY391J0
C9	CAPACITOR,FXD MICA DIEI, 18PF, PORM 0.5PF, 100V	912-4141-140		93790	CD5CA18000
C10	CAPACITOR,FXD MICA DIEI, 10PF, PORM 0.5PF, 500V	912-2753-000		81349	CH05CD100D03
C11-C66	CAPACITOR,FXD MICA DIEI, 300PF, 5%, 50V	912-4141-480		93790	CD5FY301J0
C67-C70	CAPACITOR,FXD CER DIEI, 0.01UF, 10%, 100VDC	913-5019-200		81349	CK05BX103K
C71	CAPACITOR,FXD MICA DIEI, 1200PF, 5%, 500V	912-3007-000		81349	CH06FD122J03
C72	CAPACITOR,FXD MICA DIEI, 680PF, 5%, 500V	912-2989-000		81349	CH06FD681J03
C73	CAPACITOR,FXD MICA DIEI, 620PF, 5%, 500V	912-2986-000		81349	CH06FD621J03
C74,C75	CAPACITOR,FXD MICA DIEI, 750PF, 5%, 500V	912-2992-000		81349	CH06FD751J03
C76	CAPACITOR,FXD MICA DIEI, 240PF, 5%, 500V	912-2843-000		81349	CH05FD241J03
C77	CAPACITOR,FXD MICA DIEI, 150PF, 5%, 500V	912-2828-000		81349	CH05FD151J03
C78	CAPACITOR,FXD MICA DIEI, 75PF, 5%, 500V	912-2807-000		81349	CH05ED750J03
C79	CAPACITOR,FXD MICA DIEI, 43PF, 5%, 500V	912-2789-000		81349	CH05ED430J03
C80,C81	CAPACITOR,FXD MICA DIEI, 430PF, 5%, 500V	912-2861-000		00853	D155F431J0
C82	NOT USED				
C83	CAPACITOR,FXD CER DIEI, 0.1UF, 10%, 100VDC	913-5019-440		81349	CK06BX104K
C84	NOT USED				
C85,C86	CAPACITOR,FXD MICA DIEI, 300PF, 5%, 500V	912-2849-000		81349	CH05FD301J03
C87,C88	CAPACITOR,FXD MICA DIEI, 680PF, 5%, 500V	912-2989-000		81349	CH06FD681J03
C89	CAPACITOR,FXD MICA DIEI, 750PF, 5%, 500V	912-2992-000		81349	CH06FD751J03
C90	CAPACITOR,FXD MICA DIEI, 430PF, 5%, 500V	912-2861-000		00853	D155F431J0
C91	CAPACITOR,FXD MICA DIEI, 120PF, 5%, 500V	912-2822-000		81349	CH05FD121J03
C92	CAPACITOR,FXD MICA DIEI, 75PF, 5%, 500V	912-2807-000		81349	CH05ED750J03
C93	CAPACITOR,FXD MICA DIEI, 43PF, 5%, 500V	912-2789-000		81349	CH05ED430J03
C94,C95	CAPACITOR,FXD MICA DIEI, 24PF, 5%, 500V	912-2771-000		81349	CH05ED240J03
C96	CAPACITOR,FXD MICA DIEI, 12PF, 5%, 500V	912-2756-000		81349	CH05CD120J03
C97	CAPACITOR,FXD MICA DIEI, 15PF, 5%, 500V	912-2759-000		81349	CH05CD150J03
C98,C99	NOT USED				
C100	CAPACITOR,FXD MICA DIEI, 5PF, PORM 0.5PF, 500V	912-2750-000		81349	CH05CD050D03
C101	CAPACITOR,FXD MICA DIEI, 10PF, PORM 0.5PF, 500V	912-2753-000		81349	CH05CD100D03
H1	PLATE,INSULATOR	651-4303-001			
H2	WASHER,TEFLON (QTY 8)	544-8802-003		544-8802-003	
K1-K18	RELAY	970-2601-010		94696	76URCPGX-4
K19	NOT USED				
K20,K21	RELAY	970-2601-010		94696	76URCPGX-4
L1	COIL,RF 0.82UH	240-2022-000		96906	MS75083-12
L2	COIL,RF 2.2UH	240-2715-170		96906	MS75088-5
L3	COIL,RF 1UH	240-2023-000		96906	MS75083-13
L4	COIL,RF 2.20UH	240-2027-000		96906	MS75084-04
L5-L9	COIL,RF 1000UH	240-2540-000		96906	MS90539-15
L10,L11	COIL,RF 4.70UH	240-2715-210		96906	MS75088-9
L12-L15	COIL,RF 1.50UH	240-2025-000		96906	MS75084-02
L16-L54	COIL,RF 4.70UH	240-2715-210		96906	MS75088-9
L55,L56	COIL,RF 390UH	240-2715-440		96906	MS75089-18
MP1		424-0148-010			
P1	HEADER,PCB	372-0084-130		75037	3429-2303
P2	COIL,RF 1000UH	240-2540-000		96906	MS90539-15
P3	HOUSING,CONN,EL	372-0043-330		00779	87478-2
P4	HEADER,PCB	372-0084-120		75037	3428-2303
P5	CONNECTOR,RCPT ELEC	357-9670-000		81349	H39012-21-0001
R1	RESISTOR,FXD FILM, 34.8 OHMS, 1%, 8W	714-3187-000		19647	MS231-34-8-1PCT
R2	RESISTOR,FXD FILM, 1.33K, 1%, 1/4W	705-6602-000		81349	RN60D1331F
R3	RESISTOR,FXD FILM, 19.6 OHMS, 1%, 8W	714-3186-000		19647	MS231-19-6-1PCT
R4,R5	RESISTOR,FXD FILM, 12.1K, 1%, 1/4W	705-6648-000		81349	RN60D1212F
R6	RESISTOR,FXD FILM, 19.6 OHMS, 1%, 8W	714-3186-000		19647	MS231-19-6-1PCT
R7	RESISTOR,FXD FILM, 19.6 OHMS, 1%, 1/4W	705-6514-000		81349	RN60D19R6F
R8,R9	RESISTOR,FXD FILM, 12.1K, 1%, 1/4W	705-6648-000		81349	RN60D1212F
R10,R11	RESISTOR,FXD FILM, 3.83K, 1%, 1/4W	705-6624-000		81349	RN60D3831F
R12,R13	RESISTOR,FXD FILM, 4.64K, 1%, 1/4W	705-6628-000		81349	RN60D4641F
R14,R15	RESISTOR,VARIABLE NON-WW,20K, 10%	382-0052-470		80294	3292H-CE8-RC203
R16	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR076103KS
R17	NOT USED				
R18	RESISTOR,FXD CHPSN, 10K, 10%, 1/4W	745-0785-000		81349	RCR076103KS
R19	NOT USED				
R20	RESISTOR,FXD CHPSN, 100 OHMS, 10%, 1W	745-3310-000		81349	RCR326101KS
T1	TRANSFORMER	756-8257-004			756-8257-004
T2,T3	TRANSFORMER	756-8258-004			756-8258-004
T4	TRANSFORMER	756-8308-004			756-8308-004



		②	P3
E	25		25
RD/WR	26		26
YMA	27		27
RESET	28		28
RECHANNEL/STROBE	29		29
E2	30		30
GND DSBL ROM 1 (E8)	31		31
GND DSBL ROM 2	32		32
E7	33		33
E6	34		34
AUTO RESET (E3)	35		35

NOTES:

① CONTROL CABLE TO/FROM TRANSCEIVER CONNECTS TO A1A2P4.


② CONNECTOR A1A2P3 IS USED FOR FACTORY TESTING ONLY.

CU-380 Interconnect Diagram
Figure 13

TPA-5533-014


NOTES:

1. UNLESS OTHERWISE SPECIFIED, RESISTANCE VALUES ARE IN OHMS, CAPACITANCE VALUES ARE IN MICROFARADS AND INDUCTANCE VALUES ARE IN MICROHENRYS.
2. PARTIAL REFERENCE DESIGNATIONS ARE SHOWN; FOR COMPLETE DESIGNATIONS, PREFIX WITH UNIT NUMBER AND/OR ASSEMBLY DESIGNATION.
3. TYPE DESIGNATIONS SHOWN MAY BE GENERIC IN FORM AND ARE FOR REFERENCE ONLY. SEE APPLICABLE PARTS LIST FOR REPLACEMENT PARTS.
4. COMPONENTS SHOWN IN DASHED LINES ARE OPTIONAL AND MAY NOT APPEAR ON ALL EQUIPMENT.



651-5067
TPA-5171-025

RF Plate A1 and RF Card A1A1
Schematic Diagram
Figure 14 (Sheet 1 of 2)






NOTE 4


NOTE 4

+ 12 V
DC

P/O P


P/O RF PLATE







651-5067
TPA-5171-025


RF Plate A1 and RF Card A1A1
Schematic Diagram
Figure 14 (Sheet 2)





Control A1A2 Schematic Diagram
Figure 15 (Sheet 1 of 3)
















Control A1A2 Schematic Diagram
Figure 15 (Sheet 2)


TPA-5170-035

- (2) (\$4031) B0-B7
- (2) (\$4030) B0-B7
- (2) (\$402E) B0-B7
- (2) (\$402D) B0-B7
- (2) (\$4032) B0-B7






- NOTES:
- UNLESS OTHERWISE SPECIFIED, RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN MICROFARADS.
 - TYPE DESIGNATIONS SHOWN MAY BE GENERIC IN FORM AND ARE FOR REFERENCE ONLY. SEE APPLICABLE PARTS LIST FOR REPLACEMENT PARTS.
 - PARTIAL REFERENCE DESIGNATIONS ARE SHOWN; FOR COMPLETE DESIGNATIONS, PREFIX WITH UNIT NUMBER AND/OR ASSEMBLY DESIGNATION.
 - THIS EQUIPMENT CONTAINS ELECTROSTATIC DISCHARGE SENSITIVE (ESDS) DEVICES. SPECIAL HANDLING METHODS AND MATERIALS MUST BE USED TO PREVENT EQUIPMENT DAMAGE.
 - U25 - U38 AND U45 - U46 ARE RESISTOR ARRAYS WITH CONFIGURATIONS SHOWN BELOW WITH R VALUES:



6. CONNECTOR P3 IS USED FOR FACTORY TEST ONLY.

MICROCIRCUIT INFORMATION

U NO	TYPE	POWER (V DC)		
		+5	+12	GND
U1	2732	24		12
U2	6802	8		21.1
U3	54LS244	20		10
U4	54LS244	20		10
U5	54LS245	20		10
U6	2732	24		12
U7	8255	26		7
U8	8255	26		7
U9	8255	26		7
U10	4049	1		8
U11	4049	1		8
U12	4049	1		8
U13	54LS244	20		10
U14	54LS10	14		7
U15	LM139		3	12
U16	54LS10	14		7
U17	54LS10	14		7
U18	54LS27	14		7
U19	54LS138	16		8
U20	54LS02	14		7
U21	2114	18		9
U22	2114	18		9
U23	LM124	4		11
U24	LM124	4		11
U25	RES ARRAY			
U26	RES ARRAY			
U27	RES ARRAY			
U28	RES ARRAY			
U29	RES ARRAY			
U30	RES ARRAY			
U31	RES ARRAY			
U32	RES ARRAY			
U33	RES ARRAY			
U34	RES ARRAY			
U35	RES ARRAY			
U36	RES ARRAY			
U37	RES ARRAY			
U38	RES ARRAY			
U39	4050	1		8
U40	4013	14		7
U41	4011	14		7
U42	LM139	3		12
U43	4011	14		7
U44	4013	14		7
U45	RES ARRAY			
U46	RES ARRAY			



TPA-5170-035

Control A1A2 Schematic Diagram
 Figure 15 (Sheet 3)