

**INSTRUCTION MANUAL**  
for  
**THE**  
**NATIONAL MODEL**  
**HRO-50-1**  
**RADIO RECEIVING**  
**EQUIPMENT**

An Outstanding Communications Receiver  
of proven integrity and performance in  
Commercial and Amateur stations.

**National**



PRICE 30 CENTS

**National**  
EST. 1914



## HRO-50-1 Receiver

### FEATURES . . .

- Tuning Range 50-430 Kcs. and 480-35,000 Kcs.
- Direct Frequency Reading Slide-Rule Dial
- Twelve Tuning Bands Accurately Calibrated
- Calibrated Bandspread for 10-11, 15, 20, 40 and 80 meter Amateur Bands
- High Sensitivity — Exceptional Stability
- Excellent Signal to Noise Ratio
- Flexible Crystal Filter with Six Positions of Selectivity
- Automatic, Adjustable Threshold, Double Action Noise Limiter
- High-Fidelity, Push-Pull Audio Amplifier
- Provisions for mounting N.B.F.M. Adaptor and Crystal Calibrator Units within Receiver
- Temperature Compensation
- Plug-In Coils for Efficiency and Flexibility
- Built-In Power Supply

*National Company, Inc.*

## THE HRO-50-1 RADIO RECEIVER

### SECTION I. DESCRIPTION

#### 1-1. GENERAL

The HRO-50-1 is a deluxe radio receiver featuring performance and versatility. Sixteen tubes, including a rectifier and a voltage regulator tube, are utilized in a superheterodyne circuit for the reception of code and phone signals throughout its frequency range of 50 to 430 kilocycles and 480 to 35,000 kilocycles. The HRO type receivers have long been outstanding and proven performers in Communication and Amateur services. This new series of HRO-50-1 receivers feature many desirable innovations emanating from the latest advances in receiver circuitry and mechanical design. It is housed in a new and enlarged cabinet styled in an attractive gray finish with a self-contained power supply adequately isolated from the R.F. circuits. A calibrated, illuminated slide-rule dial provides direct reading in megacycles for each of the General Coverage coil sets as well as an additional bandspread scale for those coil sets incorporating this feature. A front-panel mounted oscillator trimmer control is provided to assure precise calibration. Of course, the dial-driving mechanism still features the micrometer dial. Temperature compensation and voltage regulation of the high-frequency oscillator as well as utilization of ceramic insulation in the coil sets and associated connecting brush blocks provide stable operation and freedom from drift. A single front-panel mounted Control switch selects any one of the four modes of operation, C.W., Phone, Narrow-Band F.M. or Phono. Sockets are mounted on the receiver chassis to accommodate the National Type NFM-83-50 FM adaptor and the National Type XCU-50-2 Crystal Calibrator Unit. These accessories may be permanently installed and switched On and Off by means of the front-panel switches. At the rear of the receiver sockets are available for external use of the National Type SOJ-3 Select-0-Ject and National Type 650S Vibrator Power Supply or battery power supply. The S-Meter circuit is designed so that the operator may adjust the sensitivity of the S-Meter. A push-pull audio system delivers the utmost in audio frequency response and undistorted power output from the built-in output transformer. Other highlights include a six-position crystal filter, maximum bandspreading of the amateur bands, a quick-acting bandspread switch and a dimmer control for the slide-rule dial and S-Meter lamps.

A standard equipment consists of a receiver, loudspeaker and coil sets A, B, C and D. Coil sets Type E, F, G, H, J, AA, AB and AC may be obtained as desired. Accessories available include the National types NFM-83-50 Narrow-Band F.M. adaptor, XCU-50-2 Crystal Calibrator, SOJ-3 Select-0-Ject and 650S Vibrator Power Supply.

#### 1-2. CIRCUIT

For all frequency ranges the circuit utilizes two tuned stages of radio frequency amplification, a tuned mixer stage, a high-frequency oscillator employing a tube separate from the mixer tube, a first intermediate frequency amplifier stage employing a variable-selectivity crystal filter and two additional I.F. amplifier stages all operating at 455 kilocycles, a combined second detector-automatic volume control stage, an S-Meter amplifier, a double-action adjustable threshold double-diode noise limiter, a first audio amplifier, a phase inverter, a push-pull audio amplifier and a beat frequency oscillator coupled to the second detector to provide for C.W. reception.

All voltages required by the receiver are supplied by a built-in power supply. A voltage regulator tube is used to regulate the plate supply to the high-frequency oscillator and the S-Meter amplifier stages.

#### 1-3. ANTENNA INPUT

Antenna input terminals are provided at the rear of the receiver. The input circuit is suitable for operation with a single-wire antenna, a balanced feed line or a low impedance 72-ohm unbalanced concentric transmission cable. The actual antenna input impedance is between 300 and 600 ohms depending on the frequency of the input signal.

#### 1-4. TUBE COMPLEMENT

The HR0-50-1 receiver is supplied complete with tubes which are tested in the receiver at the time of alignment.

The tubes employed are as follows:

First R.F. Amplifier	6BA6
Second R.F. Amplifier	6BA6
Mixer	6BE6
High-Frequency Oscillator	6C4
First I.F. Amplifier	6K7
Second I.F. Amplifier	6SG7
Third I.F. Amplifier	6SG7
Second Detector - A.V.C.	6H6
Noise Limiter	6H6
S-Meter Amplifier - Phase Inverter	6SN7GT
First A.F. Amplifier	6SJ7
Audio Output (2)	6V6GT
Beat Frequency Oscillator	6J7
Voltage Regulator	0B2
Rectifier	5V4G

#### 1-5. TUNING SYSTEM

The frequency coverage of the HR0-50-1 is covered in twelve bands as follows:

<u>COIL SET</u>	<u>GENERAL COVERAGE</u>	<u>BANDSPREAD</u>
A	14.0 - 30.0 Mc.	27.0 - 30.0 Mc.
B	7.0 - 14.4 Mc.	14.0 - 14.4 Mc.
C	3.5 - 7.3 Mc.	7.0 - 7.3 Mc.
D	1.7 - 4.0 Mc.	3.5 - 4.0 Mc.
E	900 - 2050 Kc.	
F	480 - 960 Kc.	
G	180 - 430 Kc.	
H	100 - 200 Kc.	
J	50 - 100 Kc.	
AA		27.5 - 30 Mc.
AB	25 - 35 Mc.	
AC		21.0 - 21.5 Mc.

As shown above plug-in coil set types AA, AC, A, B, C and D provide bandspread coverage of the 10-11, 15, 20, 40 and 80 meter amateur bands. The AA, AC, B, C, and D bands are spread out so as to cover 400 dial divisions while the A band is spread 430 divisions on the 500-division main tuning dial. This is accomplished by switching a small variable capacitor in series with each section of the main tuning capacitor, thus reducing its effective capacity range. All of the coil sets are factory aligned in the receiver using accurate crystal-controlled test oscillators thus assuring precise alignment.

The micrometer type dial drives the main tuning capacitor through a worm drive having a reduction ratio of approximately 20 to 1. Backlash is eliminated by the use of a spring-loaded split worm wheel which assures positive drive in either direction at all times. This dial has an effective scale length of approximately twelve feet and is calibrated from zero to 500.

A slide-rule type dial is synchronized with the micrometer dial by means of an anti-backlash gear and an efficient string drive arrangement to the main tuning dial. A dial drum provides a

means of mounting eight scales. Each of these scales is calibrated in megacycles for the general coverage and/or bandspread frequencies depending on the coil set. Mounted on the front panel is a band selector switch for ease in rotating the dial drum to select the proper band scale to correspond to the coil set in use. Each scale is clearly marked with the band designation. Two pilot lamps are used, one at each end of the dial scale drum, for illumination. The degree of illumination is controlled by the front-panel mounted Dimmer control.

#### 1-6. CRYSTAL FILTER

The selectivity characteristics of the HR0-50-1 are made adjustable by means of a crystal filter. Located in the first intermediate frequency amplifier this crystal filter is designed for extreme flexibility and efficiency of operation. A six-position Selectivity switch and a crystal Phasing control are front-panel mounted for adjustment of the filter. Figure Number 1 shows the selectivity characteristics of the receiver for each of the six degrees of selectivity.

The crystal filter may be used for either C.W. or phone reception; any degree of selectivity from true single-signal to wide band A.M. broadcast reception being available. Operation of the Phasing control provides for efficient suppression of interfering C.W. signals or M.C.W. signals which may produce objectionable heterodynes.




Figure No. 1. Crystal Filter Selectivity Curves

#### 1-7. NOISE LIMITER

The noise limiter in the HR0-50-1 receiver uses an automatic type double-action circuit resulting in the limiting of noise pulses on both the positive and negative peaks. It is equally effective on both C.W. and phone reception. The usefulness of this limiter will be most appreciated on the higher frequency bands of the receiver where automobile ignition noise and other high frequency disturbances are effectively suppressed. A threshold control on the front panel permits adjustment of the level at which limiting action starts.



#### 1-8. TONE CONTROL

The Tone control circuit has been especially designed to provide a versatile variance of the frequency characteristics of the audio amplifier output. In the extreme counter-clockwise position the greatest degree of high audio frequency response is obtained. Rotating the control clockwise until the switch mounted on the control just closes provides a comparatively flat response over the entire usable audio frequency range. Further clockwise rotation will result in the high audio frequencies being attenuated as illustrated in Figure Number 2. This control is particularly helpful when receiving weak signals through interference. If a signal is weak and partially obscured by background noise or static, an improvement in signal-to-noise ratio will be obtained by rotating the Tone control in a clockwise direction thereby attenuating the higher audio frequencies.




Figure No. 2. Audio Amplifier Response

#### 1-9. TEMPERATURE COMPENSATION

The HRO-50-1 is compensated for frequency drift due to temperature changes which may detune the receiver from the desired signal over long or short periods of reception. The most objectionable cause of frequency drift is the change of inductance of the high-frequency oscillator coil as heat from the tubes causes the interior of the receiver to increase in temperature. This undesirable heating effect in the R.F. coils is minimized by the position of the plug-in coil sets in that they are placed at the bottom of the receiver underneath the chassis in a separately shielded compartment. A further safeguard against frequency drift is provided for on bandsread operation. The heat which is dissipated in the high-frequency oscillator may change the inter-electrode capacity of the tube and thus cause frequency drift. To offset this effect a small negative temperature coefficient capacitor is placed adjacent to the high-frequency oscillator tube to compensate for any change caused by the internal heating of the tube.

The coil set terminal connecting boards of each shielded coil can as well as their mating brush blocks have been made of ceramic type material. As a result freedom from any possible leakage due to poor insulation assures a low degree of drift. This will be found especially true of the coils operating at the higher frequencies.

#### 1-10. SIGNAL STRENGTH METER

Signal input readings are indicated in S-units from 1 to 9 and in decibels above S-9 from zero to 40 db. on the panel-mounted signal strength meter. A reading of S-9 is obtained with an input signal of approximately 25 microvolts. The meter employs a zero to 1 milliampere movement with its mechanical zero at 40 db. on the dial scale. The S-Meter is connected in series with the plate input of the S-Meter Amplifier tube V-8A and measures the plate current of this tube. With the A.C. supply switch On and the A.V.C. switch set at A.V.C. the S-Meter will read zero in the absence of signal input. A variable resistor is shunted across the meter and with no antenna connected this resistor allows correct adjustment of the pointer to its electrical zero. Any increase in A.V.C. voltage caused by signal input will give a corresponding increase in the meter reading. At the 40 db. meter reading the A.V.C. grid voltage applied reaches the cut-off point of the amplifier tube. Therefore the pointer cannot be harmed by violent contact with the full-scale meter pin. For the purpose of comparing strong signals (which cause the meter to contact the full-scale meter pin) with other stronger and/or weaker signals the sensitivity of the S-Meter may be lowered by retarding the R.F. Gain control. The meter dial lamp illumination is regulated by a Dimmer control mounted on the front panel of the receiver.

#### 1-11. NARROW-BAND F.M. SOCKET

A standard octal socket, X-1, is mounted inside the receiver on the center portion of the power supply compartment chassis. It is designed to mount the National Type NFM-83-50 Narrow-Band F.M. adaptor. A control switch is front-panel mounted to provide a means of switching the adaptor into the output of the intermediate amplifier circuit. With the control switch set at the N.F.M. position the receiver is adjusted for the reception of narrow-band F.M. signals. With the A.V.C. switch set at A.V.C. the S-Meter is operative in the N.F.M. position and the receiver should be tuned for maximum meter reading to assure efficient operation. Further information concerning the NFM-50 unit is contained in a separate data sheet at the rear of this manual.

#### 1-12. CRYSTAL CALIBRATOR SOCKET

The Crystal Calibrator socket, X-2, is of the standard octal type mounted on top of the power supply compartment chassis inside the receiver. It is designed to accommodate a National Model XCU-50-2 Crystal Calibrator. The Model XCU-50-2 is compactly constructed and furnished with a drive screw clamping arrangement to hold it firmly in place. A double-pole, three-position toggle type front-panel mounted Calibrate switch marked 100-Off-1000 provides a means of connecting B-plus to the unit for instantaneous use. At the same time by using this toggle switch a resonant crystal-controlled frequency of either 100 or 1000 kcs. may be selected. The output of this unit is loosely coupled to the first R.F. amplifier stage through the socket wiring. Further information concerning the Model XCU-50-2 unit is covered by a separate data sheet included at the rear of this manual.

#### 1-13. SELECT-O-JECT SOCKET

The Select-O-Ject socket, X-3, is a standard octal type socket accessible at the rear of the receiver. It is primarily designed to accommodate a National Model SOJ-3 Select-O-Ject unit. The mating plug attached to the SOJ-3 permits a direct connection into this socket in place of the audio jumper plug originally plugged into the Select-O-Ject socket. By proper adjustment of the controls any single audio frequency selected in the range of approximately 80 to 10,000 cycles may be boosted or rejected. Detailed instructions for proper operation of the Select-O-Ject are contained with the unit.

For convenience a source of 6.3 V.A.C. filament voltage, a 240 V.D.C. high voltage as well as the 105 V.D.C. regulated voltage is available for operation of external apparatus. The Schematic diagram, Figure Number 13, shows a pin view of the Select-O-Ject socket thus providing the information necessary for making the proper connections. External equipment MUST NOT be utilized if the Narrow-Band F.M. adaptor, Crystal Calibrator and Select-O-Ject units are all operated at the same time. Consideration must also be given to the fact that the 105-volt regulated power supply cannot

be switched off by the B+ On-Off switch.

#### 1-14. PHONO INPUT JACK

A Phono jack is mounted at the rear of the Receiver and can be used for connecting auxiliary apparatus, such as a record player pick-up or microphone into the audio system of the receiver. This input circuit is of high-impedance providing a suitable match for such external equipment into the high-gain first audio amplifier stage. The front-panel mounted Control switch must be set at the Phono position when using the Phono jack. Both the A.F. Gain and Tone controls are operative with this type of operation.

The majority of record player pick-ups are terminated in a single shielded wire. The Phono jack on the HR0-50-1 is the type that accommodates a standard phono tip plug and if the record player to be used is not fitted with such a plug one can easily be attached. If the output circuit of the record player is of low impedance (less than 100,000 ohms) improved efficiency will be obtained if a suitable resistor, with a value as specified for the particular record player, is connected across the phono tip plug or its mating jack to properly load the record player output circuit.

#### 1-15. AUDIO OUTPUT

The HR0-50-1 features a push pull output amplifier using inverse feed-back. See Figure No. 2 for the audio system response characteristic. The matching transformer located inside the receiver provides two audio output circuits as follows:

(1) The transformer secondary leads are brought to a three-terminal Output board located at the rear of the receiver, having both 8 and 500-ohm terminals and a common ground terminal. The eight-ohm terminal provides output for the speaker voice coil. The 500-ohm terminal is available for connection to a 500-ohm line. Approximately 8 watts of undistorted audio output power is available at the output terminal board and a maximum power of 10 watts is obtainable.

(2) A headphones jack is front-panel mounted and is wired so as to silence the Loudspeaker upon insertion of the headphones plug. The headphones output load impedance is not critical and varying types of headphones may be used including crystal types, as no direct current flows through the headphones.

#### 1-16. POWER SUPPLY

The power supply is built in a separate compartment inside the receiver cabinet incorporating a heat-resistant shielded barrier isolating it from the R.F. chassis portion. It is designed for operation from a 110/120 or 220/240-volt, 50/60 cycle A.C. supply source. A toggle switch is mounted on top of the chassis for selection of either 110/120 or 220/240-volt operation. Normal power consumption is approximately 115 watts. The built-in power unit supplies all of the voltages required by the heater and B supply circuits, 5.1 amperes at 6.3 volts and 145 milliamperes at 240 volts respectively. In addition this supply is also capable of furnishing all voltages required by the accessories such as the NFM-83-50, XCU-50-2 and SOJ-3. A 2-ampere fuse is connected in one side of the A.C. input supply to protect the receiver circuits against possible voltage surges in the power line or short circuits in the receiver. It is located at the rear of the receiver and is easily removed for examination or replacement.

A Power Socket, X-4, is provided at the rear of the receiver so that either a battery or vibrator power supply may be utilized for portable or emergency service. The National Type 650S Vibrator Power Supply is designed to provide efficient operation of the receiver with the use of a 6-volt storage battery input. Further information concerning the 650S is contained at the rear of this manual on a separate data sheet.



### 1-17. LOUDSPEAKER

The HRO-50TS or HRO-50RS loudspeakers in table or rack mounting styles respectively are designed for use with the receiver. These are both permanent-magnet type loudspeakers furnished with a shielded connecting cable from the 8-ohm voice coil for connection to the output terminal board located at the rear of the receiver. If desirable a 500-ohm shielded line may be used from the receiver output terminals to the speaker and/or externally operated equipment. In the event a dynamic type loudspeaker is used external means for supplying field excitation voltage will be necessary.

A cabinet finished to match the receiver design houses the HRO-50TS loudspeaker for table mounting. The cabinet is lined with sound absorbent material to avoid mechanical resonance.

## SECTION 2. INSTALLATION

### 2-1. GENERAL

All HRO-50-1 receivers are supplied with the following eight scales mounted on the slide-rule dial drum, irrespective of the type of coil sets ordered, A, B, C, D, E-F, AA, AB and AC. If a coil set or coil sets are ordered with the receiver and the corresponding scale does not appear on the dial drum it will be found packed with the coil set. The new scale is installed in place of any one of the unused scales previously mounted on the dial drum. A Phillips head type screw at one end and a spring clip at the other end of the scale hold it properly in place. The drum scales for the A, B, C and D coil sets are frequency calibrated in megacycles for both of the available ranges i.e., General Coverage and Bandsread. The E and F coil set ranges are on the same scale, while the remaining scales carry just the one frequency range calibrated in megacycles. Each scale is clearly marked with the band designation.

### 2-2. LOCATION

The receiver should not be installed in small, unventilated or warm spaces. Wherever practicable placement should be made to allow freedom of air circulation on all four sides. The loudspeaker may be located in any desirable position although it is not recommended that it be placed on top of the receiver as undesirable microphonics may result. The loudspeaker should not be placed near the antenna terminals.

### 2-3. ANTENNA RECOMMENDATIONS

The radio frequency input of the receiver is designed for operation from either a single-wire antenna or other types employing transmission lines having impedances of 70 ohms or more. There is an antenna terminal panel at the rear of the receiver with three screw-type terminals marked A, A and G respectively. A link is provided on the antenna terminal panel to allow connection of two-wire or single-wire type antennae to the receiver.

For best impedance matching to the receiver input circuit an antenna with a 300 to 600 ohm transmission line is recommended. The antenna should be cut to the proper length for the most used frequency. The antenna transmission line feeders should be connected to the two antenna terminals marked A; the grounding link is not used. It must be remembered, however, that an antenna installation of this type will have maximum efficiency over a band of frequencies near that frequency for which it is designed and will be most useful in installations where the receiver is tuned to one frequency or band of frequencies. For other frequencies, it would be desirable to connect the two transmission line leads together at the antenna terminal at the left of the antenna terminal panel, grounding the other terminal by means of the link. The antenna is thus utilized as a single wire type.

The most practicable antenna for use in installations where the receiver is to be used over a wide range of frequencies is the single-wire type. An antenna length of from 50 to 100 feet is recommended. The antenna lead-in should be connected to the antenna terminal marked A at the left of the antenna terminal panel; the other terminal marked A should be grounded by means of the link.

When a doublet is used, the antenna feeders or balanced transmission line are connected to the two terminals marked A. The grounding link is not used.

The inner conductor of a concentric transmission line should be connected to the terminal marked A at the left of the antenna terminal panel. The outer conductor should be connected to the other terminal marked A and grounded by means of the link to G.

In some cases where a doublet antenna is used with a low impedance concentric or other type transmission line it may be necessary to re-trim the first R.F. amplifier stage at the high end of each band to provide a better impedance match between antenna and receiver input circuit. Paragraph 4-6 describes this procedure.

In an installation where the receiver is to be used as the receiving unit in a transmitting station the most efficient operation will result from use of the transmitting antenna as receiving antenna also. This is especially true if the transmitting antenna is of the multi-element, directional type since the same antenna gain is available for both receiving and transmitting - a very desirable condition. For switching the antenna from the receiver to transmitter, an antenna change-over relay should be used. A double-pole, double-throw relay possessing good high-frequency insulation is suitable. A second relay and a three position switch may be used to control the transmitter plate supply and the receiver B+ circuits. This second relay should be a single-pole, single-throw type having one normally open pair of contacts. The schematic diagram of this type of control circuit is shown in Figure 3. With S-1 in the receive position the antenna transmission line is connected to the receiver by contacts 2, 3, 5 and 6 on relay RY-1; the B+ circuit of the receiver is completed by the switch. (The B+ switch on the receiver should be at B+ Off). With the switch in the transmit position RY-1 contacts 1, 3, 4 and 6 are closed transferring the antenna transmission line to the transmitter; contacts 7 and 8 of relay RY-2 close to complete the plate supply circuit to the transmitter. Contacts 7 and 8 of relay RY-2 should be in series with the primary of the transmitter plate supply transformer. Thus, the station is in the receiving condition with switch S-1 in the receive position and in the transmitting condition with S-1 in the transmit position. With S-1 in the mid-position the receiver B+ circuit and transmitter plate supply circuit are both open thus permitting coil set changing in the receiver and transmitter. In the mid-position the receiver B+ circuit is controlled by the B+ switch on the front panel of the receiver.

#### NOTE

The high-frequency oscillator, C.W. oscillator, S-Meter amplifier and the push-pull audio output amplifier are not affected by the external relay connection to the B.S.W. terminal block. Unless the A.C. On-Off switch is set at Off these circuits will obtain an uninterrupted B-plus supply.

#### 2-4. A.C. OPERATION

After unpacking the HR0-50-1 receiver and associated equipment proceed as follows:

- (1) Make sure that all tubes are firmly seated in their sockets, tube clamps are properly in place and all grid clips securely fastened.
- (2) Make sure the plug-in coil set used in the receiver is firmly in position by pressing down the lever type handles on the front panel to their maximum vertical position.




Figure No. 3. Typical Antenna Switching System

(3) Connect the antenna as recommended in Section 2-2.

(4) Connect the loudspeaker cable to the Output terminal board at the rear of the receiver. This is accomplished by connecting the outer shield lead to the common terminal and the other to the 8-ohm terminal. A 500-ohm terminal is also available on the Output terminal board in cases where a 500-ohm line is utilized for loudspeaker connection.

(5) Connect the receiver A.C. line cord to the proper source of voltage. The Primary switch, S-10, must be set at the position corresponding to the line voltage to be used i.e., 110/120 or 220/240 volts, 50/60 cps.

(6) Set the controls as recommended in Section 3 for reception of signals.

#### NOTE

Where the receiver is located in the R.F. field of a relatively powerful transmitter, it is advisable to provide some means of preventing damage to the receiver R.F. coil. If a separate receiving antenna is used a means of disconnecting or grounding it during transmission periods should be provided.

#### 2-5. BATTERY OPERATION

The HRO-50-1 is readily adaptable for emergency, portable operation or operation in localities where a 115 or 230-volt A.C. power source is not available. It may be operated directly from batteries or a National Type 650S Vibrator Power Supply designed for operation from a 6-volt storage battery. The Type 650S power unit draws 9.5 amperes at 6-volts when furnishing power to the receiver if the Narrow-Band F.M. Adaptor, Crystal Calibrator and Select-O-Ject units are not used. If these plug-in units are utilized typical operating conditions and power consumption data will be found in Section 6.

The Schematic Diagram Figure Number 13 illustrates pin connections of the receiver Power Socket X-4. This provides the information necessary for wiring the octal type battery plug which is used to place of the regular A.C. jumper plug. To conserve battery power the battery plug must be disconnected when the receiver is not being used. For stand-by operation in all cases it is recommended that a switch be placed in the battery B-plus lead as the B-plus switch in the receiver does not open the B-plus circuit supplying the high-frequency oscillator, C.W. oscillator, S-Meter Amplifier or the push-pull audio output tubes. A suggested refinement is to include a switch in the A-plus input lead so that the tube heaters may be turned off when the receiver is not in use without the necessity of removing the battery plug from the Power socket.

## 2-6. ACCESSORY SOCKETS

Three octal type sockets are available for additional accessories as follows:

(1) A N.B. F.M. socket, X-1, is mounted on top of the chassis inside the power supply compartment. A National Type NFM-83-50 Narrow-Band F.M. adaptor is designed to fit into this socket and is supplied with a mounting bracket and drive screws to hold it firmly in place. The front-panel mounted Control switch, S-7, provides a means of switching the NFM-50 unit into instant service, as required.

(2) A Crystal Calibrator socket, X-2, is top chassis mounted in the power supply compartment. This socket is wired to accommodate a National plug-in Type XCU-50-2 Crystal Calibrator unit. A slotted head screw arrangement bolts the unit firmly in place. The front panel Calibrate switch provides a means of applying B-plus to the unit as well as the selection of either a 100 or 1000 kc. marker signal.

(3) A Select-O-Ject socket, X-3, of the standard octal type is mounted so as to be accessible from the rear of the receiver. This socket is designed primarily for the use of a National Model SOJ-3 Select-O-Ject unit. The SOJ-3 is fitted with an interconnecting cable and plug for direct connection to the Select-O-Ject socket.

Reference to the Schematic Diagram will show the various connections made to the socket if it is desired to use the voltages available for accessories other than the Select-O-Ject. It will be noted that B+ (240 V.D.C. and 105 V.D.C. regulated) and filament voltages are available. There is a definite limitation on the drain permissible at this socket. The total permissible drain (if the NFM-83-50, XCU-50-2 and SOJ-3 are not used) is 1.8 amps at 6.3 V.A.C., 10 milliamperes at 240 V.D.C. and 5 milliamperes at 105 V.D.C. If the 105-volt supply is used it must be remembered that it cannot be switched Off by the B+ On-Off switch or external switching devices connected to the B.S.W. panel unless an additional relay is used.




Figure No. 4. Rear View of Receiver

## SECTION 3. OPERATION

### 3-1. CONTROLS

All controls are identified by front-panel markings for ease of identification. The controls are located in a symmetrical manner and are arranged for ease of operation.

The main tuning HRO type micrometer dial is arranged so that the frequency to which the receiver tunes increases as the dial reading increases. The slide-rule dial pointer mechanism is synchronized with the main tuning dial using an anti-backlash gear plus an efficient string-drive arrangement to provide an accurate relationship between the main tuning dial and the direct frequency calibrated scales on the slide-rule drum assembly. Front-panel mounted is a Band selector switch for switching the proper scale in place for the coil set to be used.

The R.F. Gain control serves to adjust the amplification of the second R.F., first, and second and third I.F. amplifier stages. Maximum sensitivity is obtained by rotating the control knob to the extreme clockwise position (10 on its circular scale). At the extreme clockwise position all tubes are operating at maximum gain with minimum bias. As the control is rotated counter-clockwise, increasing bias is applied to the cathodes of the second R.F., first, second and third I.F. tubes, thus reducing their amplification.

The A.C. On-Off switch is associated with the A.F. Gain control and A.C. power is turned on as the A.F. Gain control is advanced from A.C. Off to zero on its scale.

The B+ On-Off switch is connected in the positive lead of the power supply circuit and its purpose is to disconnect the B-plus during periods of transmission or WHEN CHANGING COIL SETS. This last function is important. The B+ circuits are completed when the switch is set at On. However, the B-plus circuits of the high-frequency oscillator, S-Meter amplifier, C.W. oscillator and push-pull audio output tubes remain On at all times regardless of the position of the B+ On-Off switch providing the A.C. On-Off switch is set at On.

Connected in parallel with the B+ switch and mounted at the rear of the chassis is a pair of contacts marked B.S.W. intended for use with relay control of the receiver. The B.S.W. panel is covered by a metal shield to prevent accidental contact with the terminals by the operator. Two slots are provided in this shield to bring out wires to connect to an external switch or relay. Care should be taken that these wires for external connection do not short to the B.S.W. shield.

The Phasing control and Selectivity switch are part of the crystal filter. When the Selectivity switch is set at Off the crystal is switched out of the circuit. With the crystal switched out the Phasing control has no influence on receiver performance. With the Selectivity switch set at any point between 1 and 5, inclusive, the crystal filter is in operation, selectivity increasing as the switch is progressively advanced to position 5. The Phasing control is then used to balance the crystal bridge circuit and eliminate interfering signals or heterodynes. It is recommended that the Tone control be rotated counter-clockwise until the switch is turned Off. This will provide optimum reception of the high audio frequencies when using the crystal filter for A.M. reception. The resultant boost of the higher frequencies tends to compensate for the side-band cutting action of the crystal filter.

The C.W. oscillator is turned on by setting the front-panel mounted Control switch at the C.W. position. The C.W.O. control provides a vernier tuning adjustment for the C.W. oscillator transformer. This oscillator is used to produce an audible beat note when receiving C.W. signals or to locate the carrier of a weak phone station. With the Control switch set at the C.W. position, B-plus is applied to the C.W. oscillator tube providing a constant B-plus supply regardless of the B+ On-Off switch setting or the B.S.W. external control devices. Normally the C.W.O. control is set at zero, however by rotating it either to the right or left of zero the operator can select an audio tone suitable to the ear, or he may set the control for best reception. The C.W. code characters are made audible through the heterodyning action of the C.W. oscillator with that of the incoming signal. Care






Figure No. 5. Front View of Receiver

should be taken to retard the R.F. Gain control to a point where the receiver does not overload.

The Limiter control serves to switch on the limiter and following this, to adjust the threshold at which limiting action starts. With the Limiter control turned on (at position 0 on the dial scale) limiting action automatically takes place at a relatively high percentage modulation. Rotating the control clockwise progressively lowers the threshold, or percentage modulation, at which limiting action starts until maximum clipping is achieved at 10. This limiter is double-acting in that limiting is accomplished by clipping of both positive and negative peaks. Limiting action is equally effective for both phone or C.W. reception.

The Tone control is used to vary the audio frequency characteristic of the audio system. In the extreme counter-clockwise position the greatest degree of high audio frequency response is obtained. Rotating the control clockwise until the switch mounted on the control just closes provides a comparatively flat response over the entire usable audio frequency range. Rotating the control further in a clockwise direction will attenuate the high audio frequencies as shown in Figure Number 2. If a signal is weak and partially obscured by background noise or static an improvement in signal-to-noise ratio is possible by the attenuation of the higher audio frequencies. Excessive attenuation of these frequencies, however, may result in an impairment of A.M. speech intelligibility. When receiving C.W. signals it will be possible to advance the Tone control considerably further than is possible in A.M. reception since audio distortion is relatively unimportant.

The A.V.C. switch is a two-position toggle marked A.V.C.-Off. The automatic volume control circuits are operative with the toggle switch in the A.V.C. or upper position.

The A.F. Gain control adjusts the volume level of the signal at both the Phones jack and loud-speaker terminals. Clockwise rotation of this control increases the signal applied to the grid of the first audio amplifier tube. The A.F. Gain control is operative when an audio signal is applied to the Phono input jack with the Control switch set at the Phono position.

A Bandspread switch is mounted on the A, B, C and D coil sets. Inspection of the coil set ceramic terminal panel will show a silver-plated spring metal strip with a slotted center-screw. Four silver-plated contacts are provided on the terminal panels; two for each type of reception i.e., General Coverage or Bandspread. The metal strip may be turned either to the right or left thereby selecting the type of reception required. A spring tension detent arrangement provides for proper placement and a firm trouble-free electrical contact in each position. It is only necessary to switch this from the right to the left hand side to change from General Coverage to Bandspread. The

lower calibrated scale on the slide rule dial is used when operating in the Bandsread position. A typical coil set showing adjustment locations is illustrated in Figure Number 7 contained in Section 4.

The Ant. Trim. control operates a tuning capacitor which is connected across the first R.F. amplifier section of the main tuning capacitor. This trimmer control is used to tune the first R.F. amplifier stage properly under a wide variety of antenna loading conditions over the entire frequency range of the receiver.

The Dimmer control is a variable resistor actuated by a front-panel mounted dial. It is connected in series with one of the filament supply wires to the S-Meter and slide-rule dial pilot lamps and furnishes a means of varying the degree of illumination as desired by the operator.

The front-panel mounted Osc. trimmer control drives a variable air capacitor connected in parallel with the oscillator main tuning capacitor. Assuming that the receiver is properly aligned this compensating trimmer may be used for minor calibration adjustments. Calibration can be checked by the use of accurate crystal-controlled test oscillators or by using the National Model XCU-50-2 Crystal Calibrator. Use of the Osc. trimmer should not be attempted until the receiver has had a warm-up period of at least five minutes.

A four position Control switch is mounted on the front panel of the receiver. In the C.W. position the C.W. oscillator is placed in operation. The A.M. position provides normal reception of phone or broadcast signals. In the N.F.M. position the reception of narrow-band F.M. signals is possible provided a National Type NFM-83-50 adaptor is plugged into the N.B.F.M. socket. With the Control switch in this position the adaptor is connected between the output of the intermediate amplifier and the input of the audio system. When the Control switch is set in the Phono position the Phono jack is connected to the input of the audio amplifier. In the Phono position all of the receiver circuits except the audio system are rendered inoperative. The A.F. Gain and Tone controls remain operative. If it is so desired the record player may remain connected to the receiver and normal receiving operation resumed by setting the Control switch to any of the other positions.

### 3-2. PHONE RECEPTION

After the HRO-50-1 is properly installed as outlined in Section 2, it is placed in operation by the following adjustments:

1. Set the Control switch at A.M.
2. Set the A.V.C. switch at A.V.C.
3. Set the Selectivity switch at Off.
4. Set the Phasing control at zero.
5. Set the Limiter control at Off.
6. Set the R.F. Gain control at 10.
7. Check the position of the Osc. trimmer control pointer. It is aligned at the factory so that proper calibration is obtained with the pointer in a vertical position with the arrow head pointed to the "S" in the Osc. panel engraving.
8. Turn the A.C.-On-Off switch mounted on the A.F. Gain control to On i.e., zero on the dial scale.
9. Set the receiver B+ switch at On.
10. Adjust the Band control to select the scale corresponding to the plug-in coil set in use.
11. Turn the A.F. Gain control to the position giving the desired audio volume.
12. Adjust the Ant. Trim. control for a maximum S-Meter reading after the desired station has been selected. Alternately in the absence of a signal the Ant. Trim. control may be set for maximum receiver background noise.
13. Turn the Tone control to a position giving the desired audio output response.

The receiver is now adjusted for the reception of phone signals and will tune to the frequency

corresponding to the plug-in coil set in use and the setting of the main tuning dial. If a dual-coverage plug-in coil set is used the position of the Bandsread switch, as previously described in paragraph 1 of this section, will determine the frequency coverage i.e., General Coverage or Bandsread.

The settings given above are for the reception of signals of average strength. Exceptionally strong or weak signals may require modification of the above settings. Very strong signals may cause overload or distortion in the receiver with the R.F. Gain control at 10. In this case retarding this control slightly until the overload or distortion disappears is recommended. However, the operator must remember that automatic volume control action will be restricted unless the R.F. Gain control is fully advanced. Audio output should be adjusted entirely by means of the A.F. Gain control.

The A.V.C. - Off switch may be set at the Off position to provide increased sensitivity in some cases. With such a setting the operator must be careful not to advance the R.F. Gain control to a point where I.F. or audio amplifier overload occurs. Such overload is indicated by distortion.

Various types of interference which may be encountered due to adverse receiving conditions can be minimized by utilization of the following controls in the manner described.

Noise Limiter — When a signal is accompanied by static peaks or noise pulses of high intensity and short duration, the best signal-to-noise ratio will be obtained by turning On the Limiter control. In general, it will be found that turning the Limiter control On to 0 on the dial scale will effectively minimize interference caused by external noise pulses. In cases where the noise pulses are extremely pronounced a higher degree of noise suppression will be realized by advancing the Limiter control to a higher dial setting.

Tone control — An improvement in signal-to-noise ratio can be realized by setting the Tone control to attenuate the high audio frequencies. When receiving weak signals which are partially obscured by background noise or static an improvement in reception will be noticed by rotating the Tone control in a clockwise manner. However, too much attenuation of the high audio frequencies may impair the intelligibility of speech.

Selectivity and Phasing — The selectivity of the receiver is adjusted by means of the crystal filter Selectivity switch. The normal setting of the Selectivity switch in phone or broadcast reception is at one of the positions affording broad selectivity. Positions marked Off, 1 or 2 are recommended. Selectivity may be progressively increased by turning the Selectivity switch to position 3, 4 or 5. Increasing selectivity will result in the attenuation of the higher audio frequency tones of the signal as well as sharper tuning. If the selectivity is increased too much these higher frequency audio tones will be attenuated to such an extent that phone or broadcast signals may become unintelligible due to excessive side-band cutting. The Phasing control is part of the crystal filter and is used to eliminate or attenuate interfering heterodynes. The Phasing control is inoperative with the Selectivity switch set in the Off position but is operative in all other settings. The normal setting of the Phasing control with the crystal filter On (i.e., the Selectivity switch set at 1, 2, 3, 4 or 5) in phone reception is at zero on its scale. If, after a desired signal has been tuned in, an interfering signal causes a heterodyne or whistle the Phasing control should be adjusted until this interference is reduced to a minimum. The setting of the Phasing control should be that which provides a maximum attenuation of the objectionable heterodyne. If the heterodyne is below 1,000 cycles the optimum Phasing control setting will be near either one or the other end of the dial scale, depending upon whether the interfering signal has a higher or lower frequency than the desired signal.

### 3-3. C.W. RECEPTION

The initial adjustment of the receiver controls for C.W. reception is the same as given in Section 3-2 except that the Control switch must be set at C.W.

For the reception of C.W. signals the action of the crystal filter is similar to that for phone reception except that full use of the sharp selectivity position may be used without the loss of intelligibility experienced in phone reception. When maximum selectivity is used, (Selectivity switch at position 5) care must be exercised since tuning is very critical. When the receiver is slowly tuned across the carrier at the received signal the beat-note produced will be very sharply peaked in output at a particular audio pitch. This peak in response indicates the correct receiver dial setting. The setting of the C.W.O. control must be such that the beat-note peak is well within the audible range so that the receiver peak response may be readily observed. A C.W.O. dial setting near zero is recommended. After the receiver has been correctly tuned, the pitch of the beat-note peak may be adjusted by means of the C.W.O. control to provide an audio tone which is pleasing to copy or coincides with any response peaks in the speaker or headphones. Under these conditions the receiver will exhibit pronounced single-signal properties which may be demonstrated by tuning the receiver to the other side of "zero-beat" so that the pitch is the same as before and observe the marked reduction in output. This dial setting is not recommended for use other than to demonstrate the single-signal properties of the receiver. With the receiver tuned to "crystal peak", an interfering signal may be attenuated by proper setting of the Phasing control since this control has little effect on the desired signal.

Similar to phone reception the Limiter control can be used to great advantage in C.W. reception for the reduction of interference due to external noise pulses. For C.W. reception, however, the Limiter control may be set at a well advanced position on the dial scale as excessive clipping of the modulation peaks will not be experienced as might be the case in phone reception. Also the Tone control may be advanced considerably further for C.W. reception since audio distortion is relatively unimportant.

#### 3-4. N.B.F.M. OPERATION

The HRO-50-1 receiver is adaptable for Narrow-Band F.M. reception by utilizing a National Type NFM-83-50 Narrow-Band F.M. adaptor. Operating instructions as given in paragraph 3-2 of this section are applicable for the reception of narrow-band F.M. signals except that the Control switch must be set at N.F.M. It is recommended when the operator is scanning a band for signals that the Control switch is set at A.M. An F.M. signal is indicated by the presence of an audio null in the center of the signal carrier. When an F.M. signal is encountered the Control switch should then be set at N.F.M. and with the A.V.C. switch set at A.V.C. the signal tuned for maximum S-Meter reading.

#### 3-5. MEASUREMENT OF SIGNAL STRENGTH

To measure the strength or intensity of a signal the R.F. Gain control must be advanced to 10, the Control switch set at A.M. and the A.V.C.-Off switch at A.V.C. The crystal filter should be turned Off by means of the Selectivity switch and the Phasing control set at zero. The Ant. Trim. control should be adjusted for a maximum S-Meter reading after a signal has been tuned in. The Limiter, Tone and A.F. Gain controls do not affect the S-Meter reading.

Tuning the receiver to a signal will cause the S-Meter to read, indicating the signal input in S-units from 1 to 9 and in decibels above the S-9 level from zero to 40 db. With no R.F. input to the receiver, or with the antenna disconnected, the S-Meter should read zero plus or minus one-half an S-unit. If it does not the S-Meter circuit compensator requires adjustment. See Section 4-7 for adjustment procedure.

Design of the S-Meter actuating circuit is such that a signal stronger than 40 db. above S-9 cannot cause the meter pointer to come in violent contact with the full-scale meter stop pin thus preventing the possible bending of the meter pointer.

For the purpose of comparing strong signals, which cause the meter pointer to read full scale, with other stronger and/or weaker signals the sensitivity of the S-Meter may be lowered by retarding the R.F. Gain control.

Measurements of the signal strength of C.W. signals cannot be made with the C.W. oscillator in operation.

With the receiver A.C.-On-Off switch set at Off the meter pointer will return to its mechanical zero located on the right hand or 40 db. end of the meter.

## SECTION 4. ALIGNMENT DATA

### 4-1. GENERAL

All circuits in the HR0-50-1 receiver are carefully aligned before shipment using precision test equipment insuring accurate conformability to the alignment frequency. No realignment of the various adjustments will be required unless the receiver is tampered with or component parts or tube replacements have been necessary.

A definite need for realignment can be determined by checking the performance of the receiver against its normal operation as outlined in Section 3. A simple check to assure the need of realignment of the I.F. Amplifier is provided in paragraph 4-2 of this section. In no case should realignment be attempted unless tests indicate that such realignment is necessary. Even then it must be remembered that the HR0-50-1 is a communications receiver and should not be serviced or realigned by any individual who does not have a complete understanding of the functioning of the equipment and who has not had previous experience adjusting receivers of this type.

Complete alignment of the receiver can be divided into three steps as follows:

- (a) Intermediate Frequency Amplifier alignment including crystal filter adjustments.
- (b) General Coverage Alignment
- (c) Bandspread Alignment

All circuits must be tuned in the above order when complete alignment is required. All alignment adjustments and controls are shown on Figure Numbers 6, 7 and 10.

### 4-2. I.F. AMPLIFIER CHECK

The making of any adjustment indiscriminately is cautioned against and no circuit should be realigned unless tests definitely indicate that realignment is necessary.

The alignment of the intermediate frequency amplifier may be easily checked in the following manner:

1. Adjust the receiver for normal operation with the antenna disconnected.
2. Connect a pair of headphones to the Phones jack.
3. Set the A.V.C. switch at Off.
4. Set the Control switch at C.W.
5. Set the Phasing control at zero.
6. Set the Selectivity switch at 5.
7. Set the R.F. Gain control at 10.

The setting of the A.F. Gain control does not affect the measurement and may be adjusted to provide sufficient headphone output to make the required observations. Adjust the C.W.O. control



until a point is found where the predominant pitch of the background noise is lowest and a distinct crystal ring is heard. Note this setting of the C.W.O. control. Disconnect the crystal filter from the circuit by turning the Selectivity switch to the Off position. Once more adjust the C.W.O. control for the lowest predominant pitch of background noise and note the setting. If the I.F. amplifier is correctly aligned to the crystal filter frequency the setting of the C.W.O. control will be the same for both tests outlined above. If the two settings differ perform the complete I.F. amplifier alignment procedures in the following paragraph 4-3.




Figure No. 6. Top View of Receiver

#### 4-3. I.F. AMPLIFIER ALIGNMENT

The intermediate frequency of the HR0-50-1 is 455 kilocycles plus or minus 2 kilocycles. The exact frequency is determined by the quartz crystal resonator, Y-1, used in the crystal filter.

The crystal filter and C.W. oscillator transformer are fitted with air-type variable trimmer capacitors for alignment purposes. The I.F. transformers are aligned by means of variable iron cores. These adjustments are located on Figure Numbers 6 and 10.

The preliminary alignment procedure is as follows:

- (1) Connect the high output lead of an accurately calibrated signal generator to the stator portion of the mixer section of the main tuning capacitor, C-5C, and the grounded lead to any convenient point on the chassis. This is a direct connection.
- (2) Connect an output meter having an 8 or 500 ohm resistive load to the matching output terminals on the receiver. As an alternative a high-impedance A.C. voltmeter may be connected to the phones jack.
- (3) Set the Control switch at C.W.
- (4) Set the A.V.C. switch at Off.
- (5) Set the Phasing control at zero.
- (6) Set the Selectivity switch at 5.
- (7) Set the A.F. Gain control at 10.
- (8) Set the R.F. Gain control at 9.
- (9) Turn the modulation of the signal generator off to provide a steady C.W. test signal

tuned to approximately 455 kilocycles.

Adjust the output attenuator of the signal generator to provide a signal of approximately 100 microvolts. The C.W.O. control must be set to provide an audio beat-note at some frequency between 400 and 1000 cycles per second. The presence of this beat note can readily be determined by temporarily connecting headphones or a loudspeaker to the receiver. If difficulty is encountered in obtaining such a beat-note an adjustment of the C.W.O. transformer trimmer capacitor, C-61, must be made.

Vary the tuning control of the signal generator very slowly between the frequencies of 453 and 457 kilocycles. At one frequency between these limits the I.F. amplifier of the receiver will show a very definite sharply peaked response, as indicated on the output meter. This frequency is that of the crystal filter crystal, Y-1, and I.F. alignment, as outlined below, is made at this frequency.

While making I.F. amplifier adjustments it will be necessary to retard the attenuator of the signal generator if I.F. amplifier gain increases to a point where overload occurs. Without altering the frequency setting of the signal generator set the Selectivity switch at Off, the Control switch at A.M. and turn the modulation of the signal generator On. Capacitors C-33, C-39 and inductors L-2 through L-13 should at this point each be carefully adjusted to give a maximum reading on the output meter. The order in which these adjustments are performed is not important.

Upon completion of the above adjustments set the Selectivity switch at 1. Set the frequency of the signal generator 2 kilocycles higher and adjust the crystal filter trimmer capacitor C-39 for a maximum output meter indication. After making this adjustment set the Selectivity control at Off and return the signal generator to the exact crystal frequency (2 kilocycles lower). Tune the Selectivity compensating trimmer capacitor C-38 for a maximum reading on the output meter.

The Phasing control as set at the factory should need no further attention. When correctly set a predominant decrease in background level will be found with the Selectivity switch at position 5 and the Phasing control set at zero. This same null point should be found by rotating the Phasing control exactly 180 degrees. If not, a slight adjustment of the phase balancing capacitor C-36 will provide the proper setting.

Turn the modulation of the signal generator Off and set the Control switch at C.W. Rotate the C.W.O. control to its full clockwise position. If in this position the dial control does not coincide with 5 on its scale loosen the dial knob and reset it at 5. Set the C.W.O. control to zero beat with the signal generator signal. If zero beat does not occur at 0 on the control dial carefully readjust the air trimmer capacitor C-61 of the C.W. oscillator transformer T-8.

#### 4-4. GENERAL COVERAGE ALIGNMENT

The data given in this section applies to the General Coverage alignment of the H.F. oscillator and R.F. amplifier stages of all coil sets. The original alignment at the National Laboratories is accomplished by the use of precision, crystal-controlled test oscillators. No realignment should be attempted unless a reliable test signal source is available. In the case of General Coverage H.F. oscillator alignment, a test signal source with an accuracy of 1% or better is required. For Band-spread alignment the calibration accuracy demands that the test signal source have the accuracy of precision-calibrated crystals. The entire range of test frequencies required may be obtained by the use of nine crystals operating at their fundamental and harmonic frequencies. The frequency of these crystals is as follows: 0.05, 0.1, 1.0, 2.0, 3.5, 5.0, 6.8, 7.0, 7.3, 14.4 and 15 megacycles.

The need for realignment of the H.F. oscillator of any band is indicated when the frequency calibration of the receiver dial is in error by more than 1% at the high frequency end of the band in question. If it is determined that realignment is necessary proceed as follows:

(1) Connect an output meter to the receiver as described in paragraph 4-3 of this Section and disconnect the antenna.




Figure No. 7. Typical Coil Set Showing Alignment Adjustment Locations

- (2) Set the Control switch at A.M.
- (3) Set the A.V.C. switch at Off.
- (4) Set the Selectivity switch at Off.
- (5) Set the R.F. Gain control at 10.
- (6) Set the Bandsread switch in the General Coverage position.
- (7) Set the A.F. Gain control to provide a suitable output level.
- (8) Check the position of the Ant. Trim. and Osc. trimmer controls. Alignment should be made with both of the pointers on these controls in a vertical position with the arrow-head pointed towards the top of the receiver.

The following Alignment chart gives the step-by-step procedure to follow in effecting the General Coverage alignment of each coil set. It is important that the chart of adjustments is adhered to in the order shown. It will be noted that General Coverage alignment affects Bandsread alignment, but that adjustment of Bandsread alignment does not affect General Coverage.

Particular care must be taken when adjusting the high-frequency oscillator trimmer C-26 in each coil set. It is imperative that the high-frequency oscillator is set to operate at a frequency above the R.F. amplifier frequency and not below. This can be checked by tuning in the image of the test signal which must appear 910 kilocycles lower on the receiver dial. If it is found that the image does not appear at this dial setting the H.F. oscillator is incorrectly adjusted and the capacity of the trimmer capacitor C-26 must be decreased until the image and fundamental signals appear at the proper points on the dial. After the high-frequency oscillator is correctly calibrated the R.F. amplifier trimmers C-2 and C-15 and the mixer trimmer C-21 should be adjusted for maximum receiver gain as measured by the output meter. Coil sets A and D do not use a first R.F. amplifier trimmer but are peak-tuned by the use of the Ant. Trim. control over the full frequency range of each

coil set. It may be desirable to align the R.F. Amplifier trimmers C-2 and C-15 and the mixer trimmer C-21 using receiver background noise as an indication of maximum gain, rather than the signal source. If this alternate method of alignment is used the point of maximum gain is that setting of the trimmers which provides the loudest receiver background noise. However, it is possible to align the R.F. amplifier and mixer stages to the image frequency using background noise as an indicator. A check of this possibility is to tune in the image signal — if the image is weaker than the fundamental signal the R.F. amplifier and mixer stages are correctly aligned.

Correction of tracking errors of the R.F. amplifier and mixer stages at the low frequency limit of each coil set is accomplished by the adjustments listed on the Alignment Chart. The actual tracking of these stages may be checked by pressing the outside rotor plates of the main tuning capacitor section toward or away from the stator in a manner assuring that the rotor plates will spring back to their original position. Any change in capacity should decrease the receiver gain if the stage is tracking properly.

The locations of the adjustments referred to on the General Coverage Chart are shown on Figure Number 7. Each variable on the chart is followed by a number in parenthesis to identify its position on the respective coil set. Schematic diagrams of each of the plug-in coil sets are furnished on Figure Numbers 11 and 12.

GENERAL COVERAGE CHART

Step	Coil Set	Adjust Signal Source and Receiver To:	Adjust to Receive Test Signal	Adjust for Maximum Output
1	A	30.0 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4).
2	A	14.4 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
3	A	30.0 Mc.		Check step 1. Repeat steps 1 and 2 if necessary.
1	B	14.4 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	B	7.0 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
3	B	14.4 Mc.		Check step 1. Repeat steps 1 and 2 if necessary.
1	C	7.3 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	C	3.5 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
3	C	7.3 Mc.		Check step 1. Repeat steps 1 and 2 if necessary.
1	D	4.0 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	D	1.8 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
3	D	4.0 Mc.		Check step 1. Repeat steps 1 and 2 if necessary.

GENERAL COVERAGE CHART (CONT'D)

Step	Coil Set	Adjust Signal Source and Receiver to:	Adjust to Receive Test Signal	Adjust for Maximum Output
1	E	2.0 Mc	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4).
2	E	1.0 Mc.	Padder capacitor C-100 (Pos. 7).	
3	E	1.4 Mc.	Inductance at Pos. No. 16.	
4	E	2.0 Mc.		
				Check step 1. Repeat steps 1, 2 and 3 if necessary.
1	F	0.9 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	F	0.5 Mc.	Padder capacitor C-100 (Pos. 7).	
3	F	0.7 Mc.	Inductance at Pos. No. 16.	
4	F	0.9 Mc.		
				Check step 1. Repeat steps 1, 2 and 3 if necessary.
1	G	400 Kc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4).
2	G	200 Kc.	Padder capacitor C-100 (Pos. 7).	
3	G	300 Kc.	Inductance at Pos. No. 16.	
4	G	400 Kc.		
				Check step 1. Repeat steps 1, 2 and 3 if necessary.
1	H	200 Kc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	H	100 Kc.	Padder capacitor C-100 (Pos. 7).	
3	H	150 Kc.	Inductance at Pos. No. 16.	
4	H	200 Kc.		
				Check step 1. Repeat steps 1, 2 and 3 if necessary.
1	J	100 Kc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	J	50 Kc.	Padder capacitor C-100 (Pos. 7).	
3	J	75 Kc.	Inductance at Pos. No. 16.	
4	J	100 Kc.		
				Check step 1. Repeat steps 1, 2 and 3 if necessary.



GENERAL COVERAGE CHART (CONT'D)

Step	Coil Set	Adjust Signal Source and Receiver to:	Adjust to Receive Test Signal	Adjust for Maximum Output
1	AA	30 Mc.	Trimmer capacitor C-26 (Pos. 7).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	AA	27.2 Mc.	Padder capacitor C-100 (Pos. 8).	Padder capacitors C-99 (Pos. 5), C-98 (Pos. 3), C-97 (Pos. 1).
3	AA	28 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
4	AA	30 Mc.		Check step 1. Repeat steps 1, 2 and 3 if necessary.
1	AB	35 Mc.	Trimmer capacitor C-26 (Pos. 8).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	AB	25 Mc.	Padder capacitor C-100 (Pos. 7).	Padder capacitors C-99 (Pos. 5), C-98 (Pos. 3), C-97 (Pos. 1).
3	AB	30 Mc.	Inductance at Pos.No. 16.	Inductance at Pos. Nos. 13, 11, 9.
4	AB	35 Mc.		Check step 1. Repeat steps 1, 2 and 3 if necessary. Check step 1.
1	AC	21.5 Mc.	Trimmer capacitor C-26 (Pos. 7).	Trimmer capacitors C-21 (Pos. 6), C-15 (Pos. 4), C-2 (Pos. 2).
2	AC	21 Mc.	Padder capacitor C-100 (Pos. 8).	Padder capacitors C-99 (Pos. 5), C-98 (Pos. 3), C-97 (Pos. 1).
3	AC	21.3 Mc.	Inductance at Pos. No. 16.	Inductance at Pos. Nos. 13, 11, 9.
4	AC	21.5 Mc.		Check step 1. Repeat steps 1, 2 and 3 if necessary. Check step 1.

4-5. BANDSPREAD ALIGNMENT

The data given in this section applies to the Bandspread Alignment of the high-frequency oscillator, R.F. amplifier and mixer stages of coil sets A, B, C and D. It is important that no Bandspread adjustments are made until after completion of General Coverage alignment as General Coverage adjustments affect Bandspread alignment.

The need for realignment of the H.F. oscillator of any band is indicated when the frequency calibration of the main tuning dial is in error by more than  $\pm 5$  divisions. To effect alignment the receiver controls are adjusted the same as outlined in Section 4-4, except that the Bandspread switch on each of the plug-in coils must be in the right-hand or Bandspread position.

The procedure in effecting Bandspread alignment is accomplished by adhering to the instructions given in the Bandspread Alignment Chart. The procedure is similar to that for General Coverage except for the method followed in checking tracking errors of the R.F. amplifier and mixer stages at the low-frequency limit of each coil set. To secure an indication of proper tracking, check the setting of the Bandspread trimmer capacitors C-3, C-16 and C-22 for the position of maximum receiver gain. Any change in capacity should decrease the receiver gain indicating proper tracking. The use of the trimmer capacitors C-3, C-16 and C-22 for a tracking check may destroy their proper settings therefore they must be carefully rechecked at the high-frequency limit of the coil set. The location

BANDSPREAD ALIGNMENT CHART

NOTE: Do not effect Bandspread Alignment until after completion of General Coverage.

Step	Coil Set	Adjust Signal Source and Receiver to:	Adjust to Receive Test Signal	Adjust for Maximum Output
1	A	30.0 Mc.	Trimmer capacitor C-27 (Pos. 7).	Trimmer capacitors C-22 (Pos. 5), C-16 (Pos. 3), C-3 (Pos. 1).
2	A	27.2 Mc.	Padder capacitor C-25 (Pos. 15).	Padder capacitors C-20 (Pos. 14), C-14 (Pos. 12), C-1 (Pos. 10).
3	A	30.0 Mc.		Check step 1. Repeat steps 1 and 2 if necessary. Check step 1.
1	B	14.4 Mc.	Trimmer capacitor C-27 (Pos. 7).	Trimmer capacitors C-22 (Pos. 5), C-16 (Pos. 3), C-3 (Pos. 1).
2	B	14.0 Mc.	Padder capacitor C-25 (Pos. 15).	Padder capacitors C-20 (Pos. 14), C-14 (Pos. 12), C-1 (Pos. 10).
3	B	14.4 Mc.		Check step 1. Repeat steps 1 and 2 if necessary. Check step 1.
1	C	7.3 Mc.	Trimmer capacitor C-27 (Pos. 7).	Trimmer capacitors C-22 (Pos. 5), C-16 (Pos. 3), C-3 (Pos. 1).
2	C	7.0 Mc.	Padder capacitor C-25 (Pos. 15).	Padder capacitors C-20 (Pos. 14), C-14 (Pos. 12), C-1 (Pos. 10).
3	C	7.3 Mc.		Check step 1. Repeat steps 1 and 2 if necessary. Check step 1.
1	D	4.0 Mc.	Trimmer capacitor C-27 (Pos. 7).	Trimmer capacitors C-22 (Pos. 5), C-16 (Pos. 3), C-3 (Pos. 1).
2	D	3.5 Mc.	Padder capacitor C-25 (Pos. 15).	Padder capacitors C-20 (Pos. 14), C-14 (Pos. 12), C-1 (Pos. 10).
3	D	4.0 Mc.		Check step 1. Repeat steps 1 and 2 if necessary. Check step 1.

of the adjustments referred to in this section are shown on Figure Number 7. Each variable on the chart is followed by a number in parenthesis to identify its position on the respective coil set. Schematic diagrams of each of the four combination Bandspread and General Coverage coil sets A, B, C and D are furnished on Figure Number 11.

4-6. FIRST R.F. STAGE ALIGNMENT WITH LOW IMPEDANCE TRANSMISSION LINE

If a low impedance transmission line is to be used with the receiver, it may be necessary to re-align the first R.F. amplifier at the high-frequency end of each band. The tracking of the first R.F. amplifier stage on each of the coil ranges may be checked by rotating the Ant. Trim. control. If two definite peaks in output are observed while rotating the Ant. Trim. control, the first R.F. amplifier stage is tracking correctly and the setting at either peak is correct. The lack of a peak in output or the presence of only one peak indicates the stage is not tracking properly and correction should be made. The General Coverage adjustments affect the Bandspread adjustments and must therefore be performed first. The following procedure should be adhered to:

(a) GENERAL COVERAGE

(1) Set the Bandspread switch on each coil to the left-hand side or General Coverage position. Adjust the receiver for normal operation as follows: Control switch at A.M., Selectivity switch at Off, Ant. Trim. control pointer set in a vertical position with the arrow head towards the top of the receiver, A.F. Gain control set at 10 and the R.F. Gain control set to provide a suitable signal level.

(2) Connect the antenna feeders to the receiver antenna terminals and tune the receiver to the signal shown in step 1 on the General Coverage Alignment Chart for the coil set to be aligned. Adjust the trimmer capacitor C-2 for maximum signal output. Coil sets A and D do not use a first R.F. amplifier General Coverage trimmer but are peak-tuned by the Ant. Trim. control over the full frequency range of each coil set.

(b) BANDSPREAD

(1) With the receiver adjusted in the same manner as for General Coverage shift the Bandspread switch on each coil terminal panel to the right-hand side or Bandspread position.

(2) Connect the Antenna feeders to the receiver antenna terminal and tune the receiver to the signal shown in Step 1 on the Bandspread Alignment Chart for the coil set being aligned. Adjust the Bandspread trimmer capacitor C-3 for maximum signal output. If no signal can be received the trimmer may be adjusted for maximum background noise.

4-7. S-METER ADJUSTMENT

The S-Meter balancing resistor R-21 is used to obtain a zero meter reading in the absence of signal input to the receiver. To make this adjustment set the controls as follows: set the R.F. Gain control at 0, A.V.C. switch at A.V.C., Control switch at A.M. and the A.C. switch at On. Adjust the S-Meter balancing resistor R-21 for a zero reading on the S-Meter. This is a screwdriver type adjustment located on the top of the chassis.

## SECTION 5. MAINTENANCE

5-1. GENERAL MAINTENANCE DATA

Any repairs in the HRO-50-1 receiver which necessitates resoldering of joints must be made with care. A good mechanical connection must be made before the solder is applied.

Failure of a vacuum tube in the receiver may reduce the sensitivity, produce intermittent operation or cause the equipment to be completely inoperative. In such cases, all tubes should be checked either in an analyzer or similar tube testing equipment or by replacement with tubes of proven quality. When any tube is tested, it should be tapped or jarred to make sure that it has no internal loose connection or intermittent short circuit.

Tubes of the same type will vary slightly in their individual characteristics and this fact should be borne in mind when replacements become necessary. The C.W. oscillator, high-frequency oscillator and I.F. tubes should be chosen with care to select a replacement which most nearly approaches the characteristic of the original tube. A replacement high frequency oscillator tube can be readily checked by noting any change in dial calibration, particularly on the amateur bandspread bands. Substitution of new I.F. amplifier tubes may possibly alter overall gain and selectivity characteristics. The necessity for realignment as well as alignment procedures is discussed in Section 4.

In case of breakdown or failure of the receiver, the fault must first be localized. This can

often be accomplished by observation of some peculiar action of one of the controls. Reference to the circuit diagram will aid in checking voltages at the various tube elements. Measurement of voltages in accordance with Section 5-4. will most likely indicate where failure has occurred.

#### 5-2. CIRCUIT FAILURES

All components parts in the HRO-50-1 receiver have been selected to assure an ample factor of safety. Failure may occur in individual cases and the most common cause of failure, excluding tubes, will probably be due to breakdown of a capacitor or resistor.

Bypass or filter capacitors which develop poor connections internally, or which become open-circuited, will cause decreased sensitivity, oscillation or poor stability. The defective unit can be located by temporarily connecting a good capacitor in parallel with each capacitor that is under suspicion.

Failure of any bypass or filter capacitor may seriously overload resistors in associated circuits. Overload of sufficient magnitude to permanently damage a resistor will cause the surface of the resistor to be scorched, making the defective unit easy to locate by visual inspection.

Open or short-circuited resistors can be definitely located by measuring the resistance of each individual resistor. The schematic diagram should be consulted to make sure that any particular resistor under test is not connected in parallel with some other circuit element which might produce a false measurement.

Loose connections which cause intermittent or noisy operation can often be found by tapping or shaking any component under suspicion with the receiver adjusted for normal operation.

#### 5-3. STAGE GAIN MEASUREMENTS

The sensitivity measurements listed herein are made with the receiver set up as specified in Section 3-2 except that the A.F. Gain control is set at 10. Connect an output meter with an impedance to match the receiver output circuit i.e., 8 or 500 ohms to the output terminal panel in place of the loudspeaker. It is important that the proper output impedance match be observed.

Connect the high output lead of the signal generator through a 0.1 mf coupling capacitor to the grid of each tube as specified in the following table. The ground lead of the generator is connected to any convenient chassis point.

The signal generator, using modulation, is varied between 453 and 457 kilocycles until a pronounced peak reading is obtained on the output meter.

With the generator attenuated to provide a one watt reading on the output meter the signal generator attenuator should read within the limits specified on the following table:

TERMINAL	TEST SIGNAL
Mixer Grid	60 ± 20 Microvolts
First I.F. Grid	530 ± 50 Microvolts
Second I.F. Grid	2800 ± 250 Microvolts
Third I.F. Grid	48,000 ± 5000 Microvolts

#### 5-4. VOLTAGE TABULATION

All voltage measurements should be made using a high-impedance vacuum tube voltmeter. Readings taken with any other type of instrument will differ somewhat depending upon the input resistance of the meter. Voltmeter resistance should be ten times larger than the resistance of the circuit across which the voltage is measured otherwise the voltmeter will indicate a voltage lower than the




Figure No. 8. Tube Socket Voltages

actual voltage present. The tube socket voltage tabulations contained in Figure Number 8 were taken using a vacuum tube voltmeter with an input resistance of 11 megohms. All voltages are measured between specified socket terminals and chassis. The control settings to be observed are shown on Figure Number 8.

#### 5-5. MAIN TUNING DIAL

The main tuning dial should normally give no trouble. If, however, the dial should become removed from the receiver it must NOT be operated until mounted on the capacitor shaft WITH SET-SCREWS TIGHT. This is because the dial is only designed to rotate for ten revolutions (0 to 500) and if turned farther than this the mechanism will be damaged. When mounted on the capacitor, limit stops protect the dial provided the assembly is made properly. The procedure for re-mounting the dial is as follows:

- (a) Place the dial on the capacitor shaft, tighten set-screws and turn the dial counter-clockwise to fully mesh capacitor rotor plates so that the tips of the rotor plates are flush with the edge of the stator plates.
- (b) Loosen set-screws and rotate dial slowly until the dial reading has decreased to zero.
- (c) Tighten the set-screws.
- (d) Check position of rotor plates at zero. The tips of the rotor plates must be flush with the edge of the stator plates. A slight adjustment may be necessary and this is done by loosening the set-screws, adjusting the position of the dial and tightening the set-screws again.

If it is necessary to remove the dial at any future time, turn to 250 before removing the dial



and do not disturb the setting of either the dial or capacitor until reassembled. If in doubt about the correct position, inspect the springs on the back of the dial. When the dial reads 250 these springs should be straight-up-and-down, they must not be tipped to one side.

It is important that the backplate and dial do not become separated. The backplate is held in place by two springs so that its gear teeth mesh with the dial gear teeth in correct relationship for proper dial operation. If this backplate should be sprung out of place, it may return to an incorrect position and the proper dial numbers will not appear in the windows when the dial is used. To ascertain that the two parts are in correct position proceed as follows:

- (a) Locate small window near outer periphery of dial backplate and also locate dial number window on face of dial which is  $180^\circ$  removed from the small backplate window.
- (b) Hold dial so backplate lies flat in palm of left-hand and with right hand rotate dial knob until 250 appears in previously located dial window.
- (c) If dial is properly adjusted it will be noted that the pointer at the outer edge of the small window lines up with a marked tooth on the dial itself. It will be found that the dial and backplate can be moved so that the backplate pointer will mesh between teeth at points equidistant from marked tooth in either direction.
- (d) If by checking as in paragraph (c) the dial is found not properly adjusted, it will be necessary to separate the backplate from the dial far enough to bring the two gears out of mesh and then re-mesh the two parts until the proper setting is found. A number of trial settings may be required before the correct mesh is found.

#### 5-6. SLIDE-RULE TUNING DIAL


The slide-rule tuning dial assembly has been adjusted at the factory for accurate synchronization with the micrometer dial. If not tampered with this mechanism will provide complete freedom of mechanical trouble over a long period of continuous use. It is driven by an anti-backlash tuning gear ganged with the main tuning dial. The slide-rule dial pointer is controlled by a string-drive assembly.

If replacement of the string-drive cord is required it will be necessary to remove the receiver chassis from its cabinet or wraparound. Before removing the micrometer dial reference should be made to Paragraph 5 of this section for proper method of removal. Figure Number 9 illustrates the proper method of replacing the cord. After the cord has been replaced and before the receiver is returned to its cabinet the micrometer dial should temporarily be replaced (See Paragraph 5-5) and the slide-rule pointer correctly set in the following manner:

#### NOTE

This procedure may also be used if a check is desired to assure that the slide-rule dial pointer is properly synchronized with that of the main tuning dial.

- (a) Check the main tuning dial at zero on its dial scale. The tips of the rotor plates should be flush with the edge of the stator plates.
- (b) Set the Band Selector control so that the D coil set scale appears.
- (c) Set the main tuning dial at 490 on its dial scale. Correct setting of the slide-rule dial pointer is 4 megacycles on the dial scale. Draw the slide-rule pointer along the cord to its proper position being careful not to disturb the setting of the micrometer dial. After the correct setting has been obtained use a small amount of glyptol or household cement to fasten the dial pointer securely in place on the cord.



NOTE: CORD SHOWN EXPOSED FOR CLARITY  
CORD LENGTH 33 7/8" INCLUDING  
SPRING AND CLIP

Figure No. 9. Instructions for Dial Cord Replacement

PARTS LIST

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
CAPACITORS			
C-1	T-1 Bandsread Padder used on A, B, C, D coil sets	Mica, variable, 3.5 - 35 mmf	D832-2
C-2	T-1 General Coverage Trimmer used on B, C, F, H, J, AA, AB, AC coil sets	Variable, air dielectric	
C-3	T-1 Bandsread Trimmer used on A, B, C, D coil sets	Variable, air dielectric	
C-4	Antenna Trimmer	Variable, air dielectric	SA:6577
C-5	Main Tuning	Four section ganged	SA:6592
C-5A	V-1 Tuning	Air dielectric, 225 mmf. max.	
C-5B	V-2 Tuning	Air dielectric, 225 mmf. max.	
C-5C	V-3 Tuning	Air dielectric, 225 mmf. max.	
C-5D	V-4 Tuning	Air dielectric, 225 mmf. max.	
C-6	V-1 Grid Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-7	Not Used		
C-8	V-1 Grid Filter	Mica, .01 mfd. 300 vdcw	J666-56
C-9	V-1 Cathode Bypass	Paper, .1 mfd. 400 vdcw	D827-12
C-10	V-1 Screen Bypass	Ceramic, .005 mfd. 450 vdcw	K946-1
C-11	V-1 Screen Bypass	Paper, .1 mfd. 400 vdcw	D827-12
C-12	V-1 Plate Filter	Paper, .1 mfd. 600 vdcw	D827-13
C-13	V-2 Grid Return Bypass	Ceramic, .005 mfd. 450 vdcw	K946-1

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
CAPACITORS (CONT'D)			
C-14	T-2 Bandsread Padder used on A, B, C, D coil sets	Mica, variable, 3.5 - 35 mmf.	D832-2
C-15	T-2 General Coverage Trimmer used on all coil sets	Variable, air dielectric	
C-16	T-2 Bandsread Trimmer used on A, B, C, D coil sets	Variable, air dielectric	
C-17	V-2 Cathode Bypass	Paper, .1 mfd. 400 vdcw	D827-12
C-18	V-2 Screen Bypass	Ceramic, .005 mfd. 450 vdcw	K946-1
C-19	V-2 Plate Filter	Paper, .1 mfd. 600 vdcw	D827-13
C-20	T-3 Bandsread Padder used on A, B, C, D coil sets	Mica, variable, 3.5 - 35 mmf.	D832-2
C-21	T-3 General Coverage Trimmer used on all coil sets	Variable, air dielectric	
C-22	T-3 Bandsread Trimmer used on A, B, C, D coil sets	Variable, air dielectric	
C-23	V-3 Cathode Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2
C-24	V-3 Screen Bypass	Paper, .1 mfd. 400 vdcw	D827-12
C-25	T-4 Bandsread Padder used on A, B, C, D coil sets	Variable, air dielectric	
C-26	T-4 General Coverage Trimmer used on all coil sets	Variable, air dielectric	
C-27	T-4 Bandsread Trimmer used on A, B, C, D coil sets	Variable, air dielectric	
C-28	T-4 General Coverage Padder:		
	A coil set	Mica, .0012 mfd. 300 vdcw	J666-63
	B coil set	Mica, .003 mfd. 500 vdcw	J666-30
	C coil set	Mica, .0016 mfd. 500 vdcw	J666-21
	D coil set	Mica, .0009 mfd. 500 vdcw	J666-62
	E coil set	Mica, 470 mmf. 500 vdcw	H500-18
	F coil set	Mica, 330 mmf. 500 vdcw	H500-22
	G coil set	Ceramic, 100 mmf. 500 vdcw	D825C-304
	J coil set	Ceramic, 50 mmf. 500 vdcw	D825D-417
	AA coil set	Ceramic, 10 mmf. 500 vdcw	D825D-402
	AB coil set	Ceramic, 120 mmf. 500 vdcw	D825C-340
C-29	Osc. Trimmer	Variable, air dielectric	
C-30	V-4 Grid	Ceramic, 100 mmf. 500 vdcw	D825D-421
C-31	V-4 Plate	Paper, .1 mfd. 400 vdcw	D827-12
C-32	V-4 to V-3 coupling	Mica, .01 mfd. 300 vdcw	J666-56
C-33	T-5 Primary Trimmer	Variable, air dielectric	
C-34	Bridge Balancing	Ceramic, 62 mmf. 500 vdcw	J695-3
C-35	Bridge Balancing	Ceramic, 47 mmf. 500 vdcw	J695-1
C-36	Phasing Balance Adjustment	Mica, variable, 3.5 - 35 mmf.	D832-2
C-37	Phasing Control	Variable, air dielectric	SA:3655
C-38	Selectivity Compensator	Mica, variable, 3.5 - 35 mmf.	D832-2
C-39	T-5 Output adjustment	Variable, air dielectric	SA:1841
C-40	Selectivity Adjusting	Ceramic, 5 mmf. 500 vdcw	D825D-401
C-41	Selectivity Adjusting	Ceramic, 10 mmf. 500 vdcw	D825D-426
C-42	Selectivity Adjusting	Ceramic, 10 mmf. 500 vdcw	D825D-426
C-43	V-5 A.V.C. Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-44	V-5 Cathode Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
CAPACITORS (CONT'D)			
C-45	L-2 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-46	L-3 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-47	L-4 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-48	L-5 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-49	V-6 A.V.C. Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-50	V-6 Cathode Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2
C-51	V-6 Screen Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2
C-52	V-6 Plate Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-53	V-7 Load	Ceramic, 270 mmf. 500 vdcw	J633-2
C-54	V-7 Coupling	Ceramic, 100 mmf. 500 vdcw	DB25D-421
C-55	A.V.C. Filter	Paper, .01 mfd. 600 vdcw	DB27-7
C-56	V-9 to V-7 Coupling	Ceramic, 3 mmf. 500 vdcw	J695-4
C-57	V-9 Screen Bypass	Mica, .01 mfd. 300 vdcw	J666-56
C-58	C.W. Osc. Control	Variable, air dielectric	SA:6580
C-59	V-9 Grid	Mica, .001 mfd. 500 vdcw	J666-14
C-60	T-9 Fixed Tuning	Ceramic, 100 mmf. 500 vdcw	DB25C-304
C-61	T-9 Tuning	Variable, air dielectric	
C-62	D.C. Bypass	Paper, .01 mfd. 600 vdcw	DB27-7
C-63	A.C. Line Bypass	Mica, .01 mfd. 300 vdcw	J666-56
C-64	A.C. Line Bypass	Mica, .01 mfd. 300 vdcw	J666-56
C-65	Power Supply Filter	Electrolytic, 40 + 40 mfd. 475 vdcw	K945-3
C-65A	Power Supply Input Filter	Part of C-65	
C-65B	Power Supply Output Filter	Part of C-65	
C-66	V-7 to V-10 Coupling	Paper, .01 mfd. 600 vdcw	DB27-7
C-67	V-10 Threshold Filter	Paper, .1 mfd. 400 vdcw	DB27-12
C-68	V-10 Plate Filter	Paper, .1 mfd. 400 vdcw	DB27-12
C-69	V-10 to X-3 Coupling	Paper, .01 mfd. 600 vdcw	DB27-7
C-70	Tone Compensator	Electrolytic, 25 mfd. 50 vdcw	E338-4
C-71	V-11 Cathode Bypass	Paper, .5 mfd. 100 vdcw	DB27-49
C-72	V-11 Screen Bypass	Paper, .1 mfd. 400 vdcw	DB27-12
C-73	V-11 Plate Filter	Paper, .1 mfd. 400 vdcw	DB27-12
C-74	Tone	Paper, .01 mfd. 600 vdcw	DB27-7
C-75	V-8B to V-11 Coupling	Paper, .01 mfd. 600 vdcw	DB27-7
C-76	V-8B Grid	Ceramic, 100 mmf. 500 vdcw	DB25D-421
C-77	V-8B to V-12 Coupling	Paper, .01 mfd. 600 vdcw	DB27-7
C-78	V-8B to V-13 Coupling	Paper, .01 mfd. 600 vdcw	DB27-7
C-79	V-12 and V-13 Cathode Bypass	Electrolytic, 25 mfd. 50 vdcw	E338-4
C-80	Tone Compensator	Mica, .0024 mfd. 1000 vdcw	J667-68
C-81	Temperature Drift Compensator	Ceramic, 5 mmf. 500 vdcw	H872-3
C-82	T-1 Fixed Bandspread Padder:	Ceramic	
	A coil set	12 mmf. 500 vdcw	DB25D-404
	B coil set	5 mmf. 500 vdcw	DB25D-401
	C coil set	12 mmf. 500 vdcw	DB25D-404
	D coil set	25.7 mmf. 500 vdcw	DB25D-412
C-83	T-2 Fixed Bandspread Padder:	Ceramic	
	A coil set	21 mmf. 500 vdcw	DB25D-410
	B coil set	5 mmf. 500 vdcw	DB25D-401
	C coil set	12 mmf. 500 vdcw	DB25D-404
	D coil set	25.7 mmf. 500 vdcw	DB25D-412

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
C-84	T-3 Fixed Bandsread Padder: A coil set B coil set C coil set D coil set	Ceramic 21 mmf. 500 vdcw 5 mmf. 500 vdcw 12 mmf. 500 vdcw 25.7 mmf. 500 vdcw	D825D-410 D825D-401 D825D-404 D825D-412
C-85	T-4 Bandsread Padder used on A coil set	Ceramic, 10 mmf. 500 vdcw	D825D-437
C-86	T-4 Fixed Divider used on D coil set	Ceramic, 21 mmf. 500 vdcw	D825D-410
C-87	T-4 Fixed General Coverage Trimmer: A coil set B coil set AA coil set AB coil set AC coil set	Ceramic 20 mmf. 500 vdcw 5 mmf. 500 vdcw 10 mmf. 500 vdcw 35 mmf. 500 vdcw 68 mmf. 500 vdcw	D825D-446 D825D-440 D825D-402 D825D-413 D825D-439
C-88	T-1 Fixed General Coverage Padder: A coil set AB coil set	Mica, 1200 mmf. 500 vdcw Ceramic, 120 mmf. 500 vdcw	J666-16 D825C-305
C-89	T-4 Fixed Temperature Compensator: B coil set A coil set	Ceramic 5 mmf. 500 vdcw 5 mmf. 500 vdcw	D825D-440 D825D-440
C-90	T-2 Primary Trimmer used on H coil set	Ceramic, 21 mmf. 500 vdcw	D825D-410
C-91	T-1 General Coverage Trimmer: AA coil set AB coil set AC coil set	Ceramic 5 mmf. 500 vdcw 21 mmf. 500 vdcw 50 mmf. 500 vdcw	D825D-401 D825D-410 D825D-417
C-92	T-2 coupling used on AB coil set	Mica, 470 mmf. 500 vdcw	J665-56
C-93	T-2 General Coverage Padder used on AB coil set	Ceramic, 100 mmf. 500 vdcw	D825C-304
C-94	T-3 Coupling used on AB coil set	Mica, 470 mmf. 500 vdcw	J665-56
C-95	T-3 General Coverage Trimmer: AB coil set AC coil set	Ceramic, 10 mmf. 500 vdcw Ceramic, 68 mmf. 500 vdcw	D825D-402 D825D-429
C-96	V-2 Cathode Bypass	Ceramic, .005 mfd. 450 vdcw	K946-1
C-97	T-1 General Coverage Padder used on AA, AB and AC coil sets	Variable, air dielectric	
C-98	T-2 General Coverage Padder used on AA and AB coil sets	Variable, air dielectric	
C-99	T-3 General Coverage Padder used on AA, AB and AC coil sets	Variable, air dielectric	
C-100	T-4 General Coverage Padder used on E, F, G, H, J and AA, AB, AC coil sets	Variable, air dielectric	
C-101	T-3 General Coverage Padder used on AB coil set	Ceramic, 100 mmf. 500 vdcw	D825C-304
C-102	T-2 General Coverage Trimmer: AC coil sets AB coil sets	Ceramic 68 mmf. 500 vdcw 10 mmf. 500 vdcw	D825D-439 D825D-402
C-103	I.F. coupling to X-1	Ceramic, 100 mmf. 500 vdcw	D825D-402



## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
CAPACITORS (CONT'D)			
C-104	T-4 General Coverage Padder used on A coil set	Ceramic, 20 mmf. 500 vdcw	D8250-446
C-105	V-5 Plate Filter	Paper, .25 mfd. 600 vdcw	D827-19
C-106	L-8 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-107	L-9 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-108	V-16 AVC Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-109	V-16 Cathode Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2
C-110	R.F. Filter	Paper, .25 mfd. 200 vdcw	D827-15
C-111	V-16 Screen	Ceramic, .01 mfd. 450 vdcw	K946-2
C-112	V-16 Plate Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-113	L-10 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-114	L-11 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-115	L-12 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-116	L-13 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-117	V-2 Plate Filter	Ceramic, .005 mfd. 450 vdcw	K946-1
C-118	V-15 Plate Filter	Paper, .1 mfd. 600 vdcw	D827-13
C-119	Osc. Padder	Ceramic, 10 mmf. 500 vdcw	D8250-437
C-120	L-6 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-121	L-7 Tuning	Mica, 510 mmf. 500 vdcw	H500-5
C-122	V-5 Screen Bypass	Ceramic, .01 mfd. 450 vdcw	K946-2
C-123	V-3 Plate Filter	Ceramic, .01 mfd. 450 vdcw	K946-2
C-124	V-5 Screen Bypass	Paper, .1 mfd. 400 vdcw	D827-12
RESISTORS			
R-1	V-1 Grid Filter	Fixed, 470,000 ohms, 1/2 W	J569-57
R-2	V-1 Cathode	Fixed, 100 ohms, 1/2 W	J569-13
R-3	V-1 and V-2 Screen	Fixed, 2,200 ohms, 1/2 W	J569-29
R-4	V-2 Grid	Fixed, 470,000 ohms, 1/2 W	J569-57
R-5	V-2 Cathode	Fixed, 560 ohms, 1/2 W	J569-22
R-6	RF Gain Control	Variable, W.W. 10,000 ohms	K349-3
R-7	V-3 Injector Grid	Fixed, 22,000 ohms, 1/2 W	J569-41
R-8	V-3 Cathode	Fixed, 220 ohms, 1/2 W	J569-17
R-9	V-3 Screen	Fixed, 33,000 ohms, 1 W	J571-43
R-10	V-4 Grid	Fixed, 22,000 ohms, 1/2 W	J569-41
R-11	V-4 Plate	Fixed, 22 ohms, 1/2 W	J569-5
R-12	V-5 Grid Filter	Fixed, 470,000 ohms, 1/2 W	J569-57
R-13	V-1, V-2, V-5 Screen Bleeder	Fixed, 27,000 ohms, 2 W	J572-42
R-14	V-5 Cathode	Fixed, 220 ohms, 1/2 W	J569-17
R-15	V-5 Cathode	Fixed, 330/1000 ohms, 1/2 W	
R-16	V-1, V-2, V-5 Screen Dropping	Fixed, 15,000 ohms, 2 W	J572-39
R-17	V-5 Plate Filter	Fixed, 2,200 ohms, 1/2 W	J569-29
R-18	V-6 Grid Filter	Fixed, 470,000 ohms, 1/2 W	J569-57
R-19	V-6 Cathode	Fixed, 68 ohms, 1/2 W	J569-11
R-20	V-8A Plate Load	Fixed, 47,000 ohms, 1/2 W	J569-45
R-21	*S* Meter Zero Adjustment	Variable, W.W. 1000 ohms, 1 W	D831-2
R-22	V-7 Plate Load	Fixed, 1.5 meg. 1/2 W	J569-63
R-23	AVC Filter	Fixed, 1.5 meg. 1/2 W	J569-63
R-24	V-9 Plate	Fixed, 220,000 ohms, 1/2 W	J569-53
R-25	V-9 Screen Filter	Fixed, 100,000 ohms, 1/2 W	J569-49
R-26	V-9 Screen Bleeder	Fixed, 100,000 ohms, 1/2 W	J569-49
R-27	V-9 Grid	Fixed, 47,000 ohms, 1/2 W	J569-45
R-28	Dimmer Control	Variable, W.W. 25 ohms	K915-13

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
RESISTORS (CONT'D)			
R-29	V-7 Filament Dropping	Fixed, 4.3 ohms, 1 W	K098-48
R-30	V-10 Filament Dropping	Fixed, 4.3 ohms, 1 W	K098-48
R-31	V-14 Dropping	Fixed, 5,000 ohms, 10 W	E959-10
R-32	V-7 Load	Fixed, 22,000 ohms, 1/2 W	J569-41
R-33	V-7 Load	Fixed, 470,000 ohms, 1/2 W	J569-57
R-34	V-10 Plate	Fixed, 220,000 ohms, 1/2 W	J569-53
R-35	V-10 Cathode	Fixed, 220,000 ohms, 1/2 W	J569-53
R-36	Limiter Threshold control	Variable, 500,000 ohms	J681-2
R-37	Limiter Threshold Filter	Fixed, 220,000 ohms, 1/2 W	J569-53
R-38	Limiter Plate Filter	Fixed, 820,000 ohms, 1/2 W	J569-60
R-39	V-10 Plate Load	Fixed, 470,000 ohms, 1/2 W	J569-57
R-40	Audio Gain Control	Variable, 500,000 ohms	K347-1
R-41	Limiter Output Divider	Fixed, 220,000 ohms, 1/2 W	J569-53
R-42	V-11 Cathode	Fixed, 2200 ohms, 1/2 W	J569-29
R-43	V-11 Cathode Divider	Fixed, 150 ohms, 1/2 W	J569-15
R-44	Degeneration Feedback	Fixed, 6800 ohms, 1/2 W	J569-35
R-45	V-11 Screen Filter	Fixed, 470,000 ohms, 1/2 W	J569-57
R-46	V-11 Plate Load	Fixed, 100,000 ohms, 1/2 W	J569-49
R-47	V-11 Plate Filter	Fixed, 47,000 ohms, 1/2 W	J569-45
R-48	Tone control	Variable, 500,000 ohms	K347-1
R-49	V-88 Grid	Fixed, 220,000 ohms, 1/2 W	J569-53
R-50	V-88 Cathode Bias	Fixed, 4700 ohms, 1/2 W	J569-33
R-51	V-88 Cathode Load	Fixed, 47,000 ohms, 1/2 W	J569-45
R-52	V-88 Plate Load	Fixed, 47,000 ohms, 1/2 W	J569-45
R-53	V-13 Grid	Fixed, 220,000 ohms, 1/2 W	J569-53
R-54	V-12 Grid	Fixed, 220,000 ohms, 1/2 W	J569-53
R-55	V-12 and V-13 Cathode Bias	Fixed, 220 ohms, 2 W	J572-17
R-56	Output Load	Fixed, 470 ohms, 2 W	J572-21
R-57	T-1 Ant. Load used on A coil set	Fixed, 22 ohms, 1/2 W	J569-5
R-58	V-6 Screen Dropping	Fixed, 47,000 ohms, 1/2 W	J569-45
R-59	V-16 AVC Filter	Fixed, 470,000 ohms, 1/2 W	J569-57
R-60	V-16 Cathode	Fixed 68 ohms, 1/2 W	J569-11
R-61	V-16 Screen Dropping	Fixed, 47,000 ohms, 1/2 W	J569-45
R-62	V-16 Plate Filter	Fixed, 2200 ohms, 1/2 W	J569-29
MISCELLANEOUS			
E-1	Antenna Input Terminal	Screw type, three terminals	E261-3
E-2	B+ Switch Terminal	Screw type, two terminals	E265-19
E-3	Audio Output Terminal	Screw type, three terminals	E259-2
F-1	Fuse 3AG	2 Amps at 250 V	F135-4
I-1	Dial Lamp	#47	F136-6
I-2	Dial Lamp	#47	F136-6
I-3	"S" Meter Lamp	#47	F136-6
J-1	Phono Jack	Single Circuit	J993-1
J-2	Phone Jack	Multi-Circuit	F316-1

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
MISCELLANEOUS (CONT'D)			
L-1	Filter Choke	17 Henries	SA:1694
L-2	T-6 Tuning	Variable iron-core inductor	SA:3906
L-3	T-6 Tuning	Variable iron-core inductor	SA:3366
L-4	T-6 Tuning	Variable iron-core inductor	SA:3905
L-5	T-6 Tuning	Variable iron-core inductor	SA:3366
L-6	T-7 Tuning	Variable iron-core inductor	SA:3905
L-7	T-7 Tuning	Variable iron-core inductor	SA:3366
L-8	T-7 Tuning	Variable iron-core inductor	SA:3905
L-9	T-7 Tuning	Variable iron-core inductor	SA:3366
L-10	T-8 Tuning	Variable iron-core inductor	SA:3905
L-11	T-8 Tuning	Variable iron-core inductor	SA:8951
L-12	T-8 Tuning	Variable iron-core inductor	SA:3905
L-13	T-8 Tuning	Variable iron-core inductor	SA:8951
L-14	T-6 Coupling	R.F. choke, 1.1 uh.	SA:6072
L-15	T-7 Coupling	R.F. choke, 1.1 uh.	SA:6072
L-16	T-8 Coupling	R.F. choke, 1.1 uh.	SA:8952
M-1	*S* Meter	0-1 ma. W/S scale	J984-5
P-1	Select-0-Ject Plug	Octal	SA:6569
P-2	A.C. Jumper Plug	Octal	SA:3731
S-1	T-1 B.S. - G.C. Switch	Twist Type, Two position	SA:6748
S-2	T-2 B.S. - G.C. Switch	Twist Type, Two position	SA:6749
S-3	T-3 B.S. - G.C. Switch	Twist Type, Two position	SA:6749
S-4	T-4 B.S. - G.C. Switch	Twist Type, Two position	SA:6749
S-5	Selectivity Switch	Six Position, Double Pole	E195-3
S-6	A.V.C. ON-OFF switch	SPST Bat Handle, Toggle	E230-2
S-7	Control Switch	Double-Wafer, four-position	SA:6564
S-8	Calibrator Switch	DPDT Bat Handle, Toggle center position open	P738-1
S-9	A.C. Line Switch	Part of R-40	
S-10	T-10 Primary Selector Switch	DPDT, Toggle	H340-4
S-11	B+ Switch	SPST, Bat Handle, Toggle	E230-2
T-1	First R.F. Amplifier Transformer		
	A Band	14.0 - 30 Mc.	SA:6654
	B Band	7.0 - 14.4 Mc.	SA:6755
	C Band	3.5 - 7.3 Mc.	SA:6759
	D Band	1.7 - 4.0 Mc.	SA:6635
	E Band	900 - 2050 Kc.	SA:6513
	F Band	480 - 960 Kc.	SA:6660
	G Band	180 - 430 Kc.	SA:6665
	H Band	100 - 200 Kc.	SA:6803
	J Band	50 - 100 Kc.	SA:6806
	AA Band	27 - 30 Mc.	SA:6814
	AB Band	25 - 35 Mc.	SA:6675
	AC Band	21 - 21.5 Mc.	SA:8073
T-2	Second R.F. Amplifier Transformer		
	A Band	14.0 - 30 Mc.	SA:6751
	B Band	7.0 - 14.4 Mc.	SA:6650
	C Band	3.5 - 7.3 Mc.	SA:6641
	D Band	1.7 - 4.0 Mc.	SA:6637

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
MISCELLANEOUS (CONT'D)			
T-2	Cont'd		
	E Band	900 - 2050 Kc.	SA:6540
	F Band	480 - 960 Kc.	SA:6662
	G Band	180 - 430 Kc.	SA:6667
	H Band	100 - 200 Kc.	SA:6669
	J Band	50 - 100 Kc.	SA:6809
	AA Band	27 - 30 Mc.	SA:6673
	AB Band	25 - 35 Mc.	SA:6818
	AC Band	21 - 21.5 Mc.	SA:8074
T-3	Mixer Transformer		
	A Band	14.0 - 30 Mc.	SA:6752
	B Band	7.0 - 14.4 Mc.	SA:6756
	C Band	3.5 - 7.3 Mc.	SA:6642
	D Band	1.7 - 4.0 Mc.	SA:6638
	E Band	900 - 2050 Kc.	SA:6789
	F Band	480 - 960 Kc.	SA:6794
	G Band	180 - 430 Kc.	SA:6800
	H Band	100 - 200 Kc.	SA:6804
	J Band	50 - 100 Kc.	SA:6810
	AA Band	27 - 30 Mc.	SA:6815
	AB Band	25 - 35 Mc.	SA:6676
	AC Band	21 - 21.5 Mc.	SA:8075
T-4	H.F. Oscillator Transformer		
	A Band	14.0 - 30 Mc.	SA:6656
	B Band	7.0 - 14.4 Mc.	SA:6678
	C Band	3.5 - 7.3 Mc.	SA:6760
	D Band	1.7 - 4.0 Mc.	SA:6776
	E Band	900 - 2050 Kc.	SA:6631
	F Band	480 - 960 Kc.	SA:6795
	G Band	180 - 430 Kc.	SA:6785
	H Band	100 - 200 Kc.	SA:6805
	J Band	50 - 100 Kc.	SA:6811
	AA Band	27 - 30 Mc.	SA:6816
	AB Band	25 - 35 Mc.	SA:6819
	AC Band	21 - 21.5 Mc.	SA:8076
T-5	Crystal Filter	455 kc.	SA:3654
T-6	2nd. I.F. Amp. Transformer	455 kc.	SA:8448
T-7	3rd. I.F. Transformer	455 kc.	SA:8448
T-8	Det. Input Transformer	455 kc.	SA:8948
T-9	C.W. Osc. Transformer	455 kc.	SA:3361
T-10	Audio Output Transformer	Pri. 10,000 ohms Sec. 8/600 ohms 10 watts	P187-1
T-11	Power Transformer	Primary: #4 and #5, 115 volts #4 and #7, 230 volts Secondary: #1 and #3, 6.3 V at 6.5 A. Secondary: #8, #9 and #10, 275-0-275 V. Secondary: #11 and #12, 5 V. at 2 A. #2 electrostatic shield	SA:6566
V-1	First R.F. Amplifier	68A6	
V 2	Second R.F. Amplifier	68A6	

## PARTS LIST (CONT'D)

SYMBOL	FUNCTION	DESCRIPTION	DRAWING NO.
MISCELLANEOUS (CONT'D)			
V-3	Mixer	6BE6	
V-4	H.F. Oscillator	6C4	
V-5	First I.F. Amplifier	6X7	
V-6	Second I.F. Amplifier	6SG7	
V-7	Second Detector and A.V.C.	6H6	
V-8A	*S* Meter Amplifier	1/2 6SN7GT	
V-8B	Phase Inverter	1/2 6SN7GT	
V-9	C.W. Oscillator	6J7	
V-10	Noise Limiter	6H6	
V-11	Audio Amplifier	6SJ7	
V-12	Audio Output	6V6GT	
V-13	Audio Output	6V6GT	
V-14	Voltage Regulator	0B2	
V-15	Rectifier	5V4G	
V-16	Third I.F. Amplifier	6SG7	
X-1	Accessory Connector Socket	Octal	J625-2
X-2	Crystal Calibrator Socket	Octal	J625-2
X-3	Select-O-Ject Socket	Octal	J625-2
Y-1	Crystal Resonator	Quartz, 455 kc.	E979-1



## PARTS LIST (CONT'D)

DESCRIPTION	NAT. CO. TYPE	DESCRIPTION	NAT. CO. TYPE
MECHANICAL PARTS		MECHANICAL PARTS (CONT'D)	
Flexible coupling on Control switch shaft	SA:22	Tension spring for above stop	P471-1
Flexible coupling on C.W.O. control shaft	SA:22	Dial light socket (2)	SA:6600
Knurled nut to mount Calibrate Switch	Q163-2	Dial scale drum assembly (no scales included)	SA:7922
Knurled nut to mount B+ and AVC switches (2)	J703-2	Dial scale for Band A	P136-1
Knurled nut to mount phones jack	J704-2	Dial scale for Band B	P136-2
Knob for Tone control, Ant. trimmer and Dimmer controls	SA:7021	Dial scale for Band C	P136-3
Main Tuning dial control knob	SA:6586	Dial scale for Band D	P136-4
Spring washer to ground main tuning knob	L087-1	Dial scale for Band A (bandspread calibration only)	P136-5
Shaft extension for Selectivity switch	SA:3664	Dial scale for Band B (bandspread calibration only)	P136-6
Coupling on phasing control shaft	D694-2	Dial scale for Band C (bandspread calibration only)	P136-7
Set screws for mounting above coupling (4)	G879-2	Dial scale for Band D (bandspread calibration only)	P136-8
Shaft extension for Phasing control	C696-4	Dial scale for Band E-F	P136-9
Cast aluminum hub on main tuning capacitor shaft	SA:8800	Dial scale for Band G-H	P136-10
Window for dial scales	P211-1	Dial scale for Band J	P136-11
Bracket for dial scale window	P539-1	Dial scale for Band AA	P136-12
Base plate for mounting tuning capacitor	SA:6581	Dial scale for Band AB	P136-13
Spacer plate between base plate and tuning capacitor	P106-1	Dial scale for Band AC	P136-14
Triangular bracket for main tuning capacitor shaft	SA:6582	End bearing for main tuning capacitor rotor shaft	SA:2127
Dial drum supporting assembly (includes pointer, pointer rail, pulleys and drum positioning spring)	SA:6594	Ceramic brush insulators on main tuning capacitor (4)	D679-1
Drum positioning spring	P131-1	Ceramic brush insulator with cutaway surface (5)	D680-1
Gear assembly for driving dial pointer (includes pulley and gears)	SA:6595	Rotor brush (5)	SA:8675
Loading spring for above gears (2)	P216-1	Worm for driving main tuning capacitor	M939-2
Bearing for pulley	P226-1	Worm loading spring	Q544-1
Washer to mount pulley and bearing to dial drum supporting assembly	M953-2	Ball bearing used with worm loading spring	F150-2
Spring washer to position pulley and gears	J728-7	Spring thrust collar used with worm loading spring	P112-1
Shaft, for rotating dial scale drum	P221-2	Coil set levers	SA:7001
Rubber "O" ring on above shaft	L792-3	Nut to mount coil set levers (2)	P207-2
Retaining washer on above shaft	E229-3	Coil set brush board (4)	SA:6575
Snap ring on above shaft	L936-1	Fibre washer for mounting brush-board (16)	E181-3
Dial cord	SA:6596	Bakelite slide for coil sets (2)	D393-1
Spring to maintain tension on dial cord	P223-1	Shield cap for type 6K7 and 6J7 tubes (2)	E726-1
Dial scale drum stop, mounted on Osc. control shaft	P472-1	Shield for miniature tubes (3)	SA:3387
		Shield base for miniature tubes (3)	SA:3847
		Socket for miniature tubes (5)	SA:4916
		Fibre washer for mounting miniature sockets (10)	H285-2
		Octal tube sockets (15)	J625-2
		Spring clamp for type 6C4 tube	L532-3
		Spring clamp for type 0B2 tube	L532-2

## PARTS LIST (CONT'D)

DESCRIPTION	NAT. CO. TYPE	DESCRIPTION	NAT. CO. TYPE
MECHANICAL PARTS (CONT'D)		MECHANICAL PARTS USED ON TABLE MODEL ONLY	
Nut for mounting miniature sockets	B111-2	Chassis mounting angle bracket (left)	P244-1
Ceramic standoff insulated terminals (2) (one top of chassis one on bottom of chassis)	B425-1	Chassis mounting angle bracket (right)	P244-2
Insulation between chassis and heat shield	P942-1 (short) P942-2 (long)	National Co. insignia	J791-4
Heat shield (with grommets and lugs)	SA:6563	Rubber mounting foot (4)	K499-1
Plate, heat shield	P202-1	S-Meter bracket	J970-2
R.F. Gain control knob	SA:6867	Band or Osc. control knob (2)	SA:7021
Phasing and C.W.O. control knob (2)	SA:6868	Cover hinge (2)	J825-2
Selectivity control knob	SA:6869	Cover stop angle (2)	K788-1
Limiter control knob	SA:6870	Socket assembly for S-Meter lamp	K377-4
CW - AM - NFM - Phono switch knob	SA:6587	Cabinet wraparound	SA:8663
A.F. Gain control knob	SA:6871	Cabinet back	SA:8664
End bearing for main tuning capacitor	SA:8669	Cabinet cover	J701-8
Cover, gear housing	C898-4	Cabinet bottom	SA:6588
1/4" length of rubber tubing on capacitor stop	F234-2	MECHANICAL PARTS USED ON RACK MODEL ONLY	
Stop washer (10)	P149-3	Front panel	SA:8716
Stop	Q543-1	Blister for front panel	SA:6765
Spacer, stop	Q541-1	Side plate (left)	P302-1
Spring washer in stop	J728-4	Side plate (right)	P302-3
Stop washer	P149-4	National Co. insignia	J791-3
Collar in stop with set screws	Q542-2	Band control knob	SA:7470
Set screws in above	G879-4 G879-2	Osc. control knob	SA:7469
Balls in capacitor bearing (6)	H613-3	Dust cover	SA:8717
C.W.O. shaft	Q534-1	Thumb screw for dust cover (2)	L309-2
Washer on above	O802-4		
Retaining ring on above	Q102-1		
Bracket from chassis to dial support plate	Q538-1		




Figure No. 10A. Resistor Locations, Bottom View of Receiver




Figure No. 108. Capacitor and Miscellaneous Component Locations, Bottom View of Receiver

Note: coil sets shown in gen. con. position




Figure No. 11. Schematic Diagrams, Coil Sets A, B, C, D, E and F



180-130  
KC

100-200  
KC

50-100  
KC

27.5-30

25-35

21-21.5




Figure No. 12. Schematic Diagram, Coil Sets AA, AB, AC, G, H and J




Figure No. 13. Schematic Diagram, HRD-50-1 Radio Receiver