

## F3/F320/F1020/F4TR Radio Versions

### F3/F3S

Radio	Band	Version
F3-2	146 – 174 W	26
F3-3	136 – 150 N	27
F3-4	146 – 174 N	28

### F1020

Radio	Band	Model
F1020-2	146 – 174 WN	52

### F4/F4S

Radio	Band	Version
F4-1	400 – 430 N	25
F4-2	440 – 470 N	26
F4-3	400 – 430 W	27
F4-4	440 – 470 W	28
F4-5	470 – 500 N	33
F4-6	490 – 512 N	36

### F2020

Radio	Band	Version
F2020-2	450 – 470 WN	52
F2020-3	470 – 490 WN	53

### F320S

Radio	Band	Version
F320-5	135 – 155 WN	01
F320-6	146 – 174 WN	02

### F4TR

Radio	Band	Version
F4TR-1	450 – 490 WN	01, 11
F4TR-2	400 – 430 WN	02, 12
F4TR-3	480 – 512 WN	03, 13

### F320

Radio	Band	Version
F320-5	135 – 155 WN	53
F320-6	146 – 174 WN	54

### F420S

Radio	Band	Version
F420-10	450 – 470 WN	02

### F420

Radio	Band	Version
F420-9	400 – 430 WN	55
F420-10	450 – 470 WN	56
F420-11	470 – 490 WN	57
F420-12	490 – 512 WN	58