

DockSide Radio

Icom M803

User Group Channel / Memory Map

Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label	Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label
1	4125.0	4125.0	USB	Distress Working	41	2052.1	---	USB	WXFAX AK
2	6215.0	6215.0	USB	Distress Working	42	4296.1	---	USB	WXFAX AK
3	8291.0	8291.0	USB	Distress Working	43	8457.1	---	USB	WXFAX AK
4	12290.0	12290.0	USB	Distress Working	44	12410.6	---	USB	WXFAX AK
5	16420.0	16420.0	USB	Distress Working	45	4344.1	---	USB	WXFAX E. Pacific
6	4426.0	4134.0	USB	USCG 424	46	8680.1	---	USB	WXFAX E. Pacific
7	6501.0	6200.0	USB	USCG 601	47	12784.1	---	USB	WXFAX E. Pacific
8	8764.0	8240.0	USB	USCG 816	48	17149.3	---	USB	WXFAX E. Pacific
9	13089.0	12242.0	USB	USCG 1205	49	22525.1	---	USB	WEFAX E Pacific
10	17314.0	16432.0	USB	USCG 1625	50	9980.6	---	USB	WEFAX HNL
11	Time & Shortwave				51	11088.1	---	USB	WEFAX HNL
12	2500.0	---	USB	WWV 2.5 MHz (Time)	52	16133.1	---	USB	WEFAX HNL
13	5000.0	---	USB	WWV 5 MHz (Time)	53	4233.1	---	USB	WEFAX W Atlantic
14	10000.0	---	USB	WWV 10 MHz (Time)	54	6338.6	---	USB	WEFAX W Atlantic
15	15000.0	---	USB	WWV 15 MHz (Time)	55	9801.1	---	USB	WEFAX W Atlantic
16	20000.0	---	USB	WWV 20 MHz (Time)	56	12748.1	---	USB	WEFAX W Atlantic
17	3300.0	---	USB	CHU 3 MHz (Time)	57	4316.0	---	USB	WEFAX Gulf Mexico
18	7850.0	---	USB	CHU 7 MHz (Time)	58	8502.0	---	USB	WEFAX Gulf Mexico
19	14670.0	---	USB	CHU 14 MHz (Time)	59	12788.0	---	USB	WEFAX Gulf Mexico
20	3200.0	---	USB	90 Meter SW Broadcast	60	17144.5	---	USB	WEFAX Gulf Mexico
21	3950.0	---	USB	75 Meter SW Broadcast	61	4208.5	---	USB	SITOR / Text WX
22	4750.0	---	USB	60 Meter SW Broadcast	62	6312.5	---	USB	SITOR / Text WX
23	5850.0	---	USB	49 Meter SW Broadcast	63	8415.0	---	USB	SITOR / Text WX
24	7100.0	---	USB	41 Meter SW Broadcast	64	12577.5	---	USB	SITOR / Text WX
25	9400.0	---	USB	31 Meter SW Broadcast	65	16805.0	---	USB	SITOR / Text WX
26	11600.0	---	USB	25 Meter SW Broadcast	66	19680.5	---	USB	SITOR / Text WX
27	13570.0	---	USB	22 Meter SW Broadcast	67	13270.0	---	USB	Aviation WX E Coast
28	15100.0	---	USB	19 Meter SW Broadcast	68	13282.0	---	USB	Aviation WX W Coast
29	17480.0	---	USB	16 Meter SW Broadcast	69	Marine Simplex & Nets			
30	18900.0	---	USB	15 Meter SW Broadcast	70	4146.0	4146.0	USB	Ship 4A
31	21450.0	---	USB	13 Meter SW Broadcast	71	4149.0	4149.0	USB	Ship 4B
32	Weather				72	4417.0	4417.0	USB	Ship 4C
33	4316.0	---	USB	Weather - Verbal	73	4003.0	4003.0	USB	Ship 4003
34	4426.0	---	USB	Weather - Verbal	74	4006.0	4006.0	USB	Ship 4006
35	6501.0	---	USB	Weather - Verbal	75	4009.0	4009.0	USB	Ship 4009
36	8502.0	---	USB	Weather - Verbal	76	4012.0	4012.0	USB	Ship 4012
37	8764.0	---	USB	Weather - Verbal	77	4015.0	4015.0	USB	Ship 4015
38	12788.0	---	USB	Weather - Verbal	78	4018.0	4018.0	USB	Ship 4018
39	13089.0	---	USB	Weather - Verbal	79	4021.0	4021.0	USB	Ship 4021
40	17314.0	---	USB	Weather - Verbal	80	4024.0	4024.0	USB	Papagayo Net
Legend:		Green = Transmit OK - Marine Radio License Rqgd.			Brown = Receive only - Entertainment				
DSR database Ver. 01/29/20		Red = Safety comm. - Marine License Required			Violet = Receive only - Time-Propagation-Emergency.				
		Black = Receive - Weather: FAX, SITOR, Voice			Blue = Transmit OK - Amateur Radio License Rqgd.				

DockSide Radio

Icom M803									
User Group Channel / Memory Map									
Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label	Ch N°	Receive Freq.	Ship Transmit Freq.	Mode	Label
81	4027.0	4027.0	USB	Ship 4027	121	8167.0	8167.0	USB	Panama
82	4030.0	4030.0	USB	Papagayo Net	122	8170.0	8170.0	USB	Coconut Telegrph
83	4033.0	4033.0	USB	Ship 4033	123	8173.0	8173.0	USB	Ship 8173
84	4036.0	4036.0	USB	Ship 4036	124	8176.0	8176.0	USB	Ship 8176
85	4039.0	4039.0	USB	Ship 4039	125	8179.0	8179.0	USB	Ship 8179
86	4042.0	4042.0	USB	Ship 4042	126	8182.0	8182.0	USB	Ship 8182
87	4045.0	4045.0	USB	Chris Parker WX	127	8185.0	8185.0	USB	Ship 8185
88	4048.0	4048.0	USB	Ship 4048	128	8188.0	8188.0	USB	NW Caribbean
89	4051.0	4051.0	USB	Sea of Cortez Net	129	8191.0	8191.0	USB	Ship 8191
90	4054.0	4054.0	USB	Ship 4054	130	12350.0	12350.0	USB	Chris Parker WX
91	4057.0	4057.0	USB	Ship 4060	131	12353.0	12353.0	USB	Ship 12A
92	4060.0	4060.0	USB	Ship 4060	132	12356.0	12356.0	USB	Ship 12B
93	6224.0	6224.0	USB	Ship 6A	133	12359.0	12359.0	USB	Ship 12C
94	6227.0	6227.0	USB	Ship 6B	134	16528.0	16528.0	USB	Ship 16A
95	6230.0	6230.0	USB	Ship 6C	135	16531.0	16531.0	USB	Ship 16B
96	6516.0	6516.0	USB	Ship 6D	136	16534.0	16534.0	USB	Ship 16C
97	8294.0	8294.0	USB	Ship 8A	137	18825.0	18825.0	USB	Ship 18A
98	8297.0	8297.0	USB	Ship 8B	138	18828.0	18828.0	USB	Ship 18B
99	8101.0	8101.0	USB	Ship 8101	139	22159.0	22159.0	USB	Ship 22A
100	8104.0	8104.0	USB	Ship 8104	140	22162.0	22162.0	USB	Ship 22B
101	8107.0	8107.0	USB	Ship 8107	141	Ham/Amateur Radio			
102	8110.0	8110.0	USB	Ship 8110	142	3696.0	3696.0	LSB	Bahamas Net
103	8113.0	8113.0	USB	Ship 8113	143	3815.0	3815.0	LSB	West Caribbean
104	8116.0	8116.0	USB	Amigo Net	144	3930.0	3930.0	LSB	Puerto Ricoo & VI
105	8119.0	8119.0	USB	Ship 8119	145	3968.0	3968.0	LSB	Sonrisa Net
106	8122.0	8122.0	USB	Amigo Net	146	7083.0	7083.0	LSB	Central America
107	8125.0	8125.0	USB	Ship 8125	147	7096.0	7096.0	LSB	Bahamas Net
108	8128.0	8128.0	USB	Ship 8128	148	7192.0	7192.0	LSB	Chubasco Net
109	8131.0	8131.0	USB	Ship 8131	149	7233.5	7233.5	LSB	Baja Net
110	8134.0	8134.0	USB	Ship 8134	150	7250.0	7250.0	LSB	Gordo (Gordon West)
111	8137.0	8137.0	USB	Chris Parker WX	151	7268.0	7268.0	LSB	Waterway
112	8140.0	8140.0	USB	Ship 8140	152	7282.0	7282.0	LSB	Happy Hour
113	8143.0	8143.0	USB	Ship 8143	153	14300.0	14300.0	USB	24-Hr Net
114	8146.0	8146.0	USB	Cruzheimers Alt.	154	14325.0	14325.0	USB	Hurricane Net
115	8149.0	8149.0	USB	Ship 8149	155	14342.5	14342.5	USB	Mañana Net
116	8152.0	8152.0	USB	Cruzheimers Pri.	156	21412.0	21412.0	USB	Pacific Maritime
117	8155.0	8155.0	USB	Ship 8155	157	Standard AM Broadcast			
118	8158.0	8158.0	USB	Ship 8158	158	1080	1080	AM	Standard Broadcast
119	8161.0	8161.0	USB	Ship 8161	159	Miscellaneous			
120	8164.0	8164.0	USB	Cruzheimers Alt.	160	28500.0	28500.0	USB	Ham 10-Meter
Legend:	Green = Transmit OK - Marine Radio License Rqgd.				Brown = Receive only - Entertainment				
DSR database Ver. 02/03/21	Red = Safety comm. - Marine license Rqgd.				Violet = Receive only - Time - Propagation - Emergency				
	Black = Receive - Weather: FAX, SITOR, Voice				Blue = Transmit OK - Amateur Radio License Rqgd.				

DockSide Radio

www.docksideradio.com

941.661.4498

Maritime HF SSB Simplex Channels

Channel	Frequency KHz	Channel	Frequency KHz	Channel	Frequency KHz	Channel	Frequency KHz
4A	4146	12A	12,353	18A	18,825	25A	25,100
4B	4149	12B	12,356	18B	18,828	25B	25,103
4C	4417	12C	12,359	18C	18,831	25C	25,106
	4065,4089,4116,4408 Mississippi River	12D	12,362	18D	18,834	25D	25,109
		12E	12,365	18E	18,837	25E	25,112
6A	6224	----	12,362 12,365 Mississippi River	18F	18,840	25F	25,115
6B	6227	----		18G	18,843	25G	25,118
6C	6230	16A	16,528	22A	22,159	Notes: ALL communications are to be conducted in USB (UPPER SIDEBAND) MODE ONLY. There are no exceptions to this rule.	
----	6156 (<i>daytime only</i>)	16B	16,531	22B	22,162		
----	6209,6212,6510,6513 Mississippi River	16C	16,534	22C	22,165		
----		16D	16,537	22D	22,168		
8A	8294	16E	16,540	22E	22,171		
8B	8297	----	16,543, 16,546 Mississippi River	22F	22,174		
	8201,8213,8725,8737 Mississippi River	----		22G	22,177		

Maritime HF SSB Frequencies Shared with Fixed Services

4 MHz Frequency KHz		8 MHz Frequency KHz			Notes: ALL communications are to be conducted in USB (UPPER SIDEBAND) MODE ONLY. There are no exceptions to this rule. These are shared with "fixed" stations. If the frequency is occupied, we must choose another frequency. No channel numbers are assigned to these frequencies. They are referred to by the frequency itself, e.g., "...meet you on 8122...".
4000	4033	8101	8134	8167	
4003	4036	8104	8137	8170	
4006	4039	8107	8140	8173	
4009	4042	8110	8143	8176	
4012	4045	8113	8146	8179	
4015	4048	8116	8149	8182	
4018	4051	8119	8152	8185	
4021	4054	8122	8155	8188	
4024	4057	8125	8158	8191	
4027	4060	8128	8161	----	
4030	----	8131	8164	----	

Global Maritime Distress & Safety System (GMDSS) Simplex DSC & Radiotelephone Frequencies

DSC	VOICE	DSC	VOICE	Notes: DSC Frequencies are 'guarded' (monitored) frequencies. They are used for distress, urgency, and safety. Switch to the corresponding voice frequency after the DSC call is made and acknowledged. VOICE FREQUENCIES ARE NOT NORMALLY GUARDED. They are to be used only for distress, urgency, and safety related two-way communications.
2187.5	2182	8414.5	8291	
4207.5	4125	12,577	12,290	
6312.0	6215	16,804.5	16,420	
Source: http://www.navcen.uscg.gov/marcomms/high_frequency/rtchansi.htm				

Serving Boaters Coast to Coast