

■ INSTALLATION AND CONNECTION

The following instructions are for use by your KENWOOD dealer; either an authorized KENWOOD service facility, or the factory only.

■ ACCESSORY

① Remote kit assy		1 ea.
Panel	A62-0032-02	1 ea.
Case	A01-2012-02	1 ea.
Board	F15-0669-04	1 ea.
Packing	G53-0595-03	1 ea.
Bracket for panel	J21-4315-04	2 ea.
Bracket	J29-0455-03	1 ea.
Trimmed screw	N08-0514-14	2 ea.
Machine screw	N35-4008-45	2 ea.
Tapping screw	N87-3008-46	4 ea.
Flat washer	N19-0648-05	2 ea.
② Tapping screw	N09-0335-05	4 ea.
③ Machine screw	N89-3008-45	4 ea.
④ Spring washer	N16-0050-46	4 ea.
⑤ Flat washer	N15-1050-46	4 ea.
⑥ Flat washer	N15-1030-45	4 ea.
Instruction manual	B62-0029-XX	1 sheet

