


# 511 ALL BAND RADIO



# 511 RADIO PARTS LIST

- R-1 Resistor, 150 ohm 5 watt
- R-2 Resistor, 270 ohm 1/2 watt
- R-3 Resistor, 4700 ohm 1/2 watt
- R-4 Resistor, 150 ohm 1/2 watt
- R-5 Potentiometer W/SW 500K ohms
- R-6 Resistor, 100K 1/2 watt
- R-7 Resistor, 1.5Meg. ohm 1/2 watt
- R-8 Resistor, 47K ohm 1/2 watt
- R-9 Resistor, 2.2Meg. ohm 1/2 watt
- R-10 Potentiometer 300 ohm
- C-1 Capacitor, 20 mfd. 150 volt
- C-2 Capacitor, 20 mfd. 150 volt
- C-3 Capacitor, .05 mfd. tubular
- C-4 Capacitor, .01 mfd. disc
- C-5 Capacitor, .01 mfd. disc
- C-6 Capacitor, .005 mfd. disc
- C-7 Capacitor, 100 mmfd. (PF) disc
- C-8 Capacitor, 0-25 PF trimmer
- C-9 Capacitor, 10-110, 10-240PF tuning
- C-10 Capacitor, 470 mmfd. (PF) disc
- T-1 Transformer, output, 2500 ohm to 8 ohm
- Speaker, 3 inch, 8 ohm
- Plate, bottom metal
- Screws, sheet metal (4)
- Tube socket, 7 pin molded (2)
- Tube socket, 8 pin molded (1)
- Tube socket, 9 pin molded (1)
- Knob, Indicator
- Knobs, Black round (3)
- Chassis, Metal
- Front Panel
- Terminal lug, 3 pin (2)
- Terminal lug, 2 pin (1)
- Plug, AC
- Line Cord, AC
- Wire, Hook-up
- Wire, Enameled coil
- Coil form, 8 pin (3)
- Terminal, Colored (1)
- Washer, Flat fiber (1)
- Washer, Shoulder (1)
- Grommets, Rubber (2)
- Spaghetti
- Tube Set (35W4, 50C5, 12AT7)
- Feet, Rubber (4)
- Screws, Machine, (15)
- Nuts, Machine screw (15)