



- FUNCTION**
- |           |            |      |              |
|-----------|------------|------|--------------|
| S1 ~ S8   | BAND SW.   | VC-1 | ANT. TRIM    |
| S10       | AVC SW.    | VC-2 | MAIN TUNING  |
| S11 ~ S12 | MODE SW.   | VC-4 |              |
| S13 ~ S14 | A.N.L. SW. | VC-6 | BAND SPREAD  |
| S15       | OPR SW.    | VC-3 |              |
| S16       | AC/DC SW.  | VC-5 | B.F.O. PITCH |
| S17 ~ S18 | POWER SW.  | VC 7 |              |
- 
- |     |               |
|-----|---------------|
| VR1 | RF GAIN CONT. |
| VR2 | AF GAIN CONT. |

**SCHEMATIC DIAGRAM OF DX-150**