



memoryscan™

from the people who let you hear the action faster ... **TENNELEC** Commercial Products Division

Tennelec memoryscan™



MADE IN AMERICA

INSTRUCTION MANUAL AND FREQUENCY CODES

TENNELEC MEMORYSCAN™

Congratulations! You have purchased a completely new type of monitor — one which will allow you to listen in on more than 4,000 frequencies and which is capable of receiving more than 16,000 frequencies on three Public Service bands: Hi-band, Low-band, and UHF — and you will never have to buy a single crystal, ever.

The advantages of crystalless operation of your scanner are numerous: If you move, you simply re-program your scanner for the frequencies in your new location; if the frequencies change in your area or new frequencies are added, you simply re-program; on trips in your car you can listen in on the Public Service bands as you pass through new locations. (Caution: Some states have laws against having a police monitor in your car; check your local laws.)

Due to the nature of your MEMORYSCAN, getting "on the air" is different than with a conventional scanner. We strongly urge you to take a few minutes to read the manual and understand the operation of your scanner before attempting to use it. This manual is divided into three sections: I. DESCRIPTION OF CONTROLS; II. OPERATING INSTRUCTIONS; and III. FREQUENCY CODES.

I. DESCRIPTION OF CONTROLS

Off-On/Volume

Turn clockwise to turn unit ON and increase the volume. Turn the MEMORYSCAN OFF before unplugging it from the wall.

Squelch

The squelch control eliminates background noise and allows the unit to scan.

To set the squelch control, turn it counterclockwise until you hear noise and scanning stops. Turn the knob back until scanning resumes; this is the proper squelch setting.

NOTE: The squelch is properly set when the unit does not hesitate on any channel while scanning.

As the squelch control is turned farther clockwise, it takes more signal to stop the scanning action. Thus, the squelch control may be used to eliminate weak stations by turning it farther clockwise.

Scan Delay

A fixed two-second scan delay is built into your MEMORYSCAN. After any message is received, the scanner will wait for approximately two seconds to hear a reply before scanning the other channels again.

Lock-out Switches

The 16 slide switches below the indicator lamps in your MEMORYSCAN determine which channels will be scanned. To eliminate a channel from the scanning sequence, move the appropriate switch lever DOWN. Any combination of 16 channels may be locked IN or OUT of service.

NOTE: Channels which have not been programmed with a code should be switched OUT of the scanning sequence.

Channel Indicator Lamps

The 16 LED (light emitting diode) indicators normally light when a particular channel is being scanned. When the PROGRAM button is pushed IN, they become CODE indicators, and light up in a pattern indicating the frequency code stored in that particular channel.

Scan/Manual

Pushing this button IN interrupts the scanning action and allows manual selection of channels. This button should be IN (scanning stopped) when programming your MEMORYSCAN.

Channel Select

When the SCAN/MANUAL button is pressed in, the CHANNEL SELECT button allows the manual selection of the channel of your choice. This button is also used to select a channel to be programmed.

Frequency Program

When this button is OUT, your MEMORYSCAN operates as a normal scanner. Pushing this button IN prepares the unit to accept program codes from the 1 and 0 buttons. Also when the button is IN the channel indicator lamps become CODE indicator lamps.

0 & 1 Pushbuttons

These buttons are used to enter a "0" Code or a "1" Code in programming your MEMORYSCAN. They are active only when the PROGRAM button is pressed in.

External Speaker

A jack is provided on the rear panel for an external speaker. When a plug is installed, the internal speaker is cut off.

An earphone may also be plugged into this jack.

Battery Installation

Why You Should Install A 9V Battery

Your MEMORYSCAN is similar to a computer and contains an electronic memory. The 9V battery provides this electronic memory with *STAND-BY* power so that it will not "forget" the channels you have programmed in case of a power failure or should you unplug it from the wall to move the unit to another room or your car. *The battery does not affect the operation of your MEMORYSCAN. Battery failure will not damage your unit* but will cause you the inconvenience of reprogramming the channels.

Recommended battery is a standard nine-volt transistor radio battery (26V Burgess, 216 Eveready, VS323 RCA or equivalent).

To install the battery: First remove the screws from each side of the battery compartment cover on the rear panel. Next, snap the battery into the clip on the cover. Now, find the battery connection clip and connect the battery contacts. Replace the cover with the two screws.

NOTE: DO NOT LEAVE THE UNIT UNPLUGGED FROM THE WALL ANY LONGER THAN NECESSARY – THE BATTERY WILL RUN DOWN IN ABOUT TWO DAYS IF THE UNIT IS LEFT UNPLUGGED.

UNDER NORMAL CONDITIONS, RE-



PLACE THE BATTERY APPROXIMATELY EVERY SIX MONTHS. BE SURE YOUR MEMORYSCAN IS PLUGGED INTO A WALL SOCKET WHEN REPLACING BATTERY.

Antenna

Your MEMORYSCAN has one antenna jack that is internally matched to operate on all three bands. The antenna supplied will provide excellent urban area reception with your MEMORYSCAN.

An external antenna may be used to increase the area of reception. If an external antenna (or mobile antenna) is used, it should be the Hi-band type (145-175 MHz) as the internal circuitry matches a Hi-band antenna to all three bands.

Mobile Operation

With the optional MK-1 Mobile Kit, your MEMORYSCAN may be operated in automobiles, trucks, boats, or any vehicle having 12V NEGATIVE GROUND electrical system.

The optional mobile power convertor is necessary to supply power to the memory, which requires a negative as well as a positive voltage. For this reason **DO NOT ATTEMPT TO OPERATE YOUR MEMORYSCAN MOBILE EXCEPT WITH THE OPTIONAL MOBILE POWER CONVERTOR.**

II. OPERATING INSTRUCTIONS

The purpose of this section is to allow you to start receiving with your new scanner as soon as possible. Read over and carefully follow these instructions:



1. Unpack the unit from the carton. Check your MEMORYSCAN for shipping damage. If damage has occurred, contact your dealer immediately.

You should have the following items:

- 1 Scanner
1 Line Cord
1 Tri-Band Antenna
1 Instruction Manual

If any of these items are missing, see your dealer.

2. Plug the antenna into the antenna jack (1), and the line cord into the line cord receptacle (4). (See the photograph above).
3. Plug the scanner into the power line (105 to 135 VAC, 50 to 60 Hz *ONLY*).
4. Remove the battery access cover (3). Connect the nine-volt battery to the battery clip. Insert the battery into the spring clip on the inside of the access cover. Replace the access cover.



5. Turn the unit ON by turning the ON-VOLUME (8) control clockwise approximately 1/3 of its rotation.

6. Set the front panel controls as follows:

SQUELCH (9) — Turn the squelch knob counterclockwise until you hear background noise; then turn it back clockwise until the noise disappears.

SCAN MANUAL (10) — Out (SCAN).

PROGRAM (12) — Out (normal).

Channel Lockout switches (15) — Up (all channels IN).

The scanner should now be scanning.

7. You are now ready to program your scanner.

Stop the unit from scanning by pressing the SCAN MANUAL button IN (MAN.).

Advance the scanner to the channel you wish to program using the CHANNEL SELECT button (11).

8. We will use as an example the Weather frequency 162.55 MHz. The code for 162.55 MHz is:

0010 1000 1110 0010

Push the PROGRAM button IN to the Program

position. Any number of the Channel lamps (16) may now be on; this is normal.

You will program your scanner by pressing the 0 and 1 buttons in the order that the code is written, from left to right very much like dialing a telephone, except that we only have two digits, 0 and 1, whereas a telephone has ten. It is important that you follow the code exactly — if you make a mistake in entering the code, you won't get the channel you want. You can check the code as soon as you have entered it — if you have made a mistake, release the PROGRAM button and press it in again. Then re-enter the code.

Just for practice, program the channel you have selected for 162.55. Again, the code: 0010 1000 1110 0010.

Begin programming by:

Press the 0 button.

Press the 0 button.

Press the 1 button.

Press the 0 button.

Press the 1 button.

Press the 0 button.

Press the 0 button.

Press the 0 button.


Press the 1 button.

Press the 1 button.
Press the 1 button.
Press the 0 button.

Press the 0 button.
Press the 0 button.
Press the 1 button.
Press the 0 button.

You have now programmed one channel of your scanner. We have the code broken down into groups of four for convenience in programming and checking the code.

Now look at the channel lamps. Dark (un-lighted) lamps represent 0's, and lighted lamps represent 1's. You should be able to read the code right off the lamps, just as it appears on paper. The lamps should be lit in the pattern shown in the figure below:



Notice that while the lamps are not physically separated into groups of four, there is a small dividing line between each group of four on the panel.

If the lamps are not lit in that pattern, you have made a mistake. In this case, press the PROGRAM button and release it to the OUT (Normal) position, then press it back IN to Program position. This enables the circuitry inside to accept a new code.

If the lamps were lit in the proper order, release the PROGRAM switch OUT to the Normal position, then press it back IN to PROGRAM position. If the lamps are still lit in the correct pattern, the number has been entered in the memory correctly. Now release the PROGRAM button OUT to Normal position. If you have a National Weather Service station in your area broadcasting on 162.55, you should be receiving it now.

To program another channel, advance to the desired channel using the CHANNEL SELECT button, and repeat the above process. Try programming your unit again, this time use the frequency of a local station and look up the code for it in the back of this manual.

Again, here are the steps to take to program your scanner:

1. Look up the code for the desired frequency in the back of this manual.
2. Press the SCAN MANUAL button IN to stop the unit from scanning.

3. Advance to the channel you want to program using the CHANNEL SELECT button.
4. Press the PROGRAM button IN.
5. Enter the code for the desired frequency by pressing the 0 and 1 buttons in the exact order that the code is written, left to right.
6. Release the PROGRAM button and then press it in again; if the lamps light in the correct sequence, the code has been entered correctly in the memory.
7. If you see that the code has been correctly entered, release the PROGRAM button.
8. Advance to the next channel to be programmed using the CHANNEL SELECT button.
9. Repeat steps one through eight.

You can go back at any time later and check the code programmed in a particular channel simply by advancing to that channel and pressing the PROGRAM button IN. The channel lamps will then show you the code in that channel.

We suggest that you lock out (place the channel lock out switches in the down position) any channels that you have not programmed. Due to the operation of the memory, a random code may be contained in one of these channels which will cause the scanner to lock on that channel and stop scanning.

A few words about the operation of your scanner:

Your MEMORYSCAN contains an electronic memory (just like a computer) which stores the code that you program into each channel. This memory must have power constantly if it is to remember the codes. This power is supplied to the memory in two ways: power is supplied to the memory through the power line even when the unit is turned off; and if the power should go off or you unplug the unit to move it from place to place in your home or in your car, then the stand-by battery power takes over. This is the purpose of the nine-volt battery that you inserted into the unit when it was unpacked. This battery is only STAND-BY power, and should not be depended upon to keep the memory alive when the unit is unplugged from the wall socket for long periods of time. Under normal use, with the unit being unplugged from the wall only occasionally, and for short periods, the battery will last 6 months or more. If the unit is left unplugged, however, the battery will only last two days. Then the unit would have to be re-programmed. (No damage would occur to the unit.)

Under normal circumstances, you should only have to re-program your scanner if you decide to change frequencies. However, it is possible that a noisy power line, nearby lightning discharges, or other occurrences could cause the memory to "forget" some or all of the programmed codes. If this hap-

pens, your scanner will probably stop receiving on certain or all frequencies, or may pick up "garbage". More than likely, no damage has occurred, and the remedy is simply to re-program the unit.

Things to remember about your MEMORYSCAN:

LOCK OUT OF THE SCANNING SEQUENCE CHANNELS WHICH HAVE NOT BEEN PROGRAMMED WITH A CODE.

THE STANDBY BATTERY WILL DISCHARGE IF YOU LEAVE YOUR MEMORYSCAN UNPLUGGED FROM THE WALL OUTLET.

TURN THE UNIT OFF BEFORE UNPLUGGING IT FROM THE WALL. FAILURE TO TURN THE UNIT OFF MAY CAUSE IT TO FORGET SOME CHANNELS WHEN IT IS UNPLUGGED.

How to Program Frequencies Which Have More Than Six Digits

You may have frequencies in your area such as 161.2375. You will note that this frequency is not listed in your program book. This is because this is not a normal but a "split-channel" frequency. You will be able to receive this frequency by programming the frequency which is closest to it. For example, 161.235 would be the frequency to program to receive 161.2375.

Reception in the 146 to 148 MHz Band

Your code book lists codes for frequencies in the 146 to 148 MHz (2 meter Amateur Band).

When your MEMORYSCAN comes from the factory, the Hi-band is tuned for the 151 to 163 MHz band. Nevertheless, reception of 146 to 148 MHz signals is possible at reduced sensitivity without retuning the MEMORYSCAN. The sensitivity *without* retuning will be about 2 to 3 μ V for these signals; if optimum performance is desired, the MEMORYSCAN may be retuned. NOTE: If retuning is done, performance for 151 to 163 MHz signals will be hurt; it is not possible to optimize both frequency ranges simultaneously.

Reception of Signals in the 490 to 510 MHz Band

Your code book contains listings for frequencies in the 490 to 510 MHz band.

As the MEMORYSCAN comes from the factory, it is tuned for the 450 to 470 MHz band; thus, reception of 490 to 510 MHz signals is not possible with *standard* factory tuning. If you live in an area with 490-510 MHz signals, chances are your MEMORYSCAN is already tuned for this band. If it is not, a competent technician can retune your unit by following procedures outlined in the MEMORYSCAN Service Manual.

MEMORY SCAN SPECIFICATIONS

TOTAL FREQUENCY COVERAGE

31.180 MHz to 50.000 MHz in Steps¹ of 10 kHz
 146.000 MHz to 148.000 MHz in Steps of 10 kHz
 151.180 MHz to 170.000 MHz in Steps of 5 kHz
 451.200 MHz to 470.000 MHz in Steps of 25 kHz
 490.000 MHz to 508.825 MHz in Steps of 25 kHz

¹All frequencies are programmable in 5 kHz steps; steps listed here are those given in the code book.

PERFORMANCE

Frequency Range	Sensitivity ²	Squelch Sensitivity
33 MHz to 48 MHz	0.6 μ V	0.5 μ V
146 MHz to 148 MHz	3.0 μ V	2.5 μ V
Typical, with standard alignment*		
151 MHz to 163 MHz	0.6 μ V	0.5 μ V
453 MHz to 460 MHz	0.6 μ V	0.5 μ V
Special alignment required:		
490 MHz to 497 MHz	1.2 μ V	0.9 μ V

²Sensitivity is defined as 10 db $\frac{S+N}{N}$ @ 3 kHz peak modulation by a 400 Hz tone.

*The above frequency ranges are factory alignments. Special alignments can be performed by a competent service technician.

ADJACENT CHANNEL SELECTIVITY — (± 25 kHz) — 50 db.

INTERMEDIATE FREQUENCIES — 10.7 MHz, 455 kHz (two ceramic filters).

IF BANDWIDTH — 16 kHz @ 6 db down.

MODULATION ACCEPTANCE — ± 7.5 kHz, maximum.

ANTENNA INPUT — Matched for optimum response with 18" whip on all bands (whip antenna provided).

SCAN RATE — 12 channels per second, nominal.

AUDIO OUTPUT — 1.5W average power @ 10% distortion. 3 1/2", 8 Ω internal speaker. Jack for ear-phone or external speaker jack.

SOLID STATE DEVICES — 71 transistors, 26 integrated circuits, 38 diodes; 16 LED indicators.

POWER REQUIREMENTS — 105 to 130 VAC @ 25W; mobile*, 13.8 VDC @ .8A maximum (negative ground), 6 mA in stand-by mode with power switch OFF.

*With TENNELEC MK-1 mobile power convertor only.

NUMBER OF CHANNELS — 16.

CONTROLS —

16 Channel Lockout Switches
Frequency Code Display
OFF/ON and Volume Control
Variable SQUELCH
Automatic Scan or Manual Control
Manual CHANNEL SELECT
Frequency PROGRAM

"0" Button

"1" Button

SIZE AND WEIGHT — 4 1/2" x 10 3/4" x 9 3/4",
HWD; 6.1 lbs.

WARRANTY — One year.

OPTIONAL EQUIPMENT — Mobile kit including
MK-1 mobile adapter, DC power cable, and mounting
bracket.

III. MEMORYSCAN™ FREQUENCY CODES*

LOW BAND 31.180 to 50.000 MHz

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
31.180	0000 0000 0000 0000	31.500	0000 0000 0100 0000	31.820	0000 0000 1000 0000	32.140	0000 0000 1100 0000
31.190	0000 0000 0000 0010	31.510	0000 0000 0100 0010	31.830	0000 0000 1000 0010	32.150	0000 0000 1100 0010
31.200	0000 0000 0000 0100	31.520	0000 0000 0100 0100	31.840	0000 0000 1000 0100	32.160	0000 0000 1100 0100
31.210	0000 0000 0000 0110	31.530	0000 0000 0100 0110	31.850	0000 0000 1000 0110	32.170	0000 0000 1100 0110
31.220	0000 0000 0000 1000	31.540	0000 0000 0100 1000	31.860	0000 0000 1000 1000	32.180	0000 0000 1100 1000
31.230	0000 0000 0000 1010	31.550	0000 0000 0100 1010	31.870	0000 0000 1000 1010	32.190	0000 0000 1100 1010
31.240	0000 0000 0000 1100	31.560	0000 0000 0100 1100	31.880	0000 0000 1000 1100	32.200	0000 0000 1100 1100
31.250	0000 0000 0000 1110	31.570	0000 0000 0100 1110	31.890	0000 0000 1000 1110	32.210	0000 0000 1100 1110
31.260	0000 0000 0001 0000	31.580	0000 0000 0101 0000	31.900	0000 0000 1001 0000	32.220	0000 0000 1101 0000
31.270	0000 0000 0001 0010	31.590	0000 0000 0101 0010	31.910	0000 0000 1001 0010	32.230	0000 0000 1101 0010
31.280	0000 0000 0001 0100	31.600	0000 0000 0101 0100	31.920	0000 0000 1001 0100	32.240	0000 0000 1101 0100
31.290	0000 0000 0001 0110	31.610	0000 0000 0101 0110	31.930	0000 0000 1001 0110	32.250	0000 0000 1101 0110
31.300	0000 0000 0001 1000	31.620	0000 0000 0101 1000	31.940	0000 0000 1001 1000	32.260	0000 0000 1101 1000
31.310	0000 0000 0001 1010	31.630	0000 0000 0101 1010	31.950	0000 0000 1001 1010	32.270	0000 0000 1101 1010
31.320	0000 0000 0001 1100	31.640	0000 0000 0101 1100	31.960	0000 0000 1001 1100	32.280	0000 0000 1101 1100
31.330	0000 0000 0001 1110	31.650	0000 0000 0101 1110	31.970	0000 0000 1001 1110	32.290	0000 0000 1101 1110
31.340	0000 0000 0010 0000	31.660	0000 0000 0110 0000	31.980	0000 0000 1010 0000	32.300	0000 0000 1110 0000
31.350	0000 0000 0010 0010	31.670	0000 0000 0110 0010	31.990	0000 0000 1010 0010	32.310	0000 0000 1110 0010
31.360	0000 0000 0010 0100	31.680	0000 0000 0110 0100	32.000	0000 0000 1010 0100	32.320	0000 0000 1110 0100
31.370	0000 0000 0010 0110	31.690	0000 0000 0110 0110	32.010	0000 0000 1010 0110	32.330	0000 0000 1110 0110
31.380	0000 0000 0010 1000	31.700	0000 0000 0110 1000	32.020	0000 0000 1010 1000	32.340	0000 0000 1110 1000
31.390	0000 0000 0010 1010	31.710	0000 0000 0110 1010	32.030	0000 0000 1010 1010	32.350	0000 0000 1110 1010
31.400	0000 0000 0010 1100	31.720	0000 0000 0110 1100	32.040	0000 0000 1010 1100	32.360	0000 0000 1110 1100
31.410	0000 0000 0010 1110	31.730	0000 0000 0110 1110	32.050	0000 0000 1010 1110	32.370	0000 0000 1110 1110
31.420	0000 0000 0011 0000	31.740	0000 0000 0111 0000	32.060	0000 0000 1011 0000	32.380	0000 0000 1111 0000
31.430	0000 0000 0011 0010	31.750	0000 0000 0111 0010	32.070	0000 0000 1011 0010	32.390	0000 0000 1111 0010
31.440	0000 0000 0011 0100	31.760	0000 0000 0111 0100	32.080	0000 0000 1011 0100	32.400	0000 0000 1111 0100
31.450	0000 0000 0011 0110	31.770	0000 0000 0111 0110	32.090	0000 0000 1011 0110	32.410	0000 0000 1111 0110
31.460	0000 0000 0011 1000	31.780	0000 0000 0111 1000	32.100	0000 0000 1011 1000	32.420	0000 0000 1111 1000
31.470	0000 0000 0011 1010	31.790	0000 0000 0111 1010	32.110	0000 0000 1011 1010	32.430	0000 0000 1111 1010
31.480	0000 0000 0011 1100	31.800	0000 0000 0111 1100	32.120	0000 0000 1011 1100	32.440	0000 0000 1111 1100
31.490	0000 0000 0011 1110	31.810	0000 0000 0111 1110	32.130	0000 0000 1011 1110	32.450	0000 0000 1111 1110

* Important: The frequency bands listed in this manual are all the frequencies your Memoryscan will receive.

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
32.460	0000	0001	0000	0000	32.790	0000	0001	0100	0010	33.120	0000	0001	1000	0100	33.450	0000	0001	1100	0110
32.470	0000	0001	0000	0010	32.800	0000	0001	0100	0100	33.130	0000	0001	1000	0110	33.460	0000	0001	1100	1000
32.480	0000	0001	0000	0100	32.810	0000	0001	0100	0110	33.140	0000	0001	1000	1000	33.470	0000	0001	1100	1010
32.490	0000	0001	0000	0110	32.820	0000	0001	0100	1000	33.150	0000	0001	1000	1010	33.480	0000	0001	1100	1100
32.500	0000	0001	0000	1000	32.830	0000	0001	0100	1010	33.160	0000	0001	1000	1100	33.490	0000	0001	1100	1110
32.510	0000	0001	0000	1010	32.840	0000	0001	0100	1100	33.170	0000	0001	1000	1110	33.500	0000	0001	1101	0000
32.520	0000	0001	0000	1100	32.850	0000	0001	0100	1110	33.180	0000	0001	1001	0000	33.510	0000	0001	1101	0010
32.530	0000	0001	0000	1110	32.860	0000	0001	0101	0000	33.190	0000	0001	1001	0010	33.520	0000	0001	1101	0100
32.540	0000	0001	0001	0000	32.870	0000	0001	0101	0010	33.200	0000	0001	1001	0100	33.530	0000	0001	1101	0110
32.550	0000	0001	0001	0010	32.880	0000	0001	0101	0100	33.210	0000	0001	1001	0110	33.540	0000	0001	1101	1000
32.560	0000	0001	0001	0100	32.890	0000	0001	0101	0110	33.220	0000	0001	1001	1000	33.550	0000	0001	1101	1010
32.570	0000	0001	0001	0110	32.900	0000	0001	0101	1000	33.230	0000	0001	1001	1010	33.560	0000	0001	1101	1100
32.580	0000	0001	0001	1000	32.910	0000	0001	0101	1010	33.240	0000	0001	1001	1100	33.570	0000	0001	1101	1110
32.590	0000	0001	0001	1010	32.920	0000	0001	0101	1100	33.250	0000	0001	1010	1110	33.580	0000	0001	1110	0000
32.600	0000	0001	0001	1100	32.930	0000	0001	0101	1110	33.260	0000	0001	1010	0000	33.590	0000	0001	1110	0010
32.610	0000	0001	0001	1110	32.940	0000	0001	0110	0000	33.270	0000	0001	1010	0010	33.600	0000	0001	1110	0100
32.620	0000	0001	0010	0000	32.950	0000	0001	0110	0010	33.280	0000	0001	1010	0100	33.610	0000	0001	1110	0110
32.630	0000	0001	0010	0010	32.960	0000	0001	0110	0100	33.290	0000	0001	1010	0110	33.620	0000	0001	1110	1000
32.640	0000	0001	0010	0100	32.970	0000	0001	0110	0110	33.300	0000	0001	1010	1000	33.630	0000	0001	1110	1010
32.650	0000	0001	0010	0110	32.980	0000	0001	0110	1000	33.310	0000	0001	1010	1010	33.640	0000	0001	1110	1100
32.660	0000	0001	0010	1000	32.990	0000	0001	0110	1010	33.320	0000	0001	1010	1100	33.650	0000	0001	1110	1110
32.670	0000	0001	0010	1010	33.000	0000	0001	0110	1100	33.330	0000	0001	1010	1110	33.660	0000	0001	1111	0000
32.680	0000	0001	0010	1100	33.010	0000	0001	0110	1110	33.340	0000	0001	1011	0000	33.670	0000	0001	1111	0010
32.690	0000	0001	0010	1110	33.020	0000	0001	0111	0000	33.350	0000	0001	1011	0010	33.680	0000	0001	1111	0100
32.700	0000	0001	0011	0000	33.030	0000	0001	0111	0010	33.360	0000	0001	1011	0100	33.690	0000	0001	1111	0110
32.710	0000	0001	0011	0010	33.040	0000	0001	0111	0100	33.370	0000	0001	1011	0110	33.700	0000	0001	1111	1000
32.720	0000	0001	0011	0100	33.050	0000	0001	0111	0110	33.380	0000	0001	1011	1000	33.710	0000	0001	1111	1010
32.730	0000	0001	0011	0110	33.060	0000	0001	0111	1000	33.390	0000	0001	1011	1010	33.720	0000	0001	1111	1100
32.740	0000	0001	0011	1000	33.070	0000	0001	0111	1010	33.400	0000	0001	1011	1100	33.730	0000	0001	1111	1110
32.750	0000	0001	0011	1010	33.080	0000	0001	0111	1100	33.410	0000	0001	1011	1110	33.740	0000	0010	0000	0000
32.760	0000	0001	0011	1100	33.090	0000	0001	0111	1110	33.420	0000	0001	1100	0000	33.750	0000	0010	0000	0010
32.770	0000	0001	0011	1110	33.100	0000	0001	1000	0000	33.430	0000	0001	1100	0010	33.760	0000	0010	0000	0100
32.780	0000	0001	0100	0000	33.110	0000	0001	1000	0010	33.440	0000	0001	1100	0100	33.770	0000	0010	0000	0110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
33.780	0000 0010 0000 1000	34.110	0000 0010 0100 1010	34.440	0000 0010 1000 1100	34.770	0000 0010 1100 1110
33.790	0000 0010 0000 1010	34.120	0000 0010 0100 1100	34.450	0000 0010 1000 1110	34.780	0000 0010 1101 0000
33.800	0000 0010 0000 1100	34.130	0000 0010 0100 1110	34.460	0000 0010 1001 0000	34.790	0000 0010 1101 0010
33.810	0000 0010 0000 1110	34.140	0000 0010 0100 0000	34.470	0000 0010 1001 0010	34.800	0000 0010 1101 0100
33.820	0000 0010 0001 0000	34.150	0000 0010 0101 0010	34.480	0000 0010 1001 0100	34.810	0000 0010 1101 0110
33.830	0000 0010 0001 0010	34.160	0000 0010 0101 0100	34.490	0000 0010 1001 0110	34.820	0000 0010 1101 1000
33.840	0000 0010 0001 0100	34.170	0000 0010 0101 0110	34.500	0000 0010 1001 1000	34.830	0000 0010 1101 1010
33.850	0000 0010 0001 0110	34.180	0000 0010 0101 1000	34.510	0000 0010 1001 1010	34.840	0000 0010 1101 1100
33.860	0000 0010 0001 1000	34.190	0000 0010 0101 1010	34.520	0000 0010 1001 1100	34.850	0000 0010 1101 1110
33.870	0000 0010 0001 1010	34.200	0000 0010 0101 1100	34.530	0000 0010 1001 1110	34.860	0000 0010 1110 0000
33.880	0000 0010 0001 1100	34.210	0000 0010 0101 1110	34.540	0000 0010 1010 0000	34.870	0000 0010 1110 0010
33.890	0000 0010 0001 1110	34.220	0000 0010 0110 0000	34.550	0000 0010 1010 0010	34.880	0000 0010 1110 0100
33.900	0000 0010 0010 0000	34.230	0000 0010 0110 0010	34.560	0000 0010 1010 0100	34.890	0000 0010 1110 0110
33.910	0000 0010 0010 0010	34.240	0000 0010 0110 0100	34.570	0000 0010 1010 0110	34.900	0000 0010 1110 1000
33.920	0000 0010 0010 0100	34.250	0000 0010 0110 0110	34.580	0000 0010 1010 1000	34.910	0000 0010 1110 1010
33.930	0000 0010 0010 0110	34.260	0000 0010 0110 1000	34.590	0000 0010 1010 1010	34.920	0000 0010 1110 1100
33.940	0000 0010 0010 1000	34.270	0000 0010 0110 1010	34.600	0000 0010 1010 1100	34.930	0000 0010 1110 1110
33.950	0000 0010 0010 1010	34.280	0000 0010 0110 1100	34.610	0000 0010 1010 1110	34.940	0000 0010 1111 0000
33.960	0000 0010 0010 1100	34.290	0000 0010 0110 1110	34.620	0000 0010 1011 0000	34.950	0000 0010 1111 0010
33.970	0000 0010 0010 1110	34.300	0000 0010 0111 0000	34.630	0000 0010 1011 0010	34.960	0000 0010 1111 0100
33.980	0000 0010 0011 0000	34.310	0000 0010 0111 0010	34.640	0000 0010 1011 0100	34.970	0000 0010 1111 0110
33.990	0000 0010 0011 0010	34.320	0000 0010 0111 0100	34.650	0000 0010 1011 0110	34.980	0000 0010 1111 1000
34.000	0000 0010 0011 0100	34.330	0000 0010 0111 0110	34.660	0000 0010 1011 1000	34.990	0000 0010 1111 1010
34.010	0000 0010 0011 0110	34.340	0000 0010 0111 1000	34.670	0000 0010 1011 1010	35.000	0000 0010 1111 1100
34.020	0000 0010 0011 1000	34.350	0000 0010 0111 1010	34.680	0000 0010 1011 1100	35.010	0000 0010 1111 1110
34.030	0000 0010 0011 1010	34.360	0000 0010 0111 1100	34.690	0000 0010 1011 1110	35.020	0000 0011 0000 0000
34.040	0000 0010 0011 1100	34.370	0000 0010 0111 1110	34.700	0000 0010 1100 0000	35.030	0000 0011 0000 0010
34.050	0000 0010 0011 1110	34.380	0000 0010 1000 0000	34.710	0000 0010 1100 0010	35.040	0000 0011 0000 0100
34.060	0000 0010 0100 0000	34.390	0000 0010 1000 0010	34.720	0000 0010 1100 0100	35.050	0000 0011 0000 0110
34.070	0000 0010 0100 0010	34.400	0000 0010 1000 0100	34.730	0000 0010 1100 0110	35.060	0000 0011 0000 1000
34.080	0000 0010 0100 0100	34.410	0000 0010 1000 0110	34.740	0000 0010 1100 1000	35.070	0000 0011 0000 1010
34.090	0000 0010 0100 0110	34.420	0000 0010 1000 1000	34.750	0000 0010 1100 1010	35.080	0000 0011 0000 1100
34.100	0000 0010 0100 1000	34.430	0000 0010 1000 1010	34.760	0000 0010 1100 1100	35.090	0000 0011 0000 1110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
35.100	0000 0011 0001 0000	35.430	0000 0011 0101 0010	35.760	0000 0011 1001 0100	36.090	0000 0011 1101 0110
35.110	0000 0011 0001 0010	35.440	0000 0011 0101 0100	35.770	0000 0011 1001 0110	36.100	0000 0011 1101 1000
35.120	0000 0011 0001 0100	35.450	0000 0011 0101 0110	35.780	0000 0011 1001 1000	36.110	0000 0011 1101 1010
35.130	0000 0011 0001 0110	35.460	0000 0011 0101 1000	35.790	0000 0011 1001 1010	36.120	0000 0011 1101 1100
35.140	0000 0011 0001 1000	35.470	0000 0011 0101 1010	35.800	0000 0011 1001 1100	36.130	0000 0011 1101 1110
35.150	0000 0011 0001 1010	35.480	0000 0011 0101 1100	35.810	0000 0011 1001 1110	36.140	0000 0011 1110 0000
35.160	0000 0011 0001 1100	35.490	0000 0011 0101 1110	35.820	0000 0011 1010 0000	36.150	0000 0011 1110 0010
35.170	0000 0011 0001 1110	35.500	0000 0011 0110 0000	35.830	0000 0011 1010 0010	36.160	0000 0011 1110 0100
35.180	0000 0011 0010 0000	35.510	0000 0011 0110 0010	35.840	0000 0011 1010 0100	36.170	0000 0011 1110 0110
35.190	0000 0011 0010 0010	35.520	0000 0011 0110 0100	35.850	0000 0011 1010 0110	36.180	0000 0011 1110 1000
35.200	0000 0011 0010 0100	35.530	0000 0011 0110 0110	35.860	0000 0011 1010 1000	36.190	0000 0011 1110 1010
35.210	0000 0011 0010 0110	35.540	0000 0011 0110 1000	35.870	0000 0011 1010 1010	36.200	0000 0011 1110 1100
35.220	0000 0011 0010 1000	35.550	0000 0011 0110 1010	35.880	0000 0011 1010 1100	36.210	0000 0011 1110 1110
35.230	0000 0011 0010 1010	35.560	0000 0011 0110 1100	35.890	0000 0011 1010 1110	36.220	0000 0011 1111 0000
35.240	0000 0011 0010 1100	35.570	0000 0011 0110 1110	35.900	0000 0011 1011 0000	36.230	0000 0011 1111 0010
35.250	0000 0011 0010 1110	35.580	0000 0011 0111 0000	35.910	0000 0011 1011 0010	36.240	0000 0011 1111 0100
35.260	0000 0011 0011 0000	35.590	0000 0011 0111 0010	35.920	0000 0011 1011 0100	36.250	0000 0011 1111 0110
35.270	0000 0011 0011 0010	35.600	0000 0011 0111 0100	35.930	0000 0011 1011 0110	36.260	0000 0011 1111 1000
35.280	0000 0011 0011 0100	35.610	0000 0011 0111 0110	35.940	0000 0011 1011 1000	36.270	0000 0011 1111 1010
35.290	0000 0011 0011 0110	35.620	0000 0011 0111 1000	35.950	0000 0011 1011 1010	36.280	0000 0011 1111 1100
35.300	0000 0011 0011 1000	35.630	0000 0011 0111 1010	35.960	0000 0011 1011 1100	36.290	0000 0011 1111 1110
35.310	0000 0011 0011 1010	35.640	0000 0011 0111 1100	35.970	0000 0011 1011 1110	36.300	0000 0100 0000 0000
35.320	0000 0011 0011 1100	35.650	0000 0011 0111 1110	35.980	0000 0011 1100 0000	36.310	0000 0100 0000 0010
35.330	0000 0011 0011 1110	35.660	0000 0011 1000 0000	35.990	0000 0011 1100 0010	36.320	0000 0100 0000 0100
35.340	0000 0011 0100 0000	35.670	0000 0011 1000 0010	36.000	0000 0011 1100 0100	36.330	0000 0100 0000 0110
35.350	0000 0011 0100 0010	35.680	0000 0011 1000 0100	36.010	0000 0011 1100 0110	36.340	0000 0100 0000 1000
35.360	0000 0011 0100 0100	35.690	0000 0011 1000 0110	36.020	0000 0011 1100 1000	36.350	0000 0100 0000 1010
35.370	0000 0011 0100 0110	35.700	0000 0011 1000 1000	36.030	0000 0011 1100 1010	36.360	0000 0100 0000 1100
35.380	0000 0011 0100 1000	35.710	0000 0011 1000 1010	36.040	0000 0011 1100 1100	36.370	0000 0100 0000 1110
35.390	0000 0011 0100 1010	35.720	0000 0011 1000 1100	36.050	0000 0011 1100 1110	36.380	0000 0100 0001 0000
35.400	0000 0011 0100 1100	35.730	0000 0011 1000 1110	36.060	0000 0011 1101 0000	36.390	0000 0100 0001 0010
35.410	0000 0011 0100 1110	35.740	0000 0011 1001 0000	36.070	0000 0011 1101 0010	36.400	0000 0100 0001 0100
35.420	0000 0011 0101 0000	35.750	0000 0011 1001 0010	36.080	0000 0011 1101 0100	36.410	0000 0100 0001 0110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
36.420	0000 0100 0001 1000	36.750	0000 0100 0101 1010	37.080	0000 0100 1001 1100	37.410	0000 0100 1101 1110
36.430	0000 0100 0001 1010	36.760	0000 0100 0101 1100	37.090	0000 0100 1001 1110	37.420	0000 0100 1110 0000
36.440	0000 0100 0001 1100	36.770	0000 0100 0101 1110	37.100	0000 0100 1010 0000	37.430	0000 0100 1110 0010
36.450	0000 0100 0001 1110	36.780	0000 0100 0110 0000	37.110	0000 0100 1010 0010	37.440	0000 0100 1110 0100
36.460	0000 0100 0010 0000	36.790	0000 0100 0110 0010	37.120	0000 0100 1010 0100	37.450	0000 0100 1110 0110
36.470	0000 0100 0010 0010	36.800	0000 0100 0110 0100	37.130	0000 0100 1010 0110	37.460	0000 0100 1110 1000
36.480	0000 0100 0010 0100	36.810	0000 0100 0110 0110	37.140	0000 0100 1010 1000	37.470	0000 0100 1110 1010
36.490	0000 0100 0010 0110	36.820	0000 0100 0110 1000	37.150	0000 0100 1010 1010	37.480	0000 0100 1110 1100
36.500	0000 0100 0010 1000	36.830	0000 0100 0110 1010	37.160	0000 0100 1010 1100	37.490	0000 0100 1110 1110
36.510	0000 0100 0010 1010	36.840	0000 0100 0110 1100	37.170	0000 0100 1010 1110	37.500	0000 0100 1111 0000
36.520	0000 0100 0010 1100	36.850	0000 0100 0110 1110	37.180	0000 0100 1011 0000	37.510	0000 0100 1111 0010
36.530	0000 0100 0010 1110	36.860	0000 0100 0111 0000	37.190	0000 0100 1011 0010	37.520	0000 0100 1111 0100
36.540	0000 0100 0011 0000	36.870	0000 0100 0111 0010	37.200	0000 0100 1011 0100	37.530	0000 0100 1111 0110
36.550	0000 0100 0011 0010	36.880	0000 0100 0111 0100	37.210	0000 0100 1011 0110	37.540	0000 0100 1111 1000
36.560	0000 0100 0011 0100	36.890	0000 0100 0111 0110	37.220	0000 0100 1011 1000	37.550	0000 0100 1111 1010
36.570	0000 0100 0011 0110	36.900	0000 0100 0111 1000	37.230	0000 0100 1011 1010	37.560	0000 0100 1111 1100
36.580	0000 0100 0011 1000	36.910	0000 0100 0111 1010	37.240	0000 0100 1011 1100	37.570	0000 0100 1111 1110
36.590	0000 0100 0011 1010	36.920	0000 0100 0111 1100	37.250	0000 0100 1011 1110	37.580	0000 0101 0000 0000
36.600	0000 0100 0011 1100	36.930	0000 0100 0111 1110	37.260	0000 0100 1100 0000	37.590	0000 0101 0000 0010
36.610	0000 0100 0011 1110	36.940	0000 0100 1000 0000	37.270	0000 0100 1100 0010	37.600	0000 0101 0000 0100
36.620	0000 0100 0100 0000	36.950	0000 0100 1000 0010	37.280	0000 0100 1100 0100	37.610	0000 0101 0000 0110
36.630	0000 0100 0100 0010	36.960	0000 0100 1000 0100	37.290	0000 0100 1100 0110	37.620	0000 0101 0000 1000
36.640	0000 0100 0100 0100	36.970	0000 0100 1000 0110	37.300	0000 0100 1100 1000	37.630	0000 0101 0000 1010
36.650	0000 0100 0100 0110	36.980	0000 0100 1000 1000	37.310	0000 0100 1100 1010	37.640	0000 0101 0000 1100
36.660	0000 0100 0100 1000	36.990	0000 0100 1000 1010	37.320	0000 0100 1100 1100	37.650	0000 0101 0000 1110
36.670	0000 0100 0100 1010	37.000	0000 0100 1000 1100	37.330	0000 0100 1100 1110	37.660	0000 0101 0001 0000
36.680	0000 0100 0100 1100	37.010	0000 0100 1000 1110	37.340	0000 0100 1101 0000	37.670	0000 0101 0001 0010
36.690	0000 0100 0100 1110	37.020	0000 0100 1001 0000	37.350	0000 0100 1101 0010	37.680	0000 0101 0001 0100
36.700	0000 0100 0101 0000	37.030	0000 0100 1001 0010	37.360	0000 0100 1101 0100	37.690	0000 0101 0001 0110
36.710	0000 0100 0101 0010	37.040	0000 0100 1001 0100	37.370	0000 0100 1101 0110	37.700	0000 0101 0001 1000
36.720	0000 0100 0101 0100	37.050	0000 0100 1001 0110	37.380	0000 0100 1101 1000	37.710	0000 0101 0001 1010
36.730	0000 0100 0101 0110	37.060	0000 0100 1001 1000	37.390	0000 0100 1101 1010	37.720	0000 0101 0001 1100
36.740	0000 0100 0101 1000	37.070	0000 0100 1001 1010	37.400	0000 0100 1101 1100	37.730	0000 0101 0001 1110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
37.740	0000 0101 0010 0000	38.070	0000 0101 0110 0010	38.400	0000 0101 1010 0100	38.730	0000 0101 1110 0110
37.750	0000 0101 0010 0010	38.080	0000 0101 0110 0100	38.410	0000 0101 1010 0110	38.740	0000 0101 1110 1000
37.760	0000 0101 0010 0100	38.090	0000 0101 0110 0110	38.420	0000 0101 1010 1000	38.750	0000 0101 1110 1010
37.770	0000 0101 0010 0110	38.100	0000 0101 0110 1000	38.430	0000 0101 1010 1010	38.760	0000 0101 1110 1100
37.780	0000 0101 0010 1000	38.110	0000 0101 0110 1010	38.440	0000 0101 1010 1100	38.770	0000 0101 1110 1110
37.790	0000 0101 0010 1010	38.120	0000 0101 0110 1100	38.450	0000 0101 1010 1110	38.780	0000 0101 1111 0000
37.800	0000 0101 0010 1100	38.130	0000 0101 0110 1110	38.460	0000 0101 1011 0000	38.790	0000 0101 1111 0010
37.810	0000 0101 0010 1110	38.140	0000 0101 0111 0000	38.470	0000 0101 1011 0010	38.800	0000 0101 1111 0100
37.820	0000 0101 0011 0000	38.150	0000 0101 0111 0010	38.480	0000 0101 1011 0100	38.810	0000 0101 1111 0110
37.830	0000 0101 0011 0010	38.160	0000 0101 0111 0100	38.490	0000 0101 1011 0110	38.820	0000 0101 1111 1000
37.840	0000 0101 0011 0100	38.170	0000 0101 0111 0110	38.500	0000 0101 1011 1000	38.830	0000 0101 1111 1010
37.850	0000 0101 0011 0110	38.180	0000 0101 0111 1000	38.510	0000 0101 1011 1010	38.840	0000 0101 1111 1100
37.860	0000 0101 0011 1000	38.190	0000 0101 0111 1010	38.520	0000 0101 1011 1100	38.850	0000 0101 1111 1110
37.870	0000 0101 0011 1010	38.200	0000 0101 0111 1100	38.530	0000 0101 1011 1110	38.860	0000 0110 0000 0000
37.880	0000 0101 0011 1100	38.210	0000 0101 0111 1110	38.540	0000 0101 1100 0000	38.870	0000 0110 0000 0010
37.890	0000 0101 0011 1110	38.220	0000 0101 1000 0000	38.550	0000 0101 1100 0010	38.880	0000 0110 0000 0100
37.900	0000 0101 0100 0000	38.230	0000 0101 1000 0010	38.560	0000 0101 1100 0100	38.890	0000 0110 0000 0110
37.910	0000 0101 0100 0010	38.240	0000 0101 1000 0100	38.570	0000 0101 1100 0110	38.900	0000 0110 0000 1000
37.920	0000 0101 0100 0100	38.250	0000 0101 1000 0110	38.580	0000 0101 1100 1000	38.910	0000 0110 0000 1010
37.930	0000 0101 0100 0110	38.260	0000 0101 1000 1000	38.590	0000 0101 1100 1010	38.920	0000 0110 0000 1100
37.940	0000 0101 0100 1000	38.270	0000 0101 1000 1010	38.600	0000 0101 1100 1100	38.930	0000 0110 0000 1110
37.950	0000 0101 0100 1010	38.280	0000 0101 1000 1100	38.610	0000 0101 1100 1110	38.940	0000 0110 0001 0000
37.960	0000 0101 0100 1100	38.290	0000 0101 1000 1110	38.620	0000 0101 1101 0000	38.950	0000 0110 0001 0010
37.970	0000 0101 0100 1110	38.300	0000 0101 1001 0000	38.630	0000 0101 1101 0010	38.960	0000 0110 0001 0100
37.980	0000 0101 0101 0000	38.310	0000 0101 1001 0010	38.640	0000 0101 1101 0100	38.970	0000 0110 0001 0110
37.990	0000 0101 0101 0010	38.320	0000 0101 1001 0100	38.650	0000 0101 1101 0110	38.980	0000 0110 0001 1000
38.000	0000 0101 0101 0100	38.330	0000 0101 1001 0110	38.660	0000 0101 1101 1000	38.990	0000 0110 0001 1010
38.010	0000 0101 0101 0110	38.340	0000 0101 1001 1000	38.670	0000 0101 1101 1010	39.000	0000 0110 0001 1100
38.020	0000 0101 0101 1000	38.350	0000 0101 1001 1010	38.680	0000 0101 1101 1100	39.010	0000 0110 0001 1110
38.030	0000 0101 0101 1010	38.360	0000 0101 1001 1100	38.690	0000 0101 1101 1110	39.020	0000 0110 0010 0000
38.040	0000 0101 0101 1100	38.370	0000 0101 1001 1110	38.700	0000 0101 1110 0000	39.030	0000 0110 0010 0010
38.050	0000 0101 0101 1110	38.380	0000 0101 1010 0000	38.710	0000 0101 1110 0010	39.040	0000 0110 0010 0100
38.060	0000 0101 0110 0000	38.390	0000 0101 1010 0010	38.720	0000 0101 1110 0100	39.050	0000 0110 0010 0110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
39.060	0000 0110 0010 1000	39.390	0000 0110 0110 1010	39.720	0000 0110 1010 1100	40.050	0000 0110 1110 1110
39.070	0000 0110 0010 1010	39.400	0000 0110 0110 1100	39.730	0000 0110 1010 1110	40.060	0000 0110 1111 0000
39.080	0000 0110 0010 1100	39.410	0000 0110 0110 1110	39.740	0000 0110 1011 0000	40.070	0000 0110 1111 0010
39.090	0000 0110 0010 1110	39.420	0000 0110 0111 0000	39.750	0000 0110 1011 0010	40.080	0000 0110 1111 0100
39.100	0000 0110 0011 0000	39.430	0000 0110 0111 0010	39.760	0000 0110 1011 0100	40.090	0000 0110 1111 0110
39.110	0000 0110 0011 0010	39.440	0000 0110 0111 0100	39.770	0000 0110 1011 0110	40.100	0000 0110 1111 1000
39.120	0000 0110 0011 0100	39.450	0000 0110 0111 0110	39.780	0000 0110 1011 1000	40.110	0000 0110 1111 1010
39.130	0000 0110 0011 0110	39.460	0000 0110 0111 1000	39.790	0000 0110 1011 1010	40.120	0000 0110 1111 1100
39.140	0000 0110 0011 1000	39.470	0000 0110 0111 1010	39.800	0000 0110 1011 1100	40.130	0000 0110 1111 1110
39.150	0000 0110 0011 1010	39.480	0000 0110 0111 1100	39.810	0000 0110 1011 1110	40.140	0000 0111 0000 0000
39.160	0000 0110 0011 1100	39.490	0000 0110 0111 1110	39.820	0000 0110 1100 0000	40.150	0000 0111 0000 0010
39.170	0000 0110 0011 1110	39.500	0000 0110 1000 0000	39.830	0000 0110 1100 0010	40.160	0000 0111 0000 0100
39.180	0000 0110 0100 0000	39.510	0000 0110 1000 0010	39.840	0000 0110 1100 0100	40.170	0000 0111 0000 0110
39.190	0000 0110 0100 0010	39.520	0000 0110 1000 0100	39.850	0000 0110 1100 0110	40.180	0000 0111 0000 1000
39.200	0000 0110 0100 0100	39.530	0000 0110 1000 0110	39.860	0000 0110 1100 1000	40.190	0000 0111 0000 1010
39.210	0000 0110 0100 0110	39.540	0000 0110 1000 1000	39.870	0000 0110 1100 1010	40.200	0000 0111 0000 1100
39.220	0000 0110 0100 1000	39.550	0000 0110 1000 1010	39.880	0000 0110 1100 1100	40.210	0000 0111 0000 1110
39.230	0000 0110 0100 1010	39.560	0000 0110 1000 1100	39.890	0000 0110 1100 1110	40.220	0000 0111 0001 0000
39.240	0000 0110 0100 1100	39.570	0000 0110 1000 1110	39.900	0000 0110 1101 0000	40.230	0000 0111 0001 0010
39.250	0000 0110 0100 1110	39.580	0000 0110 1001 0000	39.910	0000 0110 1101 0010	40.240	0000 0111 0001 0100
39.260	0000 0110 0101 0000	39.590	0000 0110 1001 0010	39.920	0000 0110 1101 0100	40.250	0000 0111 0001 0110
39.270	0000 0110 0101 0010	39.600	0000 0110 1001 0100	39.930	0000 0110 1101 0110	40.260	0000 0111 0001 1000
39.280	0000 0110 0101 0100	39.610	0000 0110 1001 0110	39.940	0000 0110 1101 1000	40.270	0000 0111 0001 1010
39.290	0000 0110 0101 0110	39.620	0000 0110 1001 1000	39.950	0000 0110 1101 1010	40.280	0000 0111 0001 1100
39.300	0000 0110 0101 1000	39.630	0000 0110 1001 1010	39.960	0000 0110 1101 1100	40.290	0000 0111 0001 1110
39.310	0000 0110 0101 1010	39.640	0000 0110 1001 1100	39.970	0000 0110 1101 1110	40.300	0000 0111 0010 0000
39.320	0000 0110 0101 1100	39.650	0000 0110 1001 1110	39.980	0000 0110 1110 0000	40.310	0000 0111 0010 0010
39.330	0000 0110 0101 1110	39.660	0000 0110 1010 0000	39.990	0000 0110 1110 0010	40.320	0000 0111 0010 0100
39.340	0000 0110 0110 0000	39.670	0000 0110 1010 0010	40.000	0000 0110 1110 0100	40.330	0000 0111 0010 0110
39.350	0000 0110 0110 0010	39.680	0000 0110 1010 0100	40.010	0000 0110 1110 0110	40.340	0000 0111 0010 1000
39.360	0000 0110 0110 0100	39.690	0000 0110 1010 0110	40.020	0000 0110 1110 1000	40.350	0000 0111 0010 1010
39.370	0000 0110 0110 0110	39.700	0000 0110 1010 1000	40.030	0000 0110 1110 1010	40.360	0000 0111 0010 1100
39.380	0000 0110 0110 1000	39.710	0000 0110 1010 1010	40.040	0000 0110 1110 1100	40.370	0000 0111 0010 1110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
40.380	0000 0111 0011 0000	40.710	0000 0111 0111 0010	41.040	0000 0111 1011 0100	41.370	0000 0111 1111 0110
40.390	0000 0111 0011 0010	40.720	0000 0111 0111 0100	41.050	0000 0111 1011 0110	41.380	0000 0111 1111 1000
40.400	0000 0111 0011 0100	40.730	0000 0111 0111 0110	41.060	0000 0111 1011 1000	41.390	0000 0111 1111 1010
40.410	0000 0111 0011 0110	40.740	0000 0111 0111 1000	41.070	0000 0111 1011 1010	41.400	0000 0111 1111 1100
40.420	0000 0111 0011 1000	40.750	0000 0111 0111 1010	41.080	0000 0111 1011 1100	41.410	0000 0111 1111 1110
40.430	0000 0111 0011 1010	40.760	0000 0111 0111 1100	41.090	0000 0111 1011 1110	41.420	0000 1000 0000 0000
40.440	0000 0111 0011 1100	40.770	0000 0111 0111 1110	41.100	0000 0111 1100 0000	41.430	0000 1000 0000 0010
40.450	0000 0111 0011 1110	40.780	0000 0111 1000 0000	41.110	0000 0111 1100 0010	41.440	0000 1000 0000 0100
40.460	0000 0111 0100 0000	40.790	0000 0111 1000 0010	41.120	0000 0111 1100 0100	41.450	0000 1000 0000 0110
40.470	0000 0111 0100 0010	40.800	0000 0111 1000 0100	41.130	0000 0111 1100 0110	41.460	0000 1000 0000 1000
40.480	0000 0111 0100 0100	40.810	0000 0111 1000 0110	41.140	0000 0111 1100 1000	41.470	0000 1000 0000 1010
40.490	0000 0111 0100 0110	40.820	0000 0111 1000 1000	41.150	0000 0111 1100 1010	41.480	0000 1000 0000 1100
40.500	0000 0111 0100 1000	40.830	0000 0111 1000 1010	41.160	0000 0111 1100 1100	41.490	0000 1000 0000 1110
40.510	0000 0111 0100 1010	40.840	0000 0111 1000 1100	41.170	0000 0111 1100 1110	41.500	0000 1000 0001 0000
40.520	0000 0111 0100 1100	40.850	0000 0111 1000 1110	41.180	0000 0111 1101 0000	41.510	0000 1000 0001 0010
40.530	0000 0111 0100 1110	40.860	0000 0111 1001 0000	41.190	0000 0111 1101 0010	41.520	0000 1000 0001 0100
40.540	0000 0111 0101 0000	40.870	0000 0111 1001 0010	41.200	0000 0111 1101 0100	41.530	0000 1000 0001 0110
40.550	0000 0111 0101 0010	40.880	0000 0111 1001 0100	41.210	0000 0111 1101 0110	41.540	0000 1000 0001 1000
40.560	0000 0111 0101 0100	40.890	0000 0111 1001 0110	41.220	0000 0111 1101 1000	41.550	0000 1000 0001 1010
40.570	0000 0111 0101 0110	40.900	0000 0111 1001 1000	41.230	0000 0111 1101 1010	41.560	0000 1000 0001 1100
40.580	0000 0111 0101 1000	40.910	0000 0111 1001 1010	41.240	0000 0111 1101 1100	41.570	0000 1000 0001 1110
40.590	0000 0111 0101 1010	40.920	0000 0111 1001 1100	41.250	0000 0111 1101 1110	41.580	0000 1000 0010 0000
40.600	0000 0111 0101 1100	40.930	0000 0111 1001 1110	41.260	0000 0111 1110 0000	41.590	0000 1000 0010 0010
40.610	0000 0111 0101 1110	40.940	0000 0111 1010 0000	41.270	0000 0111 1110 0010	41.600	0000 1000 0010 0100
40.620	0000 0111 0110 0000	40.950	0000 0111 1010 0010	41.280	0000 0111 1110 0100	41.610	0000 1000 0010 0110
40.630	0000 0111 0110 0010	40.960	0000 0111 1010 0100	41.290	0000 0111 1110 0110	41.620	0000 1000 0010 1000
40.640	0000 0111 0110 0100	40.970	0000 0111 1010 0110	41.300	0000 0111 1110 1000	41.630	0000 1000 0010 1010
40.650	0000 0111 0110 0110	40.980	0000 0111 1010 1000	41.310	0000 0111 1110 1010	41.640	0000 1000 0010 1100
40.660	0000 0111 0110 1000	40.990	0000 0111 1010 1010	41.320	0000 0111 1110 1100	41.650	0000 1000 0010 1110
40.670	0000 0111 0110 1010	41.000	0000 0111 1010 1100	41.330	0000 0111 1110 1110	41.660	0000 1000 0011 0000
40.680	0000 0111 0110 1100	41.010	0000 0111 1010 1110	41.340	0000 0111 1111 0000	41.670	0000 1000 0011 0010
40.690	0000 0111 0110 1110	41.020	0000 0111 1011 0000	41.350	0000 0111 1111 0010	41.680	0000 1000 0011 0100
40.700	0000 0111 0111 0000	41.030	0000 0111 1011 0010	41.360	0000 0111 1111 0100	41.690	0000 1000 0011 0110

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
41.700	0000	1000	0011	1000	42.030	0000	1000	0111	1010	42.360	0000	1000	1011	1100	42.690	0000	1000	1111	1110
41.710	0000	1000	0011	1010	42.040	0000	1000	0111	1100	42.370	0000	1000	1011	1110	42.700	0000	1001	0000	0000
41.720	0000	1000	0011	1100	42.050	0000	1000	0111	1110	42.380	0000	1000	1100	0000	42.710	0000	1001	0000	0010
41.730	0000	1000	0011	1110	42.060	0000	1000	1000	0000	42.390	0000	1000	1100	0010	42.720	0000	1001	0000	0100
41.740	0000	1000	0100	0000	42.070	0000	1000	1000	0010	42.400	0000	1000	1100	0100	42.730	0000	1001	0000	0110
41.750	0000	1000	0100	0010	42.080	0000	1000	1000	0100	42.410	0000	1000	1100	0110	42.740	0000	1001	0000	1000
41.760	0000	1000	0100	0100	42.090	0000	1000	1000	0110	42.420	0000	1000	1100	1000	42.750	0000	1001	0000	1010
41.770	0000	1000	0100	0110	42.100	0000	1000	1000	1000	42.430	0000	1000	1100	1010	42.760	0000	1001	0000	1100
41.780	0000	1000	0100	1000	42.110	0000	1000	1000	1010	42.440	0000	1000	1100	1100	42.770	0000	1001	0000	1110
41.790	0000	1000	0100	1010	42.120	0000	1000	1000	1100	42.450	0000	1000	1100	1110	42.780	0000	1001	0001	0000
41.800	0000	1000	0100	1100	42.130	0000	1000	1000	1110	42.460	0000	1000	1101	0000	42.790	0000	1001	0001	0010
41.810	0000	1000	0100	1110	42.140	0000	1000	1001	0000	42.470	0000	1000	1101	0010	42.800	0000	1001	0001	0100
41.820	0000	1000	0101	0000	42.150	0000	1000	1001	0010	42.480	0000	1000	1101	0100	42.810	0000	1001	0001	0110
41.830	0000	1000	0101	0010	42.160	0000	1000	1001	0100	42.490	0000	1000	1101	0110	42.820	0000	1001	0001	1000
41.840	0000	1000	0101	0100	42.170	0000	1000	1001	0110	42.500	0000	1000	1101	1000	42.830	0000	1001	0001	1010
41.850	0000	1000	0101	0110	42.180	0000	1000	1001	1000	42.510	0000	1000	1101	1010	42.840	0000	1001	0001	1100
41.860	0000	1000	0101	1000	42.190	0000	1000	1001	1010	42.520	0000	1000	1101	1100	42.850	0000	1001	0001	1110
41.870	0000	1000	0101	1010	42.200	0000	1000	1001	1100	42.530	0000	1000	1101	1110	42.860	0000	1001	0010	0000
41.880	0000	1000	0101	1100	42.210	0000	1000	1001	1110	42.540	0000	1000	1110	0000	42.870	0000	1001	0010	0010
41.890	0000	1000	0101	1110	42.220	0000	1000	1010	0000	42.550	0000	1000	1110	0010	42.880	0000	1001	0010	0100
41.900	0000	1000	0110	0000	42.230	0000	1000	1010	0010	42.560	0000	1000	1110	0100	42.890	0000	1001	0010	0110
41.910	0000	1000	0110	0010	42.240	0000	1000	1010	0100	42.570	0000	1000	1110	0110	42.900	0000	1001	0010	1000
41.920	0000	1000	0110	0100	42.250	0000	1000	1010	0110	42.580	0000	1000	1110	1000	42.910	0000	1001	0010	1010
41.930	0000	1000	0110	0110	42.260	0000	1000	1010	1000	42.590	0000	1000	1110	1010	42.920	0000	1001	0010	1100
41.940	0000	1000	0110	1000	42.270	0000	1000	1010	1010	42.600	0000	1000	1110	1100	42.930	0000	1001	0010	1110
41.950	0000	1000	0110	1010	42.280	0000	1000	1010	1100	42.610	0000	1000	1110	1110	42.940	0000	1001	0011	0000
41.960	0000	1000	0110	1100	42.290	0000	1000	1010	1110	42.620	0000	1000	1111	0000	42.950	0000	1001	0011	0010
41.970	0000	1000	0110	1110	42.300	0000	1000	1011	0000	42.630	0000	1000	1111	0010	42.960	0000	1001	0011	0100
41.980	0000	1000	0111	0000	42.310	0000	1000	1011	0010	42.640	0000	1000	1111	0100	42.970	0000	1001	0011	0110
41.990	0000	1000	0111	0010	42.320	0000	1000	1011	0100	42.650	0000	1000	1111	0110	42.980	0000	1001	0011	1000
42.000	0000	1000	0111	0100	42.330	0000	1000	1011	0110	42.660	0000	1000	1111	1000	42.990	0000	1001	0011	1010
42.010	0000	1000	0111	0110	42.340	0000	1000	1011	1000	42.670	0000	1000	1111	1010	43.000	0000	1001	0011	1100
42.020	0000	1000	0111	1000	42.350	0000	1000	1011	1010	42.680	0000	1000	1111	1100	43.010	0000	1001	0011	1110

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
43.020	0000	1001	0100	0000	43.350	0000	1001	1000	0010	43.680	0000	1001	1100	0100	44.010	0000	1010	0000	0110
43.030	0000	1001	0100	0010	43.360	0000	1001	1000	0100	43.690	0000	1001	1100	0110	44.020	0000	1010	0000	1000
43.040	0000	1001	0100	0100	43.370	0000	1001	1000	0110	43.700	0000	1001	1100	1000	44.030	0000	1010	0000	1010
43.050	0000	1001	0100	0110	43.380	0000	1001	1000	1000	43.710	0000	1001	1100	1010	44.040	0000	1010	0000	1100
43.060	0000	1001	0100	1000	43.390	0000	1001	1000	1010	43.720	0000	1001	1100	1100	44.050	0000	1010	0000	1110
43.070	0000	1001	0100	1010	43.400	0000	1001	1000	1100	43.730	0000	1001	1100	1110	44.060	0000	1010	0001	0000
43.080	0000	1001	0100	1100	43.410	0000	1001	1000	1110	43.740	0000	1001	1101	0000	44.070	0000	1010	0001	0010
43.090	0000	1001	0100	1110	43.420	0000	1001	1001	0000	43.750	0000	1001	1101	0010	44.080	0000	1010	0001	0100
43.100	0000	1001	0101	0000	43.430	0000	1001	1001	0010	43.760	0000	1001	1101	0100	44.090	0000	1010	0001	0110
43.110	0000	1001	0101	0010	43.440	0000	1001	1001	0100	43.770	0000	1001	1101	0110	44.100	0000	1010	0001	1000
43.120	0000	1001	0101	0100	43.450	0000	1001	1001	0110	43.780	0000	1001	1101	1000	44.110	0000	1010	0001	1010
43.130	0000	1001	0101	0110	43.460	0000	1001	1001	1000	43.790	0000	1001	1101	1010	44.120	0000	1010	0001	1100
43.140	0000	1001	0101	1000	43.470	0000	1001	1001	1010	43.800	0000	1001	1101	1100	44.130	0000	1010	0001	1110
43.150	0000	1001	0101	1010	43.480	0000	1001	1001	1100	43.810	0000	1001	1101	1110	44.140	0000	1010	0010	0000
43.160	0000	1001	0101	1100	43.490	0000	1001	1001	1110	43.820	0000	1001	1110	0000	44.150	0000	1010	0010	0010
43.170	0000	1001	0101	1110	43.500	0000	1001	1010	0000	43.830	0000	1001	1110	0010	44.160	0000	1010	0010	0100
43.180	0000	1001	0110	0000	43.510	0000	1001	1010	0010	43.840	0000	1001	1110	0100	44.170	0000	1010	0010	0110
43.190	0000	1001	0110	0010	43.520	0000	1001	1010	0100	43.850	0000	1001	1110	0110	44.180	0000	1010	0010	1000
43.200	0000	1001	0110	0100	43.530	0000	1001	1010	0110	43.860	0000	1001	1110	1000	44.190	0000	1010	0010	1010
43.210	0000	1001	0110	0110	43.540	0000	1001	1010	1000	43.870	0000	1001	1110	1010	44.200	0000	1010	0010	1100
43.220	0000	1001	0110	1000	43.550	0000	1001	1010	1010	43.880	0000	1001	1110	1100	44.210	0000	1010	0010	1110
43.230	0000	1001	0110	1010	43.560	0000	1001	1010	1100	43.890	0000	1001	1110	1110	44.220	0000	1010	0011	0000
43.240	0000	1001	0110	1100	43.570	0000	1001	1010	1110	43.900	0000	1001	1111	0000	44.230	0000	1010	0011	0010
43.250	0000	1001	0110	1110	43.580	0000	1001	1011	0000	43.910	0000	1001	1111	0010	44.240	0000	1010	0011	0100
43.260	0000	1001	0111	0000	43.590	0000	1001	1011	0010	43.920	0000	1001	1111	0100	44.250	0000	1010	0011	0110
43.270	0000	1001	0111	0010	43.600	0000	1001	1011	0100	43.930	0000	1001	1111	0110	44.260	0000	1010	0011	1000
43.280	0000	1001	0111	0100	43.610	0000	1001	1011	0110	43.940	0000	1001	1111	1000	44.270	0000	1010	0011	1010
43.290	0000	1001	0111	0110	43.620	0000	1001	1011	1000	43.950	0000	1001	1111	1010	44.280	0000	1010	0011	1100
43.300	0000	1001	0111	1000	43.630	0000	1001	1011	1010	43.960	0000	1001	1111	1100	44.290	0000	1010	0011	1110
43.310	0000	1001	0111	1010	43.640	0000	1001	1011	1100	43.970	0000	1001	1111	1110	44.300	0000	1010	0100	0000
43.320	0000	1001	0111	1100	43.650	0000	1001	1011	1110	43.980	0000	1010	0000	0000	44.310	0000	1010	0100	0010
43.330	0000	1001	0111	1110	43.660	0000	1001	1100	0000	43.990	0000	1010	0000	0010	44.320	0000	1010	0100	0100
43.340	0000	1001	1000	0000	43.670	0000	1001	1100	0010	44.000	0000	1010	0000	0100	44.330	0000	1010	0100	0110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
44.340	0000 1010 0100 1000	44.670	0000 1010 1000 1010	45.000	0000 1010 1100 1100	45.330	0000 1011 0000 1110
44.350	0000 1010 0100 1010	44.680	0000 1010 1000 1100	45.010	0000 1010 1100 1110	45.340	0000 1011 0001 0000
44.360	0000 1010 0100 1100	44.690	0000 1010 1000 1110	45.020	0000 1010 1101 0000	45.350	0000 1011 0001 0010
44.370	0000 1010 0100 1110	44.700	0000 1010 1001 0000	45.030	0000 1010 1101 0010	45.360	0000 1011 0001 0100
44.380	0000 1010 0101 0000	44.710	0000 1010 1001 0010	45.040	0000 1010 1101 0100	45.370	0000 1011 0001 0110
44.390	0000 1010 0101 0010	44.720	0000 1010 1001 0100	45.050	0000 1010 1101 0110	45.380	0000 1011 0001 1000
44.400	0000 1010 0101 0100	44.730	0000 1010 1001 0110	45.060	0000 1010 1101 1000	45.390	0000 1011 0001 1010
44.410	0000 1010 0101 0110	44.740	0000 1010 1001 1000	45.070	0000 1010 1101 1010	45.400	0000 1011 0001 1100
44.420	0000 1010 0101 1000	44.750	0000 1010 1001 1010	45.080	0000 1010 1101 1100	45.410	0000 1011 0001 1110
44.430	0000 1010 0101 1010	44.760	0000 1010 1001 1100	45.090	0000 1010 1101 1110	45.420	0000 1011 0010 0000
44.440	0000 1010 0101 1100	44.770	0000 1010 1001 1110	45.100	0000 1010 1110 0000	45.430	0000 1011 0010 0010
44.450	0000 1010 0101 1110	44.780	0000 1010 1010 0000	45.110	0000 1010 1110 0010	45.440	0000 1011 0010 0100
44.460	0000 1010 0110 0000	44.790	0000 1010 1010 0010	45.120	0000 1010 1110 0100	45.450	0000 1011 0010 0110
44.470	0000 1010 0110 0010	44.800	0000 1010 1010 0100	45.130	0000 1010 1110 0110	45.460	0000 1011 0010 1000
44.480	0000 1010 0110 0100	44.810	0000 1010 1010 0110	45.140	0000 1010 1110 1000	45.470	0000 1011 0010 1010
44.490	0000 1010 0110 0110	44.820	0000 1010 1010 1000	45.150	0000 1010 1110 1010	45.480	0000 1011 0010 1100
44.500	0000 1010 0110 1000	44.830	0000 1010 1010 1010	45.160	0000 1010 1110 1100	45.490	0000 1011 0010 1110
44.510	0000 1010 0110 1010	44.840	0000 1010 1010 1100	45.170	0000 1010 1110 1110	45.500	0000 1011 0011 0000
44.520	0000 1010 0110 1100	44.850	0000 1010 1010 1110	45.180	0000 1010 1111 0000	45.510	0000 1011 0011 0010
44.530	0000 1010 0110 1110	44.860	0000 1010 1011 0000	45.190	0000 1010 1111 0010	45.520	0000 1011 0011 0100
44.540	0000 1010 0111 0000	44.870	0000 1010 1011 0010	45.200	0000 1010 1111 0100	45.530	0000 1011 0011 0110
44.550	0000 1010 0111 0010	44.880	0000 1010 1011 0100	45.210	0000 1010 1111 0110	45.540	0000 1011 0011 1000
44.560	0000 1010 0111 0100	44.890	0000 1010 1011 0110	45.220	0000 1010 1111 1000	45.550	0000 1011 0011 1010
44.570	0000 1010 0111 0110	44.900	0000 1010 1011 1000	45.230	0000 1010 1111 1010	45.560	0000 1011 0011 1100
44.580	0000 1010 0111 1000	44.910	0000 1010 1011 1010	45.240	0000 1010 1111 1100	45.570	0000 1011 0011 1110
44.590	0000 1010 0111 1010	44.920	0000 1010 1011 1100	45.250	0000 1010 1111 1110	45.580	0000 1011 0100 0000
44.600	0000 1010 0111 1100	44.930	0000 1010 1011 1110	45.260	0000 1011 0000 0000	45.590	0000 1011 0100 0010
44.610	0000 1010 0111 1110	44.940	0000 1010 1100 0000	45.270	0000 1011 0000 0010	45.600	0000 1011 0100 0100
44.620	0000 1010 1000 0000	44.950	0000 1010 1100 0010	45.280	0000 1011 0000 0100	45.610	0000 1011 0100 0110
44.630	0000 1010 1000 0010	44.960	0000 1010 1100 0100	45.290	0000 1011 0000 0110	45.620	0000 1011 0100 1000
44.640	0000 1010 1000 0100	44.970	0000 1010 1100 0110	45.300	0000 1011 0000 1000	45.630	0000 1011 0100 1010
44.650	0000 1010 1000 0110	44.980	0000 1010 1100 1000	45.310	0000 1011 0000 1010	45.640	0000 1011 0100 1100
44.660	0000 1010 1000 1000	44.990	0000 1010 1100 1010	45.320	0000 1011 0000 1100	45.650	0000 1011 0100 1110

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
45.660	0000	1011	0101	0000	45.990	0000	1011	1001	0010	46.320	0000	1011	1101	0100	46.650	0000	1100	0001	0110
45.670	0000	1011	0101	0010	46.000	0000	1011	1001	0100	46.330	0000	1011	1101	0110	46.660	0000	1100	0001	1000
45.680	0000	1011	0101	0100	46.010	0000	1011	1001	0110	46.340	0000	1011	1101	1000	46.670	0000	1100	0001	1010
45.690	0000	1011	0101	0110	46.020	0000	1011	1001	1000	46.350	0000	1011	1101	1010	46.680	0000	1100	0001	1100
45.700	0000	1011	0101	1000	46.030	0000	1011	1001	1010	46.360	0000	1011	1101	1100	46.690	0000	1100	0001	1110
45.710	0000	1011	0101	1010	46.040	0000	1011	1001	1100	46.370	0000	1011	1101	1110	46.700	0000	1100	0010	0000
45.720	0000	1011	0101	1100	46.050	0000	1011	1001	1110	46.380	0000	1011	1110	0000	46.710	0000	1100	0010	0010
45.730	0000	1011	0101	1110	46.060	0000	1011	1010	0000	46.390	0000	1011	1110	0010	46.720	0000	1100	0010	0100
45.740	0000	1011	0110	0000	46.070	0000	1011	1010	0010	46.400	0000	1011	1110	0100	46.730	0000	1100	0010	0110
45.750	0000	1011	0110	0010	46.080	0000	1011	1010	0100	46.410	0000	1011	1110	0110	46.740	0000	1100	0010	1000
45.760	0000	1011	0110	0100	46.090	0000	1011	1010	0110	46.420	0000	1011	1110	1000	46.750	0000	1100	0010	1010
45.770	0000	1011	0110	0110	46.100	0000	1011	1010	1000	46.430	0000	1011	1110	1010	46.760	0000	1100	0010	1100
45.780	0000	1011	0110	1000	46.110	0000	1011	1010	1010	46.440	0000	1011	1110	1100	46.770	0000	1100	0010	1110
45.790	0000	1011	0110	1010	46.120	0000	1011	1010	1100	46.450	0000	1011	1110	1110	46.780	0000	1100	0011	0000
45.800	0000	1011	0110	1100	46.130	0000	1011	1010	1110	46.460	0000	1011	1111	0000	46.790	0000	1100	0011	0010
45.810	0000	1011	0110	1110	46.140	0000	1011	1011	0000	46.470	0000	1011	1111	0010	46.800	0000	1100	0011	0100
45.820	0000	1011	0111	0000	46.150	0000	1011	1011	0010	46.480	0000	1011	1111	0100	46.810	0000	1100	0011	0110
45.830	0000	1011	0111	0010	46.160	0000	1011	1011	0100	46.490	0000	1011	1111	0110	46.820	0000	1100	0011	1000
45.840	0000	1011	0111	0100	46.170	0000	1011	1011	0110	46.500	0000	1011	1111	1000	46.830	0000	1100	0011	1010
45.850	0000	1011	0111	0110	46.180	0000	1011	1011	1000	46.510	0000	1011	1111	1010	46.840	0000	1100	0011	1100
45.860	0000	1011	0111	1000	46.190	0000	1011	1011	1010	46.520	0000	1011	1111	1100	46.850	0000	1100	0011	1110
45.870	0000	1011	0111	1010	46.200	0000	1011	1011	1100	46.530	0000	1011	1111	1110	46.860	0000	1100	0100	0000
45.880	0000	1011	0111	1100	46.210	0000	1011	1011	1110	46.540	0000	1100	0000	0000	46.870	0000	1100	0100	0010
45.890	0000	1011	0111	1110	46.220	0000	1011	1100	0000	46.550	0000	1100	0000	0010	46.880	0000	1100	0100	0100
45.900	0000	1011	1000	0000	46.230	0000	1011	1100	0010	46.560	0000	1100	0000	0100	46.890	0000	1100	0100	0110
45.910	0000	1011	1000	0010	46.240	0000	1011	1100	0100	46.570	0000	1100	0000	0110	46.900	0000	1100	0100	1000
45.920	0000	1011	1000	0100	46.250	0000	1011	1100	0110	46.580	0000	1100	0000	1000	46.910	0000	1100	0100	1010
45.930	0000	1011	1000	0110	46.260	0000	1011	1100	1000	46.590	0000	1100	0000	1010	46.920	0000	1100	0100	1100
45.940	0000	1011	1000	1000	46.270	0000	1011	1100	1010	46.600	0000	1100	0000	1100	46.930	0000	1100	0100	1110
45.950	0000	1011	1000	1010	46.280	0000	1011	1100	1100	46.610	0000	1100	0000	1110	46.940	0000	1100	0101	0000
45.960	0000	1011	1000	1100	46.290	0000	1011	1100	1110	46.620	0000	1100	0001	0000	46.950	0000	1100	0101	0010
45.970	0000	1011	1000	1110	46.300	0000	1011	1101	0000	46.630	0000	1100	0001	0010	46.960	0000	1100	0101	0100
45.980	0000	1011	1001	0000	46.310	0000	1011	1101	0010	46.640	0000	1100	0001	0100	46.970	0000	1100	0101	0110

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
46.980	0000 1100 0101 1000	47.310	0000 1100 1001 1010	47.640	0000 1100 1101 1100	47.970	0000 1101 0001 1110
46.990	0000 1100 0101 1010	47.320	0000 1100 1001 1100	47.650	0000 1100 1101 1110	47.980	0000 1101 0010 0000
47.000	0000 1100 0101 1100	47.330	0000 1100 1001 1110	47.660	0000 1100 1110 0000	47.990	0000 1101 0010 0010
47.010	0000 1100 0101 1110	47.340	0000 1100 1010 0000	47.670	0000 1100 1110 0010	48.000	0000 1101 0010 0100
47.020	0000 1100 0110 0000	47.350	0000 1100 1010 0010	47.680	0000 1100 1110 0100	48.010	0000 1101 0010 0110
47.030	0000 1100 0110 0010	47.360	0000 1100 1010 0100	47.690	0000 1100 1110 0110	48.020	0000 1101 0010 1000
47.040	0000 1100 0110 0100	47.370	0000 1100 1010 0110	47.700	0000 1100 1110 1000	48.030	0000 1101 0010 1010
47.050	0000 1100 0110 0110	47.380	0000 1100 1010 1000	47.710	0000 1100 1110 1010	48.040	0000 1101 0010 1100
47.060	0000 1100 0110 1000	47.390	0000 1100 1010 1010	47.720	0000 1100 1110 1100	48.050	0000 1101 0010 1110
47.070	0000 1100 0110 1010	47.400	0000 1100 1010 1100	47.730	0000 1100 1110 1110	48.060	0000 1101 0011 0000
47.080	0000 1100 0110 1100	47.410	0000 1100 1010 1110	47.740	0000 1100 1111 0000	48.070	0000 1101 0011 0010
47.090	0000 1100 0110 1110	47.420	0000 1100 1011 0000	47.750	0000 1100 1111 0010	48.080	0000 1101 0011 0100
47.100	0000 1100 0111 0000	47.430	0000 1100 1011 0010	47.760	0000 1100 1111 0100	48.090	0000 1101 0011 0110
47.110	0000 1100 0111 0010	47.440	0000 1100 1011 0100	47.770	0000 1100 1111 0110	48.100	0000 1101 0011 1000
47.120	0000 1100 0111 0100	47.450	0000 1100 1011 0110	47.780	0000 1100 1111 1000	48.110	0000 1101 0011 1010
47.130	0000 1100 0111 0110	47.460	0000 1100 1011 1000	47.790	0000 1100 1111 1010	48.120	0000 1101 0011 1100
47.140	0000 1100 0111 1000	47.470	0000 1100 1011 1010	47.800	0000 1100 1111 1100	48.130	0000 1101 0011 1110
47.150	0000 1100 0111 1010	47.480	0000 1100 1011 1100	47.810	0000 1100 1111 1110	48.140	0000 1101 0100 0000
47.160	0000 1100 0111 1100	47.490	0000 1100 1011 1110	47.820	0000 1101 0000 0000	48.150	0000 1101 0100 0010
47.170	0000 1100 0111 1110	47.500	0000 1100 1100 0000	47.830	0000 1101 0000 0010	48.160	0000 1101 0100 0100
47.180	0000 1100 1000 0000	47.510	0000 1100 1100 0010	47.840	0000 1101 0000 0100	48.170	0000 1101 0100 0110
47.190	0000 1100 1000 0010	47.520	0000 1100 1100 0100	47.850	0000 1101 0000 0110	48.180	0000 1101 0100 1000
47.200	0000 1100 1000 0100	47.530	0000 1100 1100 0110	47.860	0000 1101 0000 1000	48.190	0000 1101 0100 1010
47.210	0000 1100 1000 0110	47.540	0000 1100 1100 1000	47.870	0000 1101 0000 1010	48.200	0000 1101 0100 1100
47.220	0000 1100 1000 1000	47.550	0000 1100 1100 1010	47.880	0000 1101 0000 1100	48.210	0000 1101 0100 1110
47.230	0000 1100 1000 1010	47.560	0000 1100 1100 1100	47.890	0000 1101 0000 1110	48.220	0000 1101 0101 0000
47.240	0000 1100 1000 1100	47.570	0000 1100 1100 1110	47.900	0000 1101 0001 0000	48.230	0000 1101 0101 0010
47.250	0000 1100 1000 1110	47.580	0000 1100 1101 0000	47.910	0000 1101 0001 0010	48.240	0000 1101 0101 0100
47.260	0000 1100 1001 0000	47.590	0000 1100 1101 0010	47.920	0000 1101 0001 0100	48.250	0000 1101 0101 0110
47.270	0000 1100 1001 0010	47.600	0000 1100 1101 0100	47.930	0000 1101 0001 0110	48.260	0000 1101 0101 1000
47.280	0000 1100 1001 0100	47.610	0000 1100 1101 0110	47.940	0000 1101 0001 1000	48.270	0000 1101 0101 1010
47.290	0000 1100 1001 0110	47.620	0000 1100 1101 1000	47.950	0000 1101 0001 1010	48.280	0000 1101 0101 1100
47.300	0000 1100 1001 1000	47.630	0000 1100 1101 1010	47.960	0000 1101 0001 1100	48.290	0000 1101 0101 1110

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
48.300	0000	1101	0110	0000	48.630	0000	1101	1010	0010	48.960	0000	1101	1110	0100	49.290	0000	1110	0010	0110
48.310	0000	1101	0110	0010	48.640	0000	1101	1010	0100	48.970	0000	1101	1110	0110	49.300	0000	1110	0010	1000
48.320	0000	1101	0110	0100	48.650	0000	1101	1010	0110	48.980	0000	1101	1110	1000	49.310	0000	1110	0010	1010
48.330	0000	1101	0110	0110	48.660	0000	1101	1010	1000	48.990	0000	1101	1110	1010	49.320	0000	1110	0010	1100
48.340	0000	1101	0110	1000	48.670	0000	1101	1010	1010	49.000	0000	1101	1110	1100	49.330	0000	1110	0010	1110
48.350	0000	1101	0110	1010	48.680	0000	1101	1010	1100	49.010	0000	1101	1110	1110	49.340	0000	1110	0011	0000
48.360	0000	1101	0110	1100	48.690	0000	1101	1010	1110	49.020	0000	1101	1111	0000	49.350	0000	1110	0011	0010
48.370	0000	1101	0110	1110	48.700	0000	1101	1011	0000	49.030	0000	1101	1111	0010	49.360	0000	1110	0011	0100
48.380	0000	1101	0111	0000	48.710	0000	1101	1011	0010	49.040	0000	1101	1111	0100	49.370	0000	1110	0011	0110
48.390	0000	1101	0111	0010	48.720	0000	1101	1011	0100	49.050	0000	1101	1111	0110	49.380	0000	1110	0011	1000
48.400	0000	1101	0111	0100	48.730	0000	1101	1011	0110	49.060	0000	1101	1111	1000	49.390	0000	1110	0011	1010
48.410	0000	1101	0111	0110	48.740	0000	1101	1011	1000	49.070	0000	1101	1111	1010	49.400	0000	1110	0011	1100
48.420	0000	1101	0111	1000	48.750	0000	1101	1011	1010	49.080	0000	1101	1111	1100	49.410	0000	1110	0011	1110
48.430	0000	1101	0111	1010	48.760	0000	1101	1011	1100	49.090	0000	1101	1111	1110	49.420	0000	1110	0100	0000
48.440	0000	1101	0111	1100	48.770	0000	1101	1011	1110	49.100	0000	1110	0000	0000	49.430	0000	1110	0100	0010
48.450	0000	1101	0111	1110	48.780	0000	1101	1100	0000	49.110	0000	1110	0000	0010	49.440	0000	1110	0100	0100
48.460	0000	1101	1000	0000	48.790	0000	1101	1100	0010	49.120	0000	1110	0000	0100	49.450	0000	1110	0100	0110
48.470	0000	1101	1000	0010	48.800	0000	1101	1100	0100	49.130	0000	1110	0000	0110	49.460	0000	1110	0100	1000
48.480	0000	1101	1000	0100	48.810	0000	1101	1100	0110	49.140	0000	1110	0000	1000	49.470	0000	1110	0100	1010
48.490	0000	1101	1000	0110	48.820	0000	1101	1100	1000	49.150	0000	1110	0000	1010	49.480	0000	1110	0100	1100
48.500	0000	1101	1000	1000	48.830	0000	1101	1100	1010	49.160	0000	1110	0000	1100	49.490	0000	1110	0100	1110
48.510	0000	1101	1000	1010	48.840	0000	1101	1100	1100	49.170	0000	1110	0000	1110	49.500	0000	1110	0101	0000
48.520	0000	1101	1000	1100	48.850	0000	1101	1100	1110	49.180	0000	1110	0001	0000	49.510	0000	1110	0101	0010
48.530	0000	1101	1000	1110	48.860	0000	1101	1101	0000	49.190	0000	1110	0001	0010	49.520	0000	1110	0101	0100
48.540	0000	1101	1001	0000	48.870	0000	1101	1101	0010	49.200	0000	1110	0001	0100	49.530	0000	1110	0101	0110
48.550	0000	1101	1001	0010	48.880	0000	1101	1101	0100	49.210	0000	1110	0001	0110	49.540	0000	1110	0101	1000
48.560	0000	1101	1001	0100	48.890	0000	1101	1101	0110	49.220	0000	1110	0001	1000	49.550	0000	1110	0101	1010
48.570	0000	1101	1001	0110	48.900	0000	1101	1101	1000	49.230	0000	1110	0001	1010	49.560	0000	1110	0101	1100
48.580	0000	1101	1001	1000	48.910	0000	1101	1101	1010	49.240	0000	1110	0001	1100	49.570	0000	1110	0101	1110
48.590	0000	1101	1001	1010	48.920	0000	1101	1101	1100	49.250	0000	1110	0001	1110	49.580	0000	1110	0110	0000
48.600	0000	1101	1001	1100	48.930	0000	1101	1101	1110	49.260	0000	1110	0010	0000	49.590	0000	1110	0110	0010
48.610	0000	1101	1001	1110	48.940	0000	1101	1110	0000	49.270	0000	1110	0010	0010	49.600	0000	1110	0110	0100
48.620	0000	1101	1010	0000	48.950	0000	1101	1110	0010	49.280	0000	1110	0010	0100	49.610	0000	1110	0110	0110

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
49.620	0000	1110	0110	1000	49.720	0000	1110	0111	1100	49.820	0000	1110	1001	0000	49.920	0000	1110	1010	0100
49.630	0000	1110	0110	1010	49.730	0000	1110	0111	1110	49.830	0000	1110	1001	0010	49.930	0000	1110	1010	0110
49.640	0000	1110	0110	1100	49.740	0000	1110	1000	0000	49.840	0000	1110	1001	0100	49.940	0000	1110	1010	1000
49.650	0000	1110	0110	1110	49.750	0000	1110	1000	0010	49.850	0000	1110	1001	0110	49.950	0000	1110	1010	1010
49.660	0000	1110	0111	0000	49.760	0000	1110	1000	0100	49.860	0000	1110	1001	1000	49.960	0000	1110	1010	1100
49.670	0000	1110	0111	0010	49.770	0000	1110	1000	0110	49.870	0000	1110	1001	1010	49.970	0000	1110	1010	1110
49.680	0000	1110	0111	0100	49.780	0000	1110	1000	1000	49.880	0000	1110	1001	1100	49.980	0000	1110	1011	0000
49.690	0000	1110	0111	0110	49.790	0000	1110	1000	1010	49.890	0000	1110	1001	1110	49.990	0000	1110	1011	0010
49.700	0000	1110	0111	1000	49.800	0000	1110	1000	1100	49.900	0000	1110	1010	0000	50.000	0000	1110	1011	0100
49.710	0000	1110	0111	1010	49.810	0000	1110	1000	1110	49.910	0000	1110	1010	0010					

146.000 to 148.000 MHz

Note: Though these frequencies can be received on your Memory Scan, optimum reception will not be obtained without retuning.

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
146.000	0010 1100 1010 1100	146.290	0010 1100 1110 0110	146.580	0010 1101 0010 0000	146.870	0010 1101 0101 1010
146.010	0010 1100 1010 1110	146.300	0010 1100 1110 1000	146.590	0010 1101 0010 0010	146.880	0010 1101 0101 1100
146.020	0010 1100 1011 0000	146.310	0010 1100 1110 1010	146.600	0010 1101 0010 0100	146.890	0010 1101 0101 1110
146.030	0010 1100 1011 0010	146.320	0010 1100 1110 1100	146.610	0010 1101 0010 0110	146.900	0010 1101 0110 0000
146.040	0010 1100 1011 0100	146.330	0010 1100 1110 1110	146.620	0010 1101 0010 1000	146.910	0010 1101 0110 0010
146.050	0010 1100 1011 0110	146.340	0010 1100 1111 0000	146.630	0010 1101 0010 1010	146.920	0010 1101 0110 0100
146.060	0010 1100 1011 1000	146.350	0010 1100 1111 0010	146.640	0010 1101 0010 1100	146.930	0010 1101 0110 0110
146.070	0010 1100 1011 1010	146.360	0010 1100 1111 0100	146.650	0010 1101 0010 1110	146.940	0010 1101 0110 1000
146.080	0010 1100 1011 1100	146.370	0010 1100 1111 0110	146.660	0010 1101 0011 0000	146.950	0010 1101 0110 1010
146.090	0010 1100 1011 1110	146.380	0010 1100 1111 1000	146.670	0010 1101 0011 0010	146.960	0010 1101 0110 1100
146.100	0010 1100 1100 0000	146.390	0010 1100 1111 1010	146.680	0010 1101 0011 0100	146.970	0010 1101 0110 1110
146.110	0010 1100 1100 0010	146.400	0010 1100 1111 1100	146.690	0010 1101 0011 0110	146.980	0010 1101 0111 0000
146.120	0010 1100 1100 0100	146.410	0010 1100 1111 1110	146.700	0010 1101 0011 1000	146.990	0010 1101 0111 0010
146.130	0010 1100 1100 0110	146.420	0010 1101 0000 0000	146.710	0010 1101 0011 1010	147.000	0010 1101 0111 0100
146.140	0010 1100 1100 1000	146.430	0010 1101 0000 0010	146.720	0010 1101 0011 1100	147.010	0010 1101 0111 0110
146.150	0010 1100 1100 1010	146.440	0010 1101 0000 0100	146.730	0010 1101 0011 1110	147.020	0010 1101 0111 1000
146.160	0010 1100 1100 1100	146.450	0010 1101 0000 0110	146.740	0010 1101 0100 0000	147.030	0010 1101 0111 1010
146.170	0010 1100 1100 1110	146.460	0010 1101 0000 1000	146.750	0010 1101 0100 0010	147.040	0010 1101 0111 1100
146.180	0010 1100 1101 0000	146.470	0010 1101 0000 1010	146.760	0010 1101 0100 0100	147.050	0010 1101 0111 1110
146.190	0010 1100 1101 0010	146.480	0010 1101 0000 1100	146.770	0010 1101 0100 0110	147.060	0010 1101 1000 0000
146.200	0010 1100 1101 0100	146.490	0010 1101 0000 1110	146.780	0010 1101 0100 1000	147.070	0010 1101 1000 0010
146.210	0010 1100 1101 0110	146.500	0010 1101 0001 0000	146.790	0010 1101 0100 1010	147.080	0010 1101 1000 0100
146.220	0010 1100 1101 1000	146.510	0010 1101 0001 0010	146.800	0010 1101 0100 1100	147.090	0010 1101 1000 0110
146.230	0010 1100 1101 1010	146.520	0010 1101 0001 0100	146.810	0010 1101 0100 1110	147.100	0010 1101 1000 1000
146.240	0010 1100 1101 1100	146.530	0010 1101 0001 0110	146.820	0010 1101 0101 0000	147.110	0010 1101 1000 1010
146.250	0010 1100 1101 1110	146.540	0010 1101 0001 1000	146.830	0010 1101 0101 0010	147.120	0010 1101 1000 1100
146.260	0010 1100 1110 0000	146.550	0010 1101 0001 1010	146.840	0010 1101 0101 0100	147.130	0010 1101 1000 1110
146.270	0010 1100 1110 0010	146.560	0010 1101 0001 1100	146.850	0010 1101 0101 0110	147.140	0010 1101 1001 0000
146.280	0010 1100 1110 0100	146.570	0010 1101 0001 1110	146.860	0010 1101 0101 1000	147.150	0010 1101 1001 0010

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
147.160	0010	1101	1001	0100	147.380	0010	1101	1100	0000	147.600	0010	1101	1110	1100	147.820	0010	1110	0001	1000
147.170	0010	1101	1001	0110	147.390	0010	1101	1100	0010	147.610	0010	1101	1110	1110	147.830	0010	1110	0001	1010
147.180	0010	1101	1001	1000	147.400	0010	1101	1100	0100	147.620	0010	1101	1111	0000	147.840	0010	1110	0001	1100
147.190	0010	1101	1001	1010	147.410	0010	1101	1100	0110	147.630	0010	1101	1111	0010	147.850	0010	1110	0001	1110
147.200	0010	1101	1001	1100	147.420	0010	1101	1100	1000	147.640	0010	1101	1111	0100	147.860	0010	1110	0010	0000
147.210	0010	1101	1001	1110	147.430	0010	1101	1100	1010	147.650	0010	1101	1111	0110	147.870	0010	1110	0010	0010
147.220	0010	1101	1010	0000	147.440	0010	1101	1100	1100	147.660	0010	1101	1111	1000	147.880	0010	1110	0010	0100
147.230	0010	1101	1010	0010	147.450	0010	1101	1100	1110	147.670	0010	1101	1111	1010	147.890	0010	1110	0010	0110
147.240	0010	1101	1010	0100	147.460	0010	1101	1101	0000	147.680	0010	1101	1111	1100	147.900	0010	1110	0010	1000
147.250	0010	1101	1010	0110	147.470	0010	1101	1101	0010	147.690	0010	1101	1111	1110	147.910	0010	1110	0010	1010
147.260	0010	1101	1010	1000	147.480	0010	1101	1101	0100	147.700	0010	1110	0000	0000	147.920	0010	1110	0010	1100
147.270	0010	1101	1010	1010	147.490	0010	1101	1101	0110	147.710	0010	1110	0000	0010	147.930	0010	1110	0010	1110
147.280	0010	1101	1010	1100	147.500	0010	1101	1101	1000	147.720	0010	1110	0000	0100	147.940	0010	1110	0011	0000
147.290	0010	1101	1010	1110	147.510	0010	1101	1101	1010	147.730	0010	1110	0000	0110	147.950	0010	1110	0011	0010
147.300	0010	1101	1011	0000	147.520	0010	1101	1101	1100	147.740	0010	1110	0000	1000	147.960	0010	1110	0011	0100
147.310	0010	1101	1011	0010	147.530	0010	1101	1101	1110	147.750	0010	1110	0000	1010	147.970	0010	1110	0011	0110
147.320	0010	1101	1011	0100	147.540	0010	1101	1110	0000	147.760	0010	1110	0000	1100	147.980	0010	1110	0011	1000
147.330	0010	1101	1011	0110	147.550	0010	1101	1110	0010	147.770	0010	1110	0000	1110	147.990	0010	1110	0011	1010
147.340	0010	1101	1011	1000	147.560	0010	1101	1110	0100	147.780	0010	1110	0001	0000	148.000	0010	1110	0011	1100
147.350	0010	1101	1011	1010	147.570	0010	1101	1110	0110	147.790	0010	1110	0001	0010					
147.360	0010	1101	1011	1100	147.580	0010	1101	1110	1000	147.800	0010	1110	0001	0100					
147.370	0010	1101	1011	1110	147.590	0010	1101	1110	1010	147.810	0010	1110	0001	0110					

HI BAND 151.180 to 170.000 MHz

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
151.180	0010 0000 0000 0000	151.335	0010 0000 0001 1111	151.490	0010 0000 0011 1110	151.645	0010 0000 0101 1101
151.185	0010 0000 0000 0001	151.340	0010 0000 0010 0000	151.495	0010 0000 0011 1111	151.650	0010 0000 0101 1110
151.190	0010 0000 0000 0010	151.345	0010 0000 0010 0001	151.500	0010 0000 0100 0000	151.655	0010 0000 0101 1111
151.195	0010 0000 0000 0011	151.350	0010 0000 0010 0010	151.505	0010 0000 0100 0001	151.660	0010 0000 0110 0000
151.200	0010 0000 0000 0100	151.355	0010 0000 0010 0011	151.510	0010 0000 0100 0010	151.665	0010 0000 0110 0001
151.205	0010 0000 0000 0101	151.360	0010 0000 0010 0100	151.515	0010 0000 0100 0011	151.670	0010 0000 0110 0010
151.210	0010 0000 0000 0110	151.365	0010 0000 0010 0101	151.520	0010 0000 0100 0100	151.675	0010 0000 0110 0011
151.215	0010 0000 0000 0111	151.370	0010 0000 0010 0110	151.525	0010 0000 0100 0101	151.680	0010 0000 0110 0100
151.220	0010 0000 0000 1000	151.375	0010 0000 0010 0111	151.530	0010 0000 0100 0110	151.685	0010 0000 0110 0101
151.225	0010 0000 0000 1001	151.380	0010 0000 0010 1000	151.535	0010 0000 0100 0111	151.690	0010 0000 0110 0110
151.230	0010 0000 0000 1010	151.385	0010 0000 0010 1001	151.540	0010 0000 0100 1000	151.695	0010 0000 0110 0111
151.235	0010 0000 0000 1011	151.390	0010 0000 0010 1010	151.545	0010 0000 0100 1001	151.700	0010 0000 0110 1000
151.240	0010 0000 0000 1100	151.395	0010 0000 0010 1011	151.550	0010 0000 0100 1010	151.705	0010 0000 0110 1001
151.245	0010 0000 0000 1101	151.400	0010 0000 0010 1100	151.555	0010 0000 0100 1011	151.710	0010 0000 0110 1010
151.250	0010 0000 0000 1110	151.405	0010 0000 0010 1101	151.560	0010 0000 0100 1100	151.715	0010 0000 0110 1011
151.255	0010 0000 0000 1111	151.410	0010 0000 0010 1110	151.565	0010 0000 0100 1101	151.720	0010 0000 0110 1100
151.260	0010 0000 0001 0000	151.415	0010 0000 0010 1111	151.570	0010 0000 0100 1110	151.725	0010 0000 0110 1101
151.265	0010 0000 0001 0001	151.420	0010 0000 0011 0000	151.575	0010 0000 0100 1111	151.730	0010 0000 0110 1110
151.270	0010 0000 0001 0010	151.425	0010 0000 0011 0001	151.580	0010 0000 0101 0000	151.735	0010 0000 0110 1111
151.275	0010 0000 0001 0011	151.430	0010 0000 0011 0010	151.585	0010 0000 0101 0001	151.740	0010 0000 0111 0000
151.280	0010 0000 0001 0100	151.435	0010 0000 0011 0011	151.590	0010 0000 0101 0010	151.745	0010 0000 0111 0001
151.285	0010 0000 0001 0101	151.440	0010 0000 0011 0100	151.595	0010 0000 0101 0011	151.750	0010 0000 0111 0010
151.290	0010 0000 0001 0110	151.445	0010 0000 0011 0101	151.600	0010 0000 0101 0100	151.755	0010 0000 0111 0011
151.295	0010 0000 0001 0111	151.450	0010 0000 0011 0110	151.605	0010 0000 0101 0101	151.760	0010 0000 0111 0100
151.300	0010 0000 0001 1000	151.455	0010 0000 0011 0111	151.610	0010 0000 0101 0110	151.765	0010 0000 0111 0101
151.305	0010 0000 0001 1001	151.460	0010 0000 0011 1000	151.615	0010 0000 0101 0111	151.770	0010 0000 0111 0110
151.310	0010 0000 0001 1010	151.465	0010 0000 0011 1001	151.620	0010 0000 0101 1000	151.775	0010 0000 0111 0111
151.315	0010 0000 0001 1011	151.470	0010 0000 0011 1010	151.625	0010 0000 0101 1001	151.780	0010 0000 0111 1000
151.320	0010 0000 0001 1100	151.475	0010 0000 0011 1011	151.630	0010 0000 0101 1010	151.785	0010 0000 0111 1001
151.325	0010 0000 0001 1101	151.480	0010 0000 0011 1100	151.635	0010 0000 0101 1011	151.790	0010 0000 0111 1010
151.330	0010 0000 0001 1110	151.485	0010 0000 0011 1101	151.640	0010 0000 0101 1100	151.795	0010 0000 0111 1011

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
151.800	0010	0000	0111	1100	151.965	0010	0000	1001	1101	152.130	0010	0000	1011	1110	152.295	0010	0000	1101	1111
151.805	0010	0000	0111	1101	151.970	0010	0000	1001	1110	152.135	0010	0000	1011	1111	152.300	0010	0000	1110	0000
151.810	0010	0000	0111	1110	151.975	0010	0000	1001	1111	152.140	0010	0000	1100	0000	152.305	0010	0000	1110	0001
151.815	0010	0000	0111	1111	151.980	0010	0000	1010	0000	152.145	0010	0000	1100	0001	152.310	0010	0000	1110	0010
151.820	0010	0000	1000	0000	151.985	0010	0000	1010	0001	152.150	0010	0000	1100	0010	152.315	0010	0000	1110	0011
151.825	0010	0000	1000	0001	151.990	0010	0000	1010	0010	152.155	0010	0000	1100	0011	152.320	0010	0000	1110	0100
151.830	0010	0000	1000	0010	151.995	0010	0000	1010	0011	152.160	0010	0000	1100	0100	152.325	0010	0000	1110	0101
151.835	0010	0000	1000	0011	152.000	0010	0000	1010	0100	152.165	0010	0000	1100	0101	152.330	0010	0000	1110	0110
151.840	0010	0000	1000	0100	152.005	0010	0000	1010	0101	152.170	0010	0000	1100	0110	152.335	0010	0000	1110	0111
151.845	0010	0000	1000	0101	152.010	0010	0000	1010	0110	152.175	0010	0000	1100	0111	152.340	0010	0000	1110	1000
151.850	0010	0000	1000	0110	152.015	0010	0000	1010	0111	152.180	0010	0000	1100	1000	152.345	0010	0000	1110	1001
151.855	0010	0000	1000	0111	152.020	0010	0000	1010	1000	152.185	0010	0000	1100	1001	152.350	0010	0000	1110	1010
151.860	0010	0000	1000	1000	152.025	0010	0000	1010	1001	152.190	0010	0000	1100	1010	152.355	0010	0000	1110	1011
151.865	0010	0000	1000	1001	152.030	0010	0000	1010	1010	152.195	0010	0000	1100	1011	152.360	0010	0000	1110	1100
151.870	0010	0000	1000	1010	152.035	0010	0000	1010	1011	152.200	0010	0000	1100	1100	152.365	0010	0000	1110	1101
151.875	0010	0000	1000	1011	152.040	0010	0000	1010	1100	152.205	0010	0000	1100	1101	152.370	0010	0000	1110	1110
151.880	0010	0000	1000	1100	152.045	0010	0000	1010	1101	152.210	0010	0000	1100	1110	152.375	0010	0000	1110	1111
151.885	0010	0000	1000	1101	152.050	0010	0000	1010	1110	151.215	0010	0000	1100	1111	152.380	0010	0000	1111	0000
151.890	0010	0000	1000	1110	152.055	0010	0000	1010	1111	152.220	0010	0000	1101	0000	152.385	0010	0000	1111	0001
151.895	0010	0000	1000	1111	152.060	0010	0000	1011	0000	152.225	0010	0000	1101	0001	152.390	0010	0000	1111	0010
151.900	0010	0000	1001	0000	152.065	0010	0000	1011	0001	152.230	0010	0000	1101	0010	152.395	0010	0000	1111	0011
151.905	0010	0000	1001	0001	152.070	0010	0000	1011	0010	152.235	0010	0000	1101	0011	152.400	0010	0000	1111	0100
151.910	0010	0000	1001	0010	152.075	0010	0000	1011	0011	152.240	0010	0000	1101	0100	152.405	0010	0000	1111	0101
151.915	0010	0000	1001	0011	152.080	0010	0000	1011	0100	152.245	0010	0000	1101	0101	152.410	0010	0000	1111	0110
151.920	0010	0000	1001	0100	152.085	0010	0000	1011	0101	152.250	0010	0000	1101	0110	152.415	0010	0000	1111	0111
151.925	0010	0000	1001	0101	152.090	0010	0000	1011	0110	152.255	0010	0000	1101	0111	152.420	0010	0000	1111	1000
151.930	0010	0000	1001	0110	152.095	0010	0000	1011	0111	152.260	0010	0000	1101	1000	152.425	0010	0000	1111	1001
151.935	0010	0000	1001	0111	152.100	0010	0000	1011	1000	152.265	0010	0000	1101	1001	152.430	0010	0000	1111	1010
151.940	0010	0000	1001	1000	152.105	0010	0000	1011	1001	152.270	0010	0000	1101	1010	152.435	0010	0000	1111	1011
151.945	0010	0000	1001	1001	151.110	0010	0000	1011	1010	152.275	0010	0000	1101	1011	152.440	0010	0000	1111	1100
151.950	0010	0000	1001	1010	152.115	0010	0000	1011	1011	152.280	0010	0000	1101	1100	152.445	0010	0000	1111	1101
151.955	0010	0000	1001	1011	152.120	0010	0000	1011	1100	152.285	0010	0000	1101	1101	152.450	0010	0000	1111	1110
151.960	0010	0000	1001	1100	152.125	0010	0000	1011	1101	152.290	0010	0000	1101	1110	152.455	0010	0000	1111	1111

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
152.460	0010	0001	0000	0000	152.625	0010	0001	0010	0001	152.790	0010	0001	0100	0010	152.955	0010	0001	0110	0011
152.465	0010	0001	0000	0001	152.630	0010	0001	0010	0010	152.795	0010	0001	0100	0011	152.960	0010	0001	0110	0100
152.470	0010	0001	0000	0010	152.635	0010	0001	0010	0011	152.800	0010	0001	0100	0100	152.965	0010	0001	0110	0101
152.475	0010	0001	0000	0011	152.640	0010	0001	0010	0100	152.805	0010	0001	0100	0101	152.970	0010	0001	0110	0110
152.480	0010	0001	0000	0100	152.645	0010	0001	0010	0101	152.810	0010	0001	0100	0110	152.975	0010	0001	0110	0111
152.485	0010	0001	0000	0101	152.650	0010	0001	0010	0110	152.815	0010	0001	0100	0111	152.980	0010	0001	0110	1000
152.490	0010	0001	0000	0110	152.655	0010	0001	0010	0111	152.820	0010	0001	0100	1000	152.985	0010	0001	0110	1001
152.495	0010	0001	0000	0111	152.660	0010	0001	0010	1000	152.825	0010	0001	0100	1001	152.990	0010	0001	0110	1010
152.500	0010	0001	0000	1000	152.665	0010	0001	0010	1001	152.830	0010	0001	0100	1010	152.995	0010	0001	0110	1011
152.505	0010	0001	0000	1001	152.670	0010	0001	0010	1010	152.835	0010	0001	0100	1011	153.000	0010	0001	0110	1100
152.510	0010	0001	0000	1010	152.675	0010	0001	0010	1011	152.840	0010	0001	0100	1100	153.005	0010	0001	0110	1101
152.515	0010	0001	0000	1011	152.680	0010	0001	0010	1100	152.845	0010	0001	0100	1101	153.010	0010	0001	0110	1110
152.520	0010	0001	0000	1100	152.685	0010	0001	0010	1101	152.850	0010	0001	0100	1110	153.015	0010	0001	0110	1111
152.525	0010	0001	0000	1101	152.690	0010	0001	0010	1110	152.855	0010	0001	0100	1111	153.020	0010	0001	0111	0000
152.530	0010	0001	0000	1110	152.695	0010	0001	0010	1111	152.860	0010	0001	0101	0000	153.025	0010	0001	0111	0001
152.535	0010	0001	0000	1111	152.700	0010	0001	0011	0000	152.865	0010	0001	0101	0001	153.030	0010	0001	0111	0010
152.540	0010	0001	0001	0000	152.705	0010	0001	0011	0001	152.870	0010	0001	0101	0010	153.035	0010	0001	0111	0011
152.545	0010	0001	0001	0001	152.710	0010	0001	0011	0010	152.875	0010	0001	0101	0011	153.040	0010	0001	0111	0100
152.550	0010	0001	0001	0010	152.715	0010	0001	0011	0011	152.880	0010	0001	0101	0100	153.045	0010	0001	0111	0101
152.555	0010	0001	0001	0011	152.720	0010	0001	0011	0100	152.885	0010	0001	0101	0101	153.050	0010	0001	0111	0110
152.560	0010	0001	0001	0100	152.725	0010	0001	0011	0101	152.890	0010	0001	0101	0110	153.055	0010	0001	0111	0111
152.565	0010	0001	0001	0101	152.730	0010	0001	0011	0110	152.895	0010	0001	0101	0111	153.060	0010	0001	0111	1000
152.570	0010	0001	0001	0110	152.735	0010	0001	0011	0111	152.900	0010	0001	0101	1000	153.065	0010	0001	0111	1001
152.575	0010	0001	0001	0111	152.740	0010	0001	0011	1000	152.905	0010	0001	0101	1001	153.070	0010	0001	0111	1010
152.580	0010	0001	0001	1000	152.745	0010	0001	0011	1001	152.910	0010	0001	0101	1010	152.075	0010	0001	0111	1011
152.585	0010	0001	0001	1001	152.750	0010	0001	0011	1010	152.915	0010	0001	0101	1011	153.080	0010	0001	0111	1100
152.590	0010	0001	0001	1010	152.755	0010	0001	0011	1011	152.920	0010	0001	0101	1100	153.085	0010	0001	0111	1101
152.595	0010	0001	0001	1011	152.760	0010	0001	0011	1100	152.925	0010	0001	0101	1101	153.090	0010	0001	0111	1110
152.600	0010	0001	0001	1100	152.765	0010	0001	0011	1101	152.930	0010	0001	0101	1110	153.095	0010	0001	0111	1111
152.605	0010	0001	0001	1101	152.770	0010	0001	0011	1110	152.935	0010	0001	0101	1111	153.100	0010	0001	1000	0000
152.610	0010	0001	0001	1110	152.775	0010	0001	0011	1111	152.940	0010	0001	0110	0000	153.105	0010	0001	1000	0001
152.615	0010	0001	0001	1111	152.780	0010	0001	0100	0000	152.945	0010	0001	0110	0001	153.110	0010	0001	1000	0010
152.620	0010	0001	0010	0000	152.785	0010	0001	0100	0001	152.950	0010	0001	0110	0010	153.115	0010	0001	1000	0011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
153.120	0010 0001 1000 0100	153.285	0010 0001 1010 0101	153.450	0010 0001 1100 0110	153.615	0010 0001 1110 0111
153.125	0010 0001 1000 0101	153.290	0010 0001 1010 0110	153.455	0010 0001 1100 0111	153.620	0010 0001 1110 1000
153.130	0010 0001 1000 0110	153.295	0010 0001 1010 0111	153.460	0010 0001 1100 1000	153.625	0010 0001 1110 1001
153.135	0010 0001 1000 0111	153.300	0010 0001 1010 1000	153.465	0010 0001 1100 1001	153.630	0010 0001 1110 1010
153.140	0010 0001 1000 1000	153.305	0010 0001 1010 1001	153.470	0010 0001 1100 1010	153.635	0010 0001 1110 1011
153.145	0010 0001 1000 1001	153.310	0010 0001 1010 1010	153.475	0010 0001 1100 1011	153.640	0010 0001 1110 1100
153.150	0010 0001 1000 1010	153.315	0010 0001 1010 1011	153.480	0010 0001 1100 1100	153.645	0010 0001 1110 1101
153.155	0010 0001 1000 1011	153.320	0010 0001 1010 1100	153.485	0010 0001 1100 1101	153.650	0010 0001 1110 1110
153.160	0010 0001 1000 1100	153.325	0010 0001 1010 1101	153.490	0010 0001 1100 1110	153.655	0010 0001 1110 1111
153.165	0010 0001 1000 1101	153.330	0010 0001 1010 1110	153.495	0010 0001 1100 1111	153.660	0010 0001 1111 0000
153.170	0010 0001 1000 1110	153.335	0010 0001 1010 1111	153.500	0010 0001 1101 0000	153.665	0010 0001 1111 0001
153.175	0010 0001 1000 1111	153.340	0010 0001 1011 0000	153.505	0010 0001 1101 0001	153.670	0010 0001 1111 0010
153.180	0010 0001 1001 0000	153.345	0010 0001 1011 0001	153.510	0010 0001 1101 0010	153.675	0010 0001 1111 0011
153.185	0010 0001 1001 0001	153.350	0010 0001 1011 0010	153.515	0010 0001 1101 0011	153.680	0010 0001 1111 0100
153.190	0010 0001 1001 0010	153.355	0010 0001 1011 0011	153.520	0010 0001 1101 0100	153.685	0010 0001 1111 0101
153.195	0010 0001 1001 0011	153.360	0010 0001 1011 0100	153.525	0010 0001 1101 0101	153.690	0010 0001 1111 0110
153.200	0010 0001 1001 0100	153.365	0010 0001 1011 0101	153.530	0010 0001 1101 0110	153.695	0010 0001 1111 0111
153.205	0010 0001 1001 0101	153.370	0010 0001 1011 0110	153.535	0010 0001 1101 0111	153.700	0010 0001 1111 1000
153.210	0010 0001 1001 0110	153.375	0010 0001 1011 0111	153.540	0010 0001 1101 1000	153.705	0010 0001 1111 1001
153.215	0010 0001 1001 0111	153.380	0010 0001 1011 1000	153.545	0010 0001 1101 1001	153.710	0010 0001 1111 1010
153.220	0010 0001 1001 1000	153.385	0010 0001 1011 1001	153.550	0010 0001 1101 1010	153.715	0010 0001 1111 1011
153.225	0010 0001 1001 1001	153.390	0010 0001 1011 1010	153.555	0010 0001 1101 1011	153.720	0010 0001 1111 1100
153.230	0010 0001 1001 1010	153.395	0010 0001 1011 1011	153.560	0010 0001 1101 1100	153.725	0010 0001 1111 1101
153.235	0010 0001 1001 1011	153.400	0010 0001 1011 1100	153.565	0010 0001 1101 1101	153.730	0010 0001 1111 1110
153.240	0010 0001 1001 1100	153.405	0010 0001 1011 1101	153.570	0010 0001 1101 1110	153.735	0010 0001 1111 1111
153.245	0010 0001 1001 1101	153.410	0010 0001 1011 1110	153.575	0010 0001 1101 1111	153.740	0010 0010 0000 0000
153.250	0010 0001 1001 1110	153.415	0010 0001 1011 1111	153.580	0010 0001 1110 0000	153.745	0010 0010 0000 0001
153.255	0010 0001 1001 1111	153.420	0010 0001 1100 0000	153.585	0010 0001 1110 0001	153.750	0010 0010 0000 0010
153.260	0010 0001 1010 0000	153.425	0010 0001 1100 0001	153.590	0010 0001 1110 0010	153.755	0010 0010 0000 0011
153.265	0010 0001 1010 0001	153.430	0010 0001 1100 0010	153.595	0010 0001 1110 0011	153.760	0010 0010 0000 0100
153.270	0010 0001 1010 0010	153.435	0010 0001 1100 0011	153.600	0010 0001 1110 0100	153.765	0010 0010 0000 0101
153.275	0010 0001 1010 0011	153.440	0010 0001 1100 0100	153.605	0010 0001 1110 0101	153.770	0010 0010 0000 0110
153.280	0010 0001 1010 0100	153.445	0010 0001 1100 0101	153.610	0010 0001 1110 0110	153.775	0010 0010 0000 0111

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
153.780	0010	0010	0000	1000	153.945	0010	0010	0010	1001	154.110	0010	0010	0100	1010	154.275	0010	0010	0110	1011
153.785	0010	0010	0000	1001	153.950	0010	0010	0010	1010	154.115	0010	0010	0100	1011	154.280	0010	0010	0110	1100
153.790	0010	0010	0000	1010	153.955	0010	0010	0010	1011	154.120	0010	0010	0100	1100	154.285	0010	0010	0110	1101
153.795	0010	0010	0000	1011	153.960	0010	0010	0010	1100	154.125	0010	0010	0100	1101	154.290	0010	0010	0110	1110
153.800	0010	0010	0000	1100	153.965	0010	0010	0010	1101	154.130	0010	0010	0100	1110	154.295	0010	0010	0110	1111
153.805	0010	0010	0000	1101	153.970	0010	0010	0010	1110	154.135	0010	0010	0100	1111	154.300	0010	0010	0111	0000
153.810	0010	0010	0000	1110	153.975	0010	0010	0010	1111	154.140	0010	0010	0101	0000	154.305	0010	0010	0111	0001
153.815	0010	0010	0000	1111	153.980	0010	0010	0011	0000	154.145	0010	0010	0101	0001	154.310	0010	0010	0111	0010
153.820	0010	0010	0001	0000	153.985	0010	0010	0011	0001	154.150	0010	0010	0101	0010	154.315	0010	0010	0111	0011
153.825	0010	0010	0001	0001	153.990	0010	0010	0011	0010	154.155	0010	0010	0101	0011	153.320	0010	0010	0111	0100
153.830	0010	0010	0001	0010	153.995	0010	0010	0011	0011	154.160	0010	0010	0101	0100	154.325	0010	0010	0111	0101
153.835	0010	0010	0001	0011	154.000	0010	0010	0011	0100	154.165	0010	0010	0101	0101	154.330	0010	0010	0111	0110
153.840	0010	0010	0001	0100	154.005	0010	0010	0011	0101	154.170	0010	0010	0101	0110	154.335	0010	0010	0111	0111
153.845	0010	0010	0001	0101	154.010	0010	0010	0011	0110	154.175	0010	0010	0101	0111	154.340	0010	0010	0111	1000
153.850	0010	0010	0001	0110	154.015	0010	0010	0011	0111	154.180	0010	0010	0101	1000	154.345	0010	0010	0111	1001
153.855	0010	0010	0001	0111	154.020	0010	0010	0011	1000	154.185	0010	0010	0101	1001	154.350	0010	0010	0111	1010
153.860	0010	0010	0001	1000	154.025	0010	0010	0011	1001	154.190	0010	0010	0101	1010	154.355	0010	0010	0111	1011
153.865	0010	0010	0001	1001	154.030	0010	0010	0011	1010	154.195	0010	0010	0101	1011	154.360	0010	0010	0111	1100
153.870	0010	0010	0001	1010	154.035	0010	0010	0011	1011	154.200	0010	0010	0101	1100	154.365	0010	0010	0111	1101
153.875	0010	0010	0001	1011	154.040	0010	0010	0011	1100	154.205	0010	0010	0101	1101	154.370	0010	0010	0111	1110
153.880	0010	0010	0001	1100	154.045	0010	0010	0011	1101	154.210	0010	0010	0101	1110	154.375	0010	0010	0111	1111
153.885	0010	0010	0001	1101	154.050	0010	0010	0011	1110	154.215	0010	0010	0101	1111	154.380	0010	0010	1000	0000
153.890	0010	0010	0001	1110	154.055	0010	0010	0011	1111	154.220	0010	0010	0110	0000	154.385	0010	0010	1000	0001
153.895	0010	0010	0001	1111	154.060	0010	0010	0100	0000	154.225	0010	0010	0110	0001	154.390	0010	0010	1000	0010
153.900	0010	0010	0010	0000	154.065	0010	0010	0100	0001	154.230	0010	0010	0110	0010	154.395	0010	0010	1000	0011
153.905	0010	0010	0010	0001	154.070	0010	0010	0100	0010	154.235	0010	0010	0110	0011	154.400	0010	0010	1000	0100
153.910	0010	0010	0010	0010	154.075	0010	0010	0100	0011	154.240	0010	0010	0110	0100	154.405	0010	0010	1000	0101
153.915	0010	0010	0010	0011	154.080	0010	0010	0100	0100	154.245	0010	0010	0110	0101	154.410	0010	0010	1000	0110
153.920	0010	0010	0010	0100	154.085	0010	0010	0100	0101	154.250	0010	0010	0110	0110	154.415	0010	0010	1000	0111
153.925	0010	0010	0010	0101	154.090	0010	0010	0100	0110	154.255	0010	0010	0110	0111	154.420	0010	0010	1000	1000
153.930	0010	0010	0010	0110	154.095	0010	0010	0100	0111	154.260	0010	0010	0110	1000	154.425	0010	0010	1000	1001
153.935	0010	0010	0010	0111	154.100	0010	0010	0100	1000	154.265	0010	0010	0110	1001	154.430	0010	0010	1000	1010
153.940	0010	0010	0010	1000	154.105	0010	0010	0100	1001	154.270	0010	0010	0110	1010	154.435	0010	0010	1000	1011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
154.440	0010 0010 1000 1100	154.605	0010 0010 1010 1101	154.770	0010 0010 1100 1110	154.935	0010 0010 1110 1111
154.445	0010 0010 1000 1101	154.610	0010 0010 1010 1110	154.775	0010 0010 1100 1111	154.940	0010 0010 1111 0000
154.450	0010 0010 1000 1110	154.615	0010 0010 1010 1111	154.780	0010 0010 1101 0000	154.945	0010 0010 1111 0001
154.455	0010 0010 1000 1111	154.620	0010 0010 1011 0000	154.785	0010 0010 1101 0001	154.950	0010 0010 1111 0010
154.460	0010 0010 1001 0000	154.625	0010 0010 1011 0001	154.790	0010 0010 1101 0010	154.955	0010 0010 1111 0011
154.465	0010 0010 1001 0001	154.630	0010 0010 1011 0010	154.795	0010 0010 1101 0011	154.960	0010 0010 1111 0100
154.470	0010 0010 1001 0010	154.635	0010 0010 1011 0011	154.800	0010 0010 1101 0100	154.965	0010 0010 1111 0101
154.475	0010 0010 1001 0011	154.640	0010 0010 1011 0100	154.805	0010 0010 1101 0101	154.970	0010 0010 1111 0110
154.480	0010 0010 1001 0100	154.645	0010 0010 1011 0101	154.810	0010 0010 1101 0110	154.975	0010 0010 1111 0111
154.485	0010 0010 1001 0101	154.650	0010 0010 1011 0110	154.815	0010 0010 1101 0111	154.980	0010 0010 1111 1000
154.490	0010 0010 1001 0110	154.655	0010 0010 1011 0111	154.820	0010 0010 1101 1000	154.985	0010 0010 1111 1001
154.495	0010 0010 1001 0111	154.660	0010 0010 1011 1000	154.825	0010 0010 1101 1001	154.990	0010 0010 1111 1010
154.500	0010 0010 1001 1000	154.665	0010 0010 1011 1001	154.830	0010 0010 1101 1010	154.995	0010 0010 1111 1011
154.505	0010 0010 1001 1001	154.670	0010 0010 1011 1010	154.835	0010 0010 1101 1011	155.000	0010 0010 1111 1100
154.510	0010 0010 1001 1010	154.675	0010 0010 1011 1011	154.840	0010 0010 1101 1100	155.005	0010 0010 1111 1101
154.515	0010 0010 1001 1011	154.680	0010 0010 1011 1100	154.845	0010 0010 1101 1101	155.010	0010 0010 1111 1110
154.520	0010 0010 1001 1100	154.685	0010 0010 1011 1101	154.850	0010 0010 1101 1110	155.015	0010 0010 1111 1111
154.525	0010 0010 1001 1101	154.690	0010 0010 1011 1110	154.855	0010 0010 1101 1111	155.020	0010 0011 0000 0000
154.530	0010 0010 1001 1110	154.695	0010 0010 1011 1111	154.860	0010 0010 1110 0000	155.025	0010 0011 0000 0001
154.535	0010 0010 1001 1111	154.700	0010 0010 1100 0000	154.865	0010 0010 1110 0001	155.030	0010 0011 0000 0010
154.540	0010 0010 1010 0000	154.705	0010 0010 1100 0001	154.870	0010 0010 1110 0010	155.035	0010 0011 0000 0011
154.545	0010 0010 1010 0001	154.710	0010 0010 1100 0010	154.875	0010 0010 1110 0011	155.040	0010 0011 0000 0100
154.550	0010 0010 1010 0010	154.715	0010 0010 1100 0011	154.880	0010 0010 1110 0100	155.045	0020 0011 0000 0010
154.555	0010 0010 1010 0011	154.720	0010 0010 1100 0100	154.885	0010 0010 1110 0101	155.050	0010 0011 0000 0110
154.560	0010 0010 1010 0100	154.725	0010 0010 1100 0101	154.890	0010 0010 1110 0110	155.055	0010 0011 0000 0111
154.565	0010 0010 1010 0101	154.730	0010 0010 1100 0110	154.895	0010 0010 1110 0111	155.060	0010 0011 0000 1000
154.570	0010 0010 1010 0110	154.735	0010 0010 1100 0111	154.900	0010 0010 1110 1000	155.065	0010 0011 0000 1001
154.575	0010 0010 1010 0111	154.740	0010 0010 1100 1000	154.905	0010 0010 1110 1001	155.070	0010 0011 0000 1010
154.580	0010 0010 1010 1000	154.745	0010 0010 1100 1001	154.910	0010 0010 1110 1010	155.075	0010 0011 0000 1011
154.585	0010 0010 1010 1001	154.750	0010 0010 1100 1010	154.915	0010 0010 1110 1011	155.080	0010 0011 0000 1100
154.590	0010 0010 1010 1010	154.755	0010 0010 1100 1011	154.920	0010 0010 1110 1100	155.085	0010 0011 0000 1101
154.595	0010 0010 1010 1011	154.760	0010 0010 1100 1100	154.925	0010 0010 1110 1101	155.090	0010 0011 0000 1110
154.600	0010 0010 1010 1100	154.765	0010 0010 1100 1101	154.930	0010 0010 1110 1110	155.095	0010 0011 0000 1111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
155.100	0010 0011 0001 0000	155.265	0010 0011 0011 0001	155.430	0010 0011 0101 0010	155.595	0010 0011 0111 0011
155.105	0010 0011 0001 0001	155.270	0010 0011 0011 0010	155.435	0010 0011 0101 0011	155.600	0010 0011 0111 0100
155.110	0010 0011 0001 0010	155.275	0010 0011 0011 0011	155.440	0010 0011 0101 0100	155.605	0010 0011 0111 0101
155.115	0010 0011 0001 0011	155.280	0010 0011 0011 0100	155.445	0010 0011 0101 0101	155.610	0010 0011 0111 0110
155.120	0010 0011 0001 0100	155.285	0010 0011 0011 0101	155.450	0010 0011 0101 0110	155.615	0010 0011 0111 0111
155.125	0010 0011 0001 0101	155.290	0010 0011 0011 0110	155.455	0010 0011 0101 0111	155.620	0010 0011 0111 1000
155.130	0010 0011 0001 0110	155.295	0010 0011 0011 0111	155.460	0010 0011 0101 1000	155.625	0010 0011 0111 1001
155.135	0010 0011 0001 0111	155.300	0010 0011 0011 1000	155.465	0010 0011 0101 1001	155.630	0010 0011 0111 1010
155.140	0010 0011 0001 1000	155.305	0010 0011 0011 1001	155.470	0010 0011 0101 1010	155.635	0010 0011 0111 1011
155.145	0010 0011 0001 1001	155.310	0010 0011 0011 1010	155.475	0010 0011 0101 1011	155.640	0010 0011 0111 1100
155.150	0010 0011 0001 1010	155.315	0010 0011 0011 1011	155.480	0010 0011 0101 1100	155.645	0010 0011 0111 1101
155.155	0010 0011 0001 1011	155.320	0010 0011 0011 1100	155.485	0010 0011 0101 1101	155.650	0010 0011 0111 1110
155.160	0010 0011 0001 1100	155.325	0010 0011 0011 1101	155.490	0010 0011 0101 1110	155.655	0010 0011 0111 1111
155.165	0010 0011 0001 1101	155.330	0010 0011 0011 1110	155.495	0010 0011 0101 1111	155.660	0010 0011 1000 0000
155.170	0010 0011 0001 1110	155.335	0010 0011 0011 1111	155.500	0010 0011 0110 0000	155.665	0010 0011 1000 0001
155.175	0010 0011 0001 1111	155.340	0010 0011 0100 0000	155.505	0010 0011 0110 0001	155.670	0010 0011 1000 0010
155.180	0010 0011 0001 0010	155.345	0010 0011 0100 0001	155.510	0010 0011 0110 0010	155.675	0010 0011 1000 0011
155.185	0010 0011 0010 0001	155.350	0010 0011 0100 0010	155.515	0010 0011 0110 0011	155.680	0010 0011 1000 0100
155.190	0010 0011 0010 0010	155.355	0010 0011 0100 0011	155.520	0010 0011 0110 0100	155.685	0010 0011 1000 0101
155.195	0010 0011 0010 0011	155.360	0010 0011 0100 0100	155.525	0010 0011 0110 0101	155.690	0010 0011 1000 0110
155.200	0010 0011 0010 0100	155.365	0010 0011 0100 0101	155.530	0010 0011 0110 0110	155.695	0010 0111 1000 0111
155.205	0010 0011 0010 0101	155.370	0010 0011 0100 0110	155.535	0010 0011 0110 0111	155.700	0010 0011 1000 1000
155.210	0010 0011 0010 0110	155.375	0010 0011 0100 0111	155.540	0010 0011 0110 1000	155.705	0010 0011 1000 1001
155.215	0010 0011 0010 0111	155.380	0010 0011 0100 1000	155.545	0010 0011 0110 1001	155.710	0010 0011 1000 1010
155.220	0010 0011 0010 1000	155.385	0010 0011 0100 1001	155.550	0010 0011 0110 1010	155.715	0010 0011 1000 1011
155.225	0010 0011 0010 1001	155.390	0010 0011 0100 1010	155.555	0010 0011 0110 1011	155.720	0010 0011 1000 1100
155.230	0010 0011 0010 1010	155.395	0010 0011 0100 1011	155.560	0010 0011 0110 1100	155.725	0010 0011 1000 1101
155.235	0010 0011 0010 1011	155.400	0010 0011 0100 1100	155.565	0010 0011 0110 1101	155.730	0010 0011 1000 1110
155.240	0010 0011 0010 1100	155.405	0010 0011 0100 1101	155.570	0010 0011 0110 1110	155.735	0010 0011 1000 1111
155.245	0010 0011 0010 1101	155.410	0010 0011 0100 1110	155.575	0010 0011 0110 1111	155.740	0010 0011 1001 0000
155.250	0010 0011 0010 1110	155.415	0010 0011 0100 1111	155.580	0010 0011 0111 0000	155.745	0010 0011 1001 0001
155.255	0010 0011 0010 1111	155.420	0010 0011 0101 0000	155.585	0010 0011 0111 0001	155.750	0010 0011 1001 0010
155.260	0010 0011 0011 0000	155.425	0010 0011 0101 0001	155.590	0010 0011 0111 0010	155.755	0010 0011 1001 0011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
155.760	0010 0011 1001 0100	155.925	0010 0011 1011 0101	156.090	0010 0011 1101 0110	156.255	0010 0011 1111 0111
155.765	0010 0011 1001 0101	155.930	0010 0011 1011 0110	156.095	0010 0011 1101 0111	156.260	0010 0011 1111 1000
155.770	0010 0011 1001 0110	155.935	0010 0011 1011 0111	156.100	0010 0011 1101 1000	156.265	0010 0011 1111 1001
155.775	0010 0011 1001 0111	155.940	0010 0011 1011 1000	156.105	0010 0011 1101 1001	156.270	0010 0011 1111 1010
155.780	0010 0011 1001 1000	155.945	0010 0011 1011 1001	156.110	0010 0011 1101 1010	156.275	0010 0011 1111 1011
155.785	0010 0011 1001 1001	155.950	0010 0011 1011 1010	156.115	0010 0011 1101 1011	156.280	0010 0011 1111 1100
155.790	0010 0011 1001 1010	155.955	0010 0011 1011 1011	156.120	0010 0011 1101 1100	156.285	0010 0011 1111 1101
155.795	0010 0011 1001 1011	155.960	0010 0011 1011 1100	156.125	0010 0011 1101 1101	156.290	0010 0011 1111 1110
155.800	0010 0011 1001 1100	155.965	0010 0011 1011 1101	156.130	0010 0011 1101 1110	156.295	0010 0011 1111 1111
155.805	0010 0011 1001 1101	155.970	0010 0011 1011 1110	156.135	0010 0011 1101 1111	156.300	0010 0100 0000 0000
144.810	0010 0011 1001 1110	155.975	0010 0011 1011 1111	156.140	0010 0011 1110 0000	156.305	0010 0100 0000 0001
155.815	0010 0011 1001 1111	155.980	0010 0011 1100 0000	156.145	0010 0011 1110 0001	156.310	0010 0100 0000 0010
155.820	0010 0011 1010 0000	155.985	0010 0011 1100 0001	156.150	0010 0011 1110 0010	156.315	0010 0100 0000 0011
155.825	0010 0011 1010 0001	155.990	0010 0011 1100 0010	156.155	0010 0011 1110 0011	156.320	0010 0100 0000 0100
155.830	0010 0011 1010 0010	155.995	0010 0011 1100 0011	156.160	0010 0011 1110 0100	156.325	0010 0100 0000 0101
155.835	0010 0011 1010 0011	156.000	0010 0011 1100 0100	156.165	0010 0011 1110 0101	156.330	0010 0100 0000 0110
155.840	0010 0011 1010 0100	156.005	0010 0011 1100 0101	156.170	0010 0011 1110 0110	156.335	0010 0100 0000 0111
155.845	0010 0011 1010 0101	156.010	0010 0011 1100 0110	156.175	0010 0011 1110 0111	156.340	0010 0100 0000 1000
155.850	0010 0011 1010 0110	156.015	0010 0011 1100 0111	156.180	0010 0011 1110 1000	156.345	0010 0100 0000 1001
155.855	0010 0011 1010 0111	156.020	0010 0011 1100 1000	156.185	0010 0011 1110 1001	156.350	0010 0100 0000 1010
155.860	0010 0011 1010 1000	156.025	0010 0011 1100 1001	156.190	0010 0011 1110 1010	156.355	0010 0100 0000 1011
155.865	0010 0011 1010 1001	156.030	0010 0011 1100 1010	156.195	0010 0011 1110 1011	156.360	0010 0100 0000 1100
155.870	0010 0011 1010 1010	156.035	0010 0011 1100 1011	156.200	0010 0011 1110 1100	156.365	0010 0100 0000 1101
155.875	0010 0011 1010 1011	156.040	0010 0011 1100 1100	156.205	0010 0011 1110 1101	156.370	0010 0100 0000 1110
155.880	0010 0011 1010 1100	156.045	0010 0011 1100 1101	156.210	0010 0011 1110 1110	156.375	0010 0100 0000 1111
155.885	0010 0011 1010 1101	156.050	0010 0011 1100 1110	156.215	0010 0011 1110 1111	156.380	0010 0100 0001 0000
155.890	0010 0011 1010 1110	156.055	0010 0011 1100 1111	156.220	0010 0011 1111 0000	156.385	0010 0100 0001 0001
155.895	0010 0011 1010 1111	156.060	0010 0011 1101 0000	156.225	0010 0011 1111 0001	156.390	0010 0100 0001 0010
155.900	0010 0011 1011 0000	156.065	0010 0011 1101 0001	156.230	0010 0011 1111 0010	156.395	0010 0100 0001 0011
155.905	0010 0011 1011 0001	156.070	0010 0011 1101 0010	156.235	0010 0011 1111 0011	156.400	0010 0100 0001 0100
155.910	0010 0011 1011 0010	156.075	0010 0011 1101 0011	156.240	0010 0011 1111 0100	156.405	0010 0100 0001 0101
155.915	0010 0011 1011 0011	156.080	0010 0011 1101 0100	156.245	0010 0011 1111 0101	156.410	0010 0100 0001 0110
155.920	0010 0011 1011 0100	156.085	0010 0011 1101 0101	156.250	0010 0011 1111 0110	156.415	0010 0100 0001 0111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
156.420	0010 0100 0001 1000	156.585	0010 0100 0011 1001	156.750	0010 0100 0101 1010	156.915	0010 0100 0111 1011
156.425	0010 0100 0001 1001	156.590	0010 0100 0011 1010	156.755	0010 0100 0101 1011	156.920	0010 0100 0111 1100
156.430	0010 0100 0001 1010	156.595	0010 0100 0011 1011	156.760	0010 0100 0101 1100	156.925	0010 0100 0111 1101
156.435	0010 0100 0001 1011	156.600	0010 0100 0011 1100	156.765	0010 0100 0101 1101	156.930	0010 0100 0111 1110
156.440	0010 0100 0001 1100	156.605	0010 0100 0011 1101	156.770	0010 0100 0101 1110	156.935	0010 0100 0111 1111
156.445	0010 0100 0001 1101	156.610	0010 0100 0011 1110	156.775	0010 0100 0101 1111	156.940	0010 0100 1000 0000
156.450	0010 0100 0001 1110	156.615	0010 0100 0011 1111	156.780	0010 0100 0110 0000	156.945	0010 0100 1000 0001
156.455	0010 0100 0001 1111	156.620	0010 0100 0100 0000	156.785	0010 0100 0110 0001	156.950	0010 0100 1000 0010
156.460	0010 0100 0010 0000	156.625	0010 0100 0100 0001	156.790	0010 0100 0110 0010	156.955	0010 0100 1000 0011
156.465	0010 0100 0010 0001	156.630	0010 0100 0100 0010	156.795	0010 0100 0110 0011	156.960	0010 0100 1000 0100
156.470	0010 0100 0010 0010	156.635	0010 0100 0100 0011	156.800	0010 0100 0110 0100	156.965	0010 0100 1000 0101
156.475	0010 0100 0010 0011	156.640	0010 0100 0100 0100	156.805	0010 0100 0110 0101	156.970	0010 0100 1000 0110
156.480	0010 0100 0010 0100	156.645	0010 0100 0100 0101	156.810	0010 0100 0110 0110	156.975	0010 0100 1000 0111
156.485	0010 0100 0010 0101	156.650	0010 0100 0100 0110	156.815	0010 0100 0110 0111	156.980	0010 0100 1000 1000
156.490	0010 0100 0010 0110	156.655	0010 0100 0100 0111	156.820	0010 0100 0110 1000	156.985	0010 0100 1000 1001
156.495	0010 0100 0010 0111	156.660	0010 0100 0100 1000	156.825	0010 0100 0110 1001	156.990	0010 0100 1000 1010
156.500	0010 0100 0010 1000	156.665	0010 0100 0100 1001	156.830	0010 0100 0110 1010	156.995	0010 0100 1000 1011
156.505	0010 0100 0010 1001	156.670	0010 0100 0100 1010	156.835	0010 0100 0110 1011	157.000	0010 0100 1000 1100
156.510	0010 0100 0010 1010	156.675	0010 0100 0100 1011	156.840	0010 0100 0110 1100	157.005	0010 0100 1000 1101
156.515	0010 0100 0010 1011	156.680	0010 0100 0100 1100	156.845	0010 0100 0110 1101	157.010	0010 0100 1000 1110
156.520	0010 0100 0010 1100	156.685	0010 0100 0100 1101	156.850	0010 0100 0110 1110	157.015	0010 0100 1000 1111
156.525	0010 0100 0010 1101	156.690	0010 0100 0100 1110	156.855	0010 0100 0110 1111	157.020	0010 0100 1001 0000
156.530	0010 0100 0010 1110	156.695	0010 0100 0100 1111	156.860	0010 0100 0111 0000	157.025	0010 0100 1001 0001
156.535	0010 0100 0010 1111	156.700	0010 0100 0101 0000	156.865	0010 0100 0111 0001	157.030	0010 0100 1001 0010
156.540	0010 0100 0011 0000	156.705	0010 0100 0101 0001	156.870	0010 0100 0111 0010	157.035	0010 0100 1001 0011
156.545	0010 0100 0011 0001	156.710	0010 0100 0101 0010	156.875	0010 0100 0111 0011	157.040	0010 0100 1001 0100
156.550	0010 0100 0011 0010	156.715	0010 0100 0101 0011	156.880	0010 0100 0111 0100	157.045	0010 0100 1001 0101
156.555	0010 0100 0011 0011	156.720	0010 0100 0101 0100	156.885	0010 0100 0111 0101	157.050	0010 0100 1001 0110
156.560	0010 0100 0011 0100	156.725	0010 0100 0101 0101	156.890	0010 0100 0111 0110	157.055	0010 0100 1001 0111
156.565	0010 0100 0011 0101	156.730	0010 0100 0101 0110	156.895	0010 0100 0111 0111	157.060	0010 0100 1001 1000
156.570	0010 0100 0011 0110	156.735	0010 0100 0101 0111	156.900	0010 0100 0111 1000	157.065	0010 0100 1001 1001
156.575	0010 0100 0011 0111	156.740	0010 0100 0101 1000	156.905	0010 0100 0111 1001	157.070	0010 0100 1001 1010
156.580	0010 0100 0011 1000	156.745	0010 0100 0101 1001	156.910	0010 0100 0111 1010	157.075	0010 0100 1001 1011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
157.080	0010 0100 1001 1100	157.245	0010 0100 1011 1101	157.410	0010 0100 1101 1110	157.575	0010 0100 1111 1111
157.085	0010 0100 1001 1101	157.250	0010 0100 1011 1110	157.415	0010 0100 1101 1111	157.580	0010 0101 0000 0000
157.090	0010 0100 1001 1110	157.255	0010 0100 1011 1111	157.420	0010 0100 1110 0000	157.585	0010 0101 0000 0001
157.095	0010 0100 1001 1111	157.260	0010 0100 1100 0000	157.425	0010 0100 1110 0001	157.590	0010 0101 0000 0010
157.100	0010 0100 1010 0000	157.265	0010 0100 1100 0001	157.430	0010 0100 1110 0010	157.595	0010 0101 0000 0011
157.105	0010 0100 1010 0001	157.270	0010 0100 1100 0010	157.435	0010 0100 1110 0011	157.600	0010 0101 0000 0100
157.110	0010 0100 1010 0010	157.275	0010 0100 1100 0011	157.440	0010 0100 1110 0100	157.605	0010 0101 0000 0101
157.115	0010 0100 1010 0011	157.280	0010 0100 1100 0100	157.445	0010 0100 1110 0101	157.610	0010 0101 0000 0110
157.120	0010 0100 1010 0100	157.285	0010 0100 1100 0101	157.450	0010 0100 1110 0110	157.615	0010 0101 0000 0111
157.125	0010 0100 1010 0101	157.290	0010 0100 1100 0110	157.455	0010 0100 1110 0111	157.620	0010 0101 0000 1000
157.130	0010 0100 1010 0110	157.295	0010 0100 1100 0111	157.460	0010 0100 1110 1000	157.625	0010 0101 0000 1001
157.135	0010 0100 1010 0111	157.300	0010 0100 1100 1000	157.465	0010 0100 1110 1001	157.630	0010 0101 0000 1010
157.140	0010 0100 1010 1000	157.305	0010 0100 1100 1001	157.470	0010 0100 1110 1010	157.635	0010 0101 0000 1011
157.145	0010 0100 1010 1001	157.310	0010 0100 1100 1010	157.475	0010 0100 1110 1011	157.640	0010 0101 0000 1100
157.150	0010 0100 1010 1010	157.315	0010 0100 1100 1011	157.480	0010 0100 1110 1100	157.645	0010 0101 0000 1101
157.155	0010 0100 1010 1011	157.320	0010 0100 1100 1100	157.485	0010 0100 1110 1101	157.650	0010 0101 0000 1110
157.160	0010 0100 1010 1100	157.325	0010 0100 1100 1101	157.490	0010 0100 1110 1110	157.655	0010 0101 0000 1111
157.165	0010 0100 1010 1101	157.330	0010 0100 1100 1110	157.495	0010 0100 1110 1111	157.660	0010 0101 0001 0000
157.170	0010 0100 1010 1110	157.335	0010 0100 1100 1111	157.500	0010 0100 1111 0000	157.665	0010 0101 0001 0001
157.175	0010 0100 1010 1111	157.340	0010 0100 1101 0000	157.505	0010 0100 1111 0001	157.670	0010 0101 0001 0010
157.180	0010 0100 1011 0000	157.345	0010 0100 1101 0001	157.510	0010 0100 1111 0010	157.675	0010 0101 0001 0011
157.185	0010 0100 1011 0001	157.350	0010 0100 1101 0010	157.515	0010 0100 1111 0011	157.680	0010 0101 0001 0100
157.190	0010 0100 1011 0010	157.355	0010 0100 1101 0011	157.520	0010 0100 1111 0100	157.685	0010 0101 0001 0101
157.195	0010 0100 1011 0011	157.360	0010 0100 1101 0100	157.525	0010 0100 1111 0101	157.690	0010 0101 0001 0110
157.200	0010 0100 1011 0100	157.365	0010 0100 1101 0101	157.530	0010 0100 1111 0110	157.695	0010 0101 0001 0111
157.205	0010 0100 1011 0101	157.370	0010 0100 1101 0110	157.535	0010 0100 1111 0111	157.700	0010 0101 0001 1000
157.210	0010 0100 1011 0110	157.375	0010 0100 1101 0111	157.540	0010 0100 1111 1000	157.705	0010 0101 0001 1001
157.215	0010 0100 1011 0111	157.380	0010 0100 1101 1000	157.545	0010 0100 1111 1001	157.710	0010 0101 0001 1010
157.220	0010 0100 1011 1000	157.385	0010 0100 1101 1001	157.550	0010 0100 1111 1010	157.715	0010 0101 0001 1011
157.225	0010 0100 1011 1001	157.390	0010 0100 1101 1010	157.555	0010 0100 1111 1011	157.720	0010 0101 0001 1100
157.230	0010 0100 1011 1010	157.395	0010 0100 1101 1011	157.560	0010 0100 1111 1100	157.725	0010 0101 0001 1101
157.235	0010 0100 1011 1011	157.400	0010 0100 1101 1100	157.565	0010 0100 1111 1101	157.730	0010 0101 0001 1110
157.240	0010 0100 1011 1100	157.405	0010 0100 1101 1101	157.570	0010 0100 1111 1110	157.735	0010 0101 0001 1111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
157.740	0010 0101 0010 0000	157.905	0010 0101 0100 0001	158.070	0010 0101 0110 0010	158.235	0010 0101 1000 0011
157.745	0010 0101 0010 0001	157.910	0010 0101 0100 0010	158.075	0010 0101 0110 0011	158.240	0010 0101 1000 0100
157.750	0010 0101 0010 0010	157.915	0010 0101 0100 0011	158.080	0010 0101 0110 0100	158.245	0010 0101 1000 0101
157.755	0010 0101 0010 0011	157.920	0010 0101 0100 0100	158.085	0010 0101 0110 0101	158.250	0010 0101 1000 0110
157.760	0010 0101 0010 0100	157.925	0010 0101 0100 0101	158.090	0010 0101 0110 0110	158.255	0010 0101 1000 0111
157.765	0010 0101 0010 0101	157.930	0010 0101 0100 0110	158.095	0010 0101 0110 0111	158.260	0010 0101 1000 1000
157.770	0010 0101 0010 0110	157.935	0010 0101 0100 0111	158.100	0010 0101 0110 1000	158.265	0010 0101 1000 1001
157.775	0010 0101 0010 0111	157.940	0010 0101 0100 1000	158.105	0010 0101 0110 1001	158.270	0010 0101 1000 1010
157.780	0010 0101 0010 1000	157.945	0010 0101 0100 1001	158.110	0010 0101 0110 1010	158.275	0010 0101 1000 1011
157.785	0010 0101 0010 1001	157.950	0010 0101 0100 1010	158.115	0010 0101 0110 1011	158.280	0010 0101 1000 1100
157.790	0010 0101 0010 1010	157.955	0010 0101 0100 1011	158.120	0010 0101 0110 1100	158.285	0010 0101 1000 1101
157.795	0010 0101 0010 1011	157.960	0010 0101 0100 1100	158.125	0010 0101 0110 1101	158.290	0010 0101 1000 1110
157.800	0010 0101 0010 1100	157.965	0010 0101 0100 1101	158.130	0010 0101 0110 1110	158.295	0010 0101 1000 1111
157.805	0010 0101 0010 1101	157.970	0010 0101 0100 1110	158.135	0010 0101 0110 1111	158.300	0010 0101 1001 0000
157.810	0010 0101 0010 1110	157.975	0010 0101 0100 1111	158.140	0010 0101 0111 0000	158.305	0010 0101 1001 0001
157.815	0010 0101 0010 1111	157.980	0010 0101 0101 0000	158.145	0010 0101 0111 0001	158.310	0010 0101 1001 0010
157.820	0010 0101 0011 0000	157.985	0010 0101 0101 0001	158.150	0010 0101 0111 0010	158.315	0010 0101 1001 0011
157.825	0010 0101 0011 0001	157.990	0010 0101 0101 0010	158.155	0010 0101 0111 0011	158.320	0010 0101 1001 0100
157.830	0010 0101 0011 0010	157.995	0010 0101 0101 0011	158.160	0010 0101 0111 0100	158.325	0010 0101 1001 0101
157.835	0010 0101 0011 0011	158.000	0010 0101 0101 0100	158.165	0010 0101 0111 0101	158.330	0010 0101 1001 0110
157.840	0010 0101 0011 0100	158.005	0010 0101 0101 0101	158.170	0010 0101 0111 0110	158.335	0010 0101 1001 0111
157.845	0010 0101 0011 0101	158.010	0010 0101 0101 0110	158.175	0010 0101 0111 0111	158.340	0010 0101 1001 1000
157.850	0010 0101 0011 0110	158.015	0010 0101 0101 0111	158.180	0010 0101 0111 1000	158.345	0010 0101 1001 1001
157.855	0010 0101 0011 0111	158.020	0010 0101 0101 1000	158.185	0010 0101 0111 1001	158.350	0010 0101 1001 1010
157.860	0010 0101 0011 1000	158.025	0010 0101 0101 1001	158.190	0010 0101 0111 1010	158.355	0010 0101 1001 1011
157.865	0010 0101 0011 1001	158.030	0010 0101 0101 1010	158.195	0010 0101 0111 1011	158.360	0010 0101 1001 1100
157.870	0010 0101 0011 1010	158.035	0010 0101 0101 1011	158.200	0010 0101 0111 1100	158.365	0010 0101 1001 1101
157.875	0010 0101 0011 1011	158.040	0010 0101 0101 1100	158.205	0010 0101 0111 1101	158.370	0010 0101 1001 1110
157.880	0010 0101 0011 1100	158.045	0010 0101 0101 1101	158.210	0010 0101 0111 1110	158.375	0010 0101 1001 1111
157.885	0010 0101 0011 1101	158.050	0010 0101 0101 1110	158.215	0010 0101 0111 1111	158.380	0010 0101 1010 0000
157.890	0010 0101 0011 1110	158.055	0010 0101 0110 1111	158.220	0010 0101 1000 0000	158.385	0010 0101 1010 0001
157.895	0010 0101 0011 1111	158.060	0010 0101 0110 0000	158.225	0010 0101 1000 0001	158.390	0010 0101 1010 0010
157.900	0010 0101 0100 0000	158.065	0010 0101 0110 0001	158.230	0010 0101 1000 0010	158.395	0010 0101 1010 0011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
158.400	0010 0101 1010 0100	158.565	0010 0101 1100 0101	158.730	0010 0101 1110 0110	158.895	0010 0110 0000 0111
158.405	0010 0101 1010 0101	158.570	0010 0101 1100 0110	158.735	0010 0101 1110 0111	158.900	0010 0110 0000 1000
158.410	0010 0101 1010 0110	158.575	0010 0101 1100 0111	158.740	0010 0101 1110 1000	158.905	0010 0110 0000 1001
158.415	0010 0101 1010 0111	158.580	0010 0101 1100 1000	158.745	0010 0101 1110 1001	158.910	0010 0110 0000 1010
158.420	0010 0101 1010 1000	158.585	0010 0101 1100 1001	158.750	0010 0101 1110 1010	158.915	0010 0110 0000 1011
158.425	0010 0101 1010 1001	158.590	0010 0101 1100 1010	158.755	0010 0101 1110 1011	158.920	0010 0110 0000 1100
158.430	0010 0101 1010 1010	158.595	0010 0101 1100 1011	158.760	0010 0101 1110 1100	158.925	0010 0110 0000 1101
158.435	0010 0101 1010 1011	158.600	0010 0101 1100 1100	158.765	0010 0101 1110 1101	158.930	0010 0110 0000 1110
158.440	0010 0101 1010 1100	158.605	0010 0101 1100 1101	158.770	0010 0101 1110 1110	158.935	0010 0110 0000 1111
158.445	0010 0101 1010 1101	158.610	0010 0101 1100 1110	158.775	0010 0101 1110 1111	158.940	0010 0110 0001 0000
158.450	0010 0101 1010 1110	158.615	0010 0101 1100 1111	158.780	0010 0101 1111 0000	158.945	0010 0110 0001 0001
158.455	0010 0101 1010 1111	158.620	0010 0101 1101 0000	158.785	0010 0101 1111 0001	158.950	0010 0110 0001 0010
158.460	0010 0101 1011 0000	158.625	0010 0101 1101 0001	158.790	0010 0101 1111 0010	158.955	0010 0110 0001 0011
158.465	0010 0101 1011 0001	158.630	0010 0101 1101 0010	158.795	0010 0101 1111 0011	158.960	0010 0110 0001 0100
158.470	0010 0101 1011 0010	158.635	0010 0101 1101 0011	158.800	0010 0101 1111 0100	158.965	0010 0110 0001 0101
158.475	0010 0101 1011 0011	158.640	0010 0101 1101 0100	158.805	0010 0101 1111 0101	158.970	0010 0110 0001 0110
158.480	0010 0101 1011 0100	158.645	0010 0101 1101 0101	158.810	0010 0101 1111 0110	158.975	0010 0110 0001 0111
158.485	0010 0101 1011 0101	158.650	0010 0101 1101 0110	158.815	0010 0101 1111 0111	158.980	0010 0110 0001 1000
158.490	0010 0101 1011 0110	158.655	0010 0101 1101 0111	158.820	0010 0101 1111 1000	158.985	0010 0110 0001 1001
158.495	0010 0101 1011 0111	158.660	0010 0101 1101 1000	158.825	0010 0101 1111 1001	158.990	0010 0110 0001 1010
158.500	0010 0101 1011 1000	158.665	0010 0101 1101 1001	158.830	0010 0101 1111 1010	158.995	0010 0110 0001 1011
158.505	0010 0101 1011 1001	158.670	0010 0101 1101 1010	158.835	0010 0101 1111 1011	159.000	0010 0110 0001 1100
158.510	0010 0101 1011 1010	158.675	0010 0101 1101 1011	158.840	0010 0101 1111 1100	159.005	0010 0110 0001 1101
158.515	0010 0101 1011 1011	158.680	0010 0101 1101 1100	158.845	0010 0101 1111 1101	159.010	0010 0110 0001 1110
158.520	0010 0101 1011 1100	158.685	0010 0101 1101 1101	158.850	0010 0101 1111 1110	159.015	0010 0110 0001 1111
158.525	0010 0101 1011 1101	158.690	0010 0101 1101 1110	158.855	0010 0101 1111 1111	159.020	0010 0110 0010 0000
158.530	0010 0101 1011 1110	158.695	0010 0101 1101 1111	158.860	0010 0110 0000 0000	159.025	0010 0110 0010 0001
158.535	0010 0101 1011 1111	158.700	0010 0101 1110 0000	158.865	0010 0110 0000 0001	159.030	0010 0110 0010 0010
158.540	0010 0101 1100 0000	158.705	0010 0101 1110 0001	158.870	0010 0110 0000 0010	159.035	0010 0110 0010 0011
158.545	0010 0101 1100 0001	158.710	0010 0101 1110 0010	158.875	0010 0110 0000 0011	159.040	0010 0110 0010 0100
158.550	0010 0101 1100 0010	158.715	0010 0101 1110 0011	158.880	0010 0110 0000 0100	159.045	0010 0110 0010 0101
158.555	0010 0101 1100 0011	158.720	0010 0101 1110 0100	158.885	0010 0110 0000 0101	159.050	0010 0110 0010 0110
158.560	0010 0101 1100 0100	158.725	0010 0101 1110 0101	158.890	0010 0110 0000 0110	159.055	0010 0110 0010 0111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
159.060	0010 0110 0010 1000	159.225	0010 0110 0100 1001	159.390	0010 0110 0110 1010	159.555	0010 0110 1000 1011
159.065	0010 0110 0010 1001	159.230	0010 0110 0100 1010	159.395	0010 0110 0110 1011	159.560	0010 0110 1000 1100
159.070	0010 0110 0010 1010	159.235	0010 0110 0100 1011	159.400	0010 0110 0110 1100	159.565	0010 0110 1000 1101
159.075	0010 0110 0010 1011	159.240	0010 0110 0100 1100	159.405	0010 0110 0110 1101	159.570	0010 0110 1000 1110
159.080	0010 0110 0010 1100	159.245	0010 0110 0100 1101	159.410	0010 0110 0110 1110	159.575	0010 0110 1000 1111
159.085	0010 0110 0010 1101	159.250	0010 0110 0100 1110	159.415	0010 0110 0110 1111	159.580	0010 0110 1001 0000
159.090	0010 0110 0010 1110	159.255	0010 0110 0100 1111	159.420	0010 0110 0111 0000	159.585	0010 0110 1001 0001
159.095	0010 0110 0010 1111	159.260	0010 0110 0101 0000	159.425	0010 0110 0111 0001	159.590	0010 0110 1001 0010
159.100	0010 0110 0011 0000	159.265	0010 0110 0101 0001	159.430	0010 0110 0111 0010	159.595	0010 0110 1001 0011
159.105	0010 0110 0011 0001	159.270	0010 0110 0101 0010	159.435	0010 0110 0111 0011	159.600	0010 0110 1001 0100
159.110	0010 0110 0011 0010	159.275	0010 0110 0101 0011	159.440	0010 0110 0111 0100	159.605	0010 0110 1001 0101
159.115	0010 0110 0011 0011	159.280	0010 0110 0101 0100	159.445	0010 0110 0111 0101	159.610	0010 0110 1001 0110
159.120	0010 0110 0011 0100	159.285	0010 0110 0101 0101	159.450	0010 0110 0111 0110	159.615	0010 0110 1001 0111
159.125	0010 0110 0011 0101	159.290	0010 0110 0101 0110	159.455	0010 0110 0111 0111	159.620	0010 0110 1001 1000
159.130	0010 0110 0011 0110	159.295	0010 0110 0101 0111	159.460	0010 0110 0111 1000	159.625	0010 0110 1001 1001
159.135	0010 0110 0011 0111	159.300	0010 0110 0101 1000	159.465	0010 0110 0111 1001	159.630	0010 0110 1001 1010
159.140	0010 0110 0011 1000	159.305	0010 0110 0101 1001	159.470	0010 0110 0111 1010	159.635	0010 0110 1001 1011
159.145	0010 0110 0011 1001	159.310	0010 0110 0101 1010	159.475	0010 0110 0111 1011	159.640	0010 0110 1001 1100
159.150	0010 0110 0011 1010	159.315	0010 0110 0101 1011	159.480	0010 0110 0111 1100	159.645	0010 0110 1001 1101
159.155	0010 0110 0011 1011	159.320	0010 0110 0101 1100	159.485	0010 0110 0111 1101	159.650	0010 0110 1001 1110
159.160	0010 0110 0011 1100	159.325	0010 0110 0101 1101	159.490	0010 0110 0111 1110	159.655	0010 0110 1001 1111
159.165	0010 0110 0011 1101	159.330	0010 0110 0101 1110	159.495	0010 0110 0111 1111	159.660	0010 0110 1010 0000
159.170	0010 0110 0011 1110	159.335	0010 0110 0101 1111	159.500	0010 0110 1000 0000	159.665	0010 0110 1010 0001
159.175	0010 0110 0011 1111	159.340	0010 0110 0110 0000	159.505	0010 0110 1000 0001	159.670	0010 0110 1010 0010
159.180	0010 0110 0100 0000	159.345	0010 0110 0110 0001	159.510	0010 0110 1000 0010	159.675	0010 0110 1010 0011
159.185	0010 0110 0100 0001	159.350	0010 0110 0110 0010	159.515	0010 0110 1000 0011	159.680	0010 0110 1010 0100
159.190	0010 0110 0100 0010	159.355	0010 0110 0110 0011	159.520	0010 0110 1000 0100	159.685	0010 0110 1010 0101
159.195	0010 0110 0100 0011	159.360	0010 0110 0110 0100	159.525	0010 0110 1000 0101	159.690	0010 0110 1010 0110
159.200	0010 0110 0100 0100	159.365	0010 0110 0110 0101	159.530	0010 0110 1000 0110	159.695	0010 0110 1010 0111
159.205	0010 0110 0100 0101	159.370	0010 0110 0110 0110	159.535	0010 0110 1000 0111	159.700	0010 0110 1010 1000
159.210	0010 0110 0100 0110	159.375	0010 0110 0110 0111	159.540	0010 0110 1000 1000	159.705	0010 0110 1010 1001
159.215	0010 0110 0100 0111	159.380	0010 0110 0110 1000	159.545	0010 0110 1000 1001	159.710	0010 0110 1010 1010
159.220	0010 0110 0100 1000	159.385	0010 0110 0110 1001	159.550	0010 0110 1000 1010	159.715	0010 0110 1010 1011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
159.720	0010 0110 1010 1100	159.885	0010 0110 1100 1101	160.050	0010 0110 1110 1110	160.215	0010 0111 0000 1111
159.725	0010 0110 1010 1101	159.890	0010 0110 1100 1110	160.055	0010 0110 1110 1111	160.220	0010 0111 0001 0000
159.730	0010 0110 1010 1110	159.895	0010 0110 1100 1111	160.060	0010 0110 1111 0000	160.225	0010 0111 0001 0001
159.735	0010 0110 1010 1111	159.900	0010 0110 1101 0000	160.065	0010 0110 1111 0001	160.230	0010 0111 0001 0010
159.740	0010 0110 1011 0000	159.905	0010 0110 1101 0001	160.070	0010 0110 1111 0010	160.235	0010 0111 0001 0011
159.745	0010 0110 1011 0001	159.910	0010 0110 1101 0010	160.075	0010 0110 1111 0011	160.240	0010 0111 0001 0100
159.750	0010 0110 1011 0010	159.915	0010 0110 1101 0011	160.080	0010 0110 1111 0100	160.245	0010 0111 0001 0101
159.755	0010 0110 1011 0011	159.920	0010 0110 1101 0100	160.085	0010 0110 1111 0101	160.250	0010 0111 0001 0110
159.760	0010 0110 1011 0100	159.925	0010 0110 1101 0101	160.090	0010 0110 1111 0110	160.255	0010 0111 0001 0111
159.765	0010 0110 1011 0101	159.930	0010 0110 1101 0110	160.095	0010 0110 1111 0111	160.260	0010 0111 0001 1000
159.770	0010 0110 1011 0110	159.935	0010 0110 1101 0111	160.100	0010 0110 1111 1000	160.265	0010 0111 0001 1001
159.775	0010 0110 1011 0111	159.940	0010 0110 1101 1000	160.105	0010 0110 1111 1001	160.270	0010 0111 0001 1010
159.780	0010 0110 1011 1000	159.945	0010 0110 1101 1001	160.110	0010 0110 1111 1010	160.275	0010 0111 0001 1011
159.785	0010 0110 1011 1001	159.950	0010 0110 1101 1010	160.115	0010 0110 1111 1011	160.280	0010 0111 0001 1100
159.790	0010 0110 1011 1010	159.955	0010 0110 1101 1011	160.120	0010 0110 1111 1100	160.285	0010 0111 0001 1101
159.795	0010 0110 1011 1011	159.960	0010 0110 1101 1100	160.125	0010 0110 1111 1101	160.290	0010 0111 0001 1110
159.800	0010 0110 1011 1100	159.965	0010 0110 1101 1101	160.130	0010 0110 1111 1110	160.295	0010 0111 0001 1111
159.805	0010 0110 1011 1101	159.970	0010 0110 1101 1110	160.135	0010 0110 1111 1111	160.300	0010 0111 0010 0000
159.810	0010 0110 1011 1110	159.975	0010 0110 1101 1111	160.140	0010 0111 0000 0000	160.305	0010 0111 0010 0001
159.815	0010 0110 1011 1111	159.980	0010 0110 1110 0000	160.145	0010 0111 0000 0001	160.310	0010 0111 0010 0010
159.820	0010 0110 1100 0000	159.985	0010 0110 1110 0001	160.150	0010 0111 0000 0010	160.315	0010 0111 0010 0011
159.825	0010 0110 1100 0001	159.990	0010 0110 1110 0010	160.155	0010 0111 0000 0011	160.320	0010 0111 0010 0100
159.830	0010 0110 1100 0010	159.995	0010 0110 1110 0011	160.160	0010 0111 0000 0100	160.325	0010 0111 0010 0101
159.835	0010 0110 1100 0011	160.000	0010 0110 1110 0100	160.165	0010 0111 0000 0101	160.330	0010 0111 0010 0110
159.840	0010 0110 1100 0100	160.005	0010 0110 1110 0101	160.170	0010 0111 0000 0110	160.335	0010 0111 0010 0111
159.845	0010 0110 1100 0101	160.010	0010 0110 1110 0110	160.175	0010 0111 0000 0111	160.340	0010 0111 0010 1000
159.850	0010 0110 1100 0110	160.015	0010 0110 1110 0111	160.180	0010 0111 0000 1000	160.345	0010 0111 0010 1001
159.855	0010 0110 1100 0111	160.020	0010 0110 1110 1000	160.185	0010 0111 0000 1001	160.350	0010 0111 0010 1010
159.860	0010 0110 1100 1000	160.025	0010 0110 1110 1001	160.190	0010 0111 0000 1010	160.355	0010 0111 0010 1011
159.865	0010 0110 1100 1001	160.030	0010 0110 1110 1010	160.195	0010 0111 0000 1011	160.360	0010 0111 0010 1100
159.870	0010 0110 1100 1010	160.035	0010 0110 1110 1011	160.200	0010 0111 0000 1100	160.365	0010 0111 0010 1101
159.875	0010 0110 1100 1011	160.040	0010 0110 1110 1100	160.205	0010 0111 0000 1101	160.370	0010 0111 0010 1110
159.880	0010 0110 1100 1100	160.045	0010 0110 1110 1101	160.210	0010 0111 0000 1110	160.375	0010 0111 0010 1111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
160.380	0010 0111 0011 0000	160.545	0010 0111 0101 0001	160.710	0010 0111 0111 0010	160.875	0010 0111 1001 0011
160.385	0010 0111 0011 0001	160.550	0010 0111 0101 0010	160.715	0010 0111 0111 0011	160.880	0010 0111 1001 0100
160.390	0010 0111 0011 0010	160.555	0010 0111 0101 0011	160.720	0010 0111 0111 0100	160.885	0010 0111 1001 0101
160.395	0010 0111 0011 0011	160.560	0010 0111 0101 0100	160.725	0010 0111 0111 0101	160.890	0010 0111 1001 0110
160.400	0010 0111 0011 0100	160.565	0010 0111 0101 0101	160.730	0010 0111 0111 0110	160.895	0010 0111 1001 0111
160.405	0010 0111 0011 0101	160.570	0010 0111 0101 0110	160.735	0010 0111 0111 0111	160.900	0010 0111 1001 1000
160.410	0010 0111 0011 0110	160.575	0010 0111 0101 0111	160.740	0010 0111 0111 1000	160.905	0010 0111 1001 1001
160.415	0010 0111 0011 0111	160.580	0010 0111 0101 1000	160.745	0010 0111 0111 1001	160.910	0010 0111 1001 1010
160.420	0010 0111 0011 1000	160.585	0010 0111 0101 1001	160.750	0010 0111 0111 1010	160.915	0010 0111 1001 1011
160.425	0010 0111 0011 1001	160.590	0010 0111 0101 1010	160.755	0010 0111 0111 1011	160.920	0010 0111 1001 1100
160.430	0010 0111 0011 1010	160.595	0010 0111 0101 1011	160.760	0010 0111 0111 1100	160.925	0010 0111 1001 1101
160.435	0010 0111 0011 1011	160.600	0010 0111 0101 1100	160.765	0010 0111 0111 1101	160.930	0010 0111 1001 1110
160.440	0010 0111 0011 1100	160.605	0010 0111 0101 1101	160.770	0010 0111 0111 1110	160.935	0010 0111 1001 1111
160.445	0010 0111 0011 1101	160.610	0010 0111 0101 1110	160.775	0010 0111 0111 1111	160.940	0010 0111 1010 0000
160.450	0010 0111 0011 1110	160.615	0010 0111 0101 1111	160.780	0010 0111 1000 0000	160.945	0010 0111 1010 0001
160.455	0010 0111 0011 1111	160.620	0010 0111 0110 0000	160.785	0010 0111 1000 0001	160.950	0010 0111 1010 0010
160.460	0010 0111 0100 0000	160.625	0010 0111 0110 0001	160.790	0010 0111 1000 0010	160.955	0010 0111 1010 0011
160.465	0010 0111 0100 0001	160.630	0010 0111 0110 0010	160.795	0010 0111 1000 0011	160.960	0010 0111 1010 0100
160.470	0010 0111 0100 0010	160.635	0010 0111 0110 0011	160.800	0010 0111 1000 0100	160.965	0010 0111 1010 0101
160.475	0010 0111 0100 0011	160.640	0010 0111 0110 0100	160.805	0010 0111 1000 0101	160.970	0010 0111 1010 0110
160.480	0010 0111 0100 0100	160.645	0010 0111 0110 0101	160.810	0010 0111 1000 0110	160.975	0010 0111 1010 0111
160.485	0010 0111 0100 0101	160.650	0010 0111 0110 0110	160.815	0010 0111 1000 0111	160.980	0010 0111 1010 1000
160.490	0010 0111 0100 0110	160.655	0010 0111 0110 0111	160.820	0010 0111 1000 1000	160.985	0010 0111 1010 1001
160.495	0010 0111 0100 0111	160.660	0010 0111 0110 1000	160.825	0010 0111 1000 1001	160.990	0010 0111 1010 1010
160.500	0010 0111 0100 1000	160.665	0010 0111 0110 1001	160.830	0010 0111 1000 1010	160.995	0010 0111 1010 1011
160.505	0010 0111 0100 1001	160.670	0010 0111 0110 1010	160.835	0010 0111 1000 1011	161.000	0010 0111 1010 1100
160.510	0010 0111 0100 1010	160.675	0010 0111 0110 1011	160.840	0010 0111 1000 1100	161.005	0010 0111 1010 1101
160.515	0010 0111 0100 1011	160.680	0010 0111 0110 1100	160.845	0010 0111 1000 1101	161.010	0010 0111 1010 1110
160.520	0010 0111 0100 1100	160.685	0010 0111 0110 1101	160.850	0010 0111 1000 1110	161.015	0010 0111 1010 1111
160.525	0010 0111 0100 1101	160.690	0010 0111 0110 1110	160.855	0010 0111 1000 1111	161.020	0010 0111 1011 0000
160.530	0010 0111 0100 1110	160.695	0010 0111 0110 1111	160.860	0010 0111 1001 0000	161.025	0010 0111 1011 0001
160.535	0010 0111 0100 1111	160.700	0010 0111 0111 0000	160.865	0010 0111 1001 0001	161.030	0010 0111 1011 0010
160.540	0010 0111 0101 0000	160.705	0010 0111 0111 0001	160.870	0010 0111 1001 0010	161.035	0010 0111 1011 0011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
161.040	0010 0111 1011 0100	161.205	0010 0111 1101 0101	161.370	0010 0111 1111 0110	161.535	0010 1000 0001 0111
161.045	0010 0111 1011 0101	161.210	0010 0111 1101 0110	161.375	0010 0111 1111 0111	161.540	0010 1000 0001 1000
161.050	0010 0111 1011 0110	161.215	0010 0111 1101 0111	161.380	0010 0111 1111 1000	161.545	0010 1000 0001 1001
161.055	0010 0111 1011 0111	161.220	0010 0111 1101 1000	161.385	0010 0111 1111 1001	161.550	0010 1000 0001 1010
161.060	0010 0111 1011 1000	161.225	0010 0111 1101 1001	161.390	0010 0111 1111 1010	161.555	0010 1000 0001 1011
161.065	0010 0111 1011 1001	161.230	0010 0111 1101 1010	161.395	0010 0111 1111 1011	161.560	0010 1000 0001 1100
161.070	0010 0111 1011 1010	161.235	0010 0111 1101 1011	161.400	0010 0111 1111 1100	161.565	0010 1000 0001 1101
161.075	0010 0111 1011 1011	161.240	0010 0111 1101 1100	161.405	0010 0111 1111 1101	161.570	0010 1000 0001 1110
161.080	0010 0111 1011 1100	161.245	0010 0111 1101 1101	161.410	0010 0111 1111 1110	161.575	0010 1000 0001 1111
161.085	0010 0111 1011 1101	161.250	0010 0111 1101 1110	161.415	0010 0111 1111 1111	161.580	0010 1000 0010 0000
161.090	0010 0111 1011 1110	161.255	0010 0111 1101 1111	161.420	0010 1000 0000 0000	161.585	0010 1000 0010 0001
161.095	0010 0111 1011 1111	161.260	0010 0111 1110 0000	161.425	0010 1000 0000 0001	161.590	0010 1000 0010 0010
161.100	0010 0111 1100 0000	161.265	0010 0111 1110 0001	161.430	0010 1000 0000 0010	161.595	0010 1000 0010 0011
161.105	0010 0111 1100 0001	161.270	0010 0111 1110 0010	161.435	0010 1000 0000 0011	161.600	0010 1000 0010 0100
161.110	0010 0111 1100 0010	161.275	0010 0111 1110 0011	161.440	0010 1000 0000 0100	161.605	0010 1000 0010 0101
161.115	0010 0111 1100 0011	161.280	0010 0111 1110 0100	161.445	0010 1000 0000 0101	161.610	0010 1000 0010 0110
161.120	0010 0111 1100 0100	161.285	0010 0111 1110 0101	161.450	0010 1000 0000 0110	161.615	0010 1000 0010 0111
161.125	0010 0111 1100 0101	161.290	0010 0111 1110 0110	161.455	0010 1000 0000 0111	161.620	0010 1000 0010 1000
161.130	0010 0111 1100 0110	161.295	0010 0111 1110 0111	161.460	0010 1000 0000 1000	161.625	0010 1000 0010 1001
161.135	0010 0111 1100 0111	161.300	0010 0111 1110 1000	161.465	0010 1000 0000 1001	161.630	0010 1000 0010 1010
161.140	0010 0111 1100 1000	161.305	0010 0111 1110 1001	161.470	0010 1000 0000 1010	161.635	0010 1000 0010 1011
161.145	0010 0111 1100 1001	161.310	0010 0111 1110 1010	161.475	0010 1000 0000 1011	161.640	0010 1000 0010 1100
161.150	0010 0111 1100 1010	161.315	0010 0111 1110 1011	161.480	0010 1000 0000 1100	161.645	0010 1000 0010 1101
161.155	0010 0111 1100 1011	161.320	0010 0111 1110 1100	161.485	0010 1000 0000 1101	161.650	0010 1000 0010 1110
161.160	0010 0111 1100 1100	161.325	0010 0111 1110 1101	161.490	0010 1000 0000 1110	161.655	0010 1000 0010 1111
161.165	0010 0111 1100 1101	161.330	0010 0111 1110 1110	161.495	0010 1000 0000 1111	161.660	0010 1000 0011 0000
161.170	0010 0111 1100 1110	161.335	0010 0111 1110 1111	161.500	0010 1000 0001 0000	161.665	0010 1000 0011 0001
161.175	0010 0111 1100 1111	161.340	0010 0111 1111 0000	161.505	0010 1000 0001 0001	161.670	0010 1000 0011 0010
161.180	0010 0111 1101 0000	161.345	0010 0111 1111 0001	161.510	0010 1000 0001 0010	161.675	0010 1000 0011 0011
161.185	0010 0111 1101 0001	161.350	0010 0111 1111 0010	161.515	0010 1000 0001 0011	161.680	0010 1000 0011 0100
161.190	0010 0111 1101 0010	161.355	0010 0111 1111 0011	161.520	0010 1000 0001 0100	161.685	0010 1000 0011 0101
161.195	0010 0111 1101 0011	161.360	0010 0111 1111 0100	161.525	0010 1000 0001 0101	161.690	0010 1000 0011 0110
161.200	0010 0111 1101 0100	161.365	0010 0111 1111 0101	161.530	0010 1000 0001 0110	161.695	0010 1000 0011 0111

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
161.700	0010	1000	0011	1000	161.865	0010	1000	0101	1001	162.030	0010	1000	0111	1010	162.195	0010	1000	1001	1011
161.705	0010	1000	0011	1001	161.870	0010	1000	0101	1010	162.035	0010	1000	0111	1011	162.200	0010	1000	1001	1100
161.710	0010	1000	0011	1010	161.875	0010	1000	0101	1011	162.040	0010	1000	0111	1100	162.205	0010	1000	1001	1101
161.715	0010	1000	0011	1011	161.880	0010	1000	0101	1100	162.045	0010	1000	0111	1101	162.210	0010	1000	1001	1110
161.720	0010	1000	0011	1100	161.885	0010	1000	0101	1101	162.050	0010	1000	0111	1110	162.215	0010	1000	1001	1111
161.725	0010	1000	0011	1101	161.890	0010	1000	0101	1110	162.055	0010	1000	0111	1111	162.220	0010	1000	1010	0000
161.730	0010	1000	0011	1110	161.895	0010	1000	0101	1111	162.060	0010	1000	1000	0000	162.225	0010	1000	1010	0001
161.735	0010	1000	0011	1111	161.900	0010	1000	0110	0000	162.065	0010	1000	1000	0001	162.230	0010	1000	1010	0010
161.740	0010	1000	0100	0000	161.905	0010	1000	0110	0001	162.070	0010	1000	1000	0010	162.235	0010	1000	1010	0011
161.745	0010	1000	0100	0001	161.910	0010	1000	0110	0010	162.075	0010	1000	1000	0011	162.240	0010	1000	1010	0100
161.750	0010	1000	0100	0010	161.915	0010	1000	0110	0011	162.080	0010	1000	1000	0100	162.245	0010	1000	1010	0101
161.755	0010	1000	0100	0011	161.920	0010	1000	0110	0100	162.085	0010	1000	1000	0101	162.250	0010	1000	1010	0110
161.760	0010	1000	0100	0100	161.925	0010	1000	0110	0101	162.090	0010	1000	1000	0110	162.255	0010	1000	1010	0111
161.765	0010	1000	0100	0101	161.930	0010	1000	0110	0110	162.095	0010	1000	1000	0111	162.260	0010	1000	1010	1000
161.770	0010	1000	0100	0110	161.935	0010	1000	0110	0111	162.100	0010	1000	1000	1000	162.265	0010	1000	1010	1001
161.775	0010	1000	0100	0111	161.940	0010	1000	0110	1000	162.105	0010	1000	1000	1001	162.270	0010	1000	1010	1010
161.780	0010	1000	0100	1000	161.945	0010	1000	0110	1001	162.110	0010	1000	1000	1010	162.275	0010	1000	1010	1011
161.785	0010	1000	0100	1001	161.950	0010	1000	0110	1010	162.115	0010	1000	1000	1011	162.280	0010	1000	1010	1100
161.790	0010	1000	0100	1010	161.955	0010	1000	0110	1011	162.120	0010	1000	1000	1100	162.285	0010	1000	1010	1101
161.795	0010	1000	0100	1011	161.960	0010	1000	0110	1100	162.125	0010	1000	1000	1101	162.290	0010	1000	1010	1110
161.800	0010	1000	0100	1100	161.965	0010	1000	0110	1101	162.130	0010	1000	1000	1110	162.295	0010	1000	1010	1111
161.805	0010	1000	0100	1101	161.970	0010	1000	0110	1110	162.135	0010	1000	1000	1111	162.300	0010	1000	1011	0000
161.810	0010	1000	0100	1110	161.975	0010	1000	0110	1111	162.140	0010	1000	1001	0000	162.305	0010	1000	1011	0001
161.815	0010	1000	0100	1111	161.980	0010	1000	0111	0000	162.145	0010	1000	1001	0001	162.310	0010	1000	1011	0010
161.820	0010	1000	0101	0000	161.985	0010	1000	0111	0001	162.150	0010	1000	1001	0010	162.315	0010	1000	1011	0011
161.825	0010	1000	0101	0001	161.990	0010	1000	0111	0010	162.155	0010	1000	1001	0011	162.320	0010	1000	1011	0100
161.830	0010	1000	0101	0010	161.995	0010	1000	0111	0011	162.160	0010	1000	1001	0100	162.325	0010	1000	1011	0101
161.835	0010	1000	0101	0011	162.000	0010	1000	0111	0100	162.165	0010	1000	1001	0101	162.330	0010	1000	1011	0110
161.840	0010	1000	0101	0100	162.005	0010	1000	0111	0101	162.170	0010	1000	1001	0110	162.335	0010	1000	1011	0111
161.845	0010	1000	0101	0101	162.010	0010	1000	0111	0110	162.175	0010	1000	1001	0111	162.340	0010	1000	1011	1000
161.850	0010	1000	0101	0110	162.015	0010	1000	0111	0111	162.180	0010	1000	1001	1000	162.345	0010	1000	1011	1001
161.855	0010	1000	0101	0111	162.020	0010	1000	0111	1000	162.185	0010	1000	1001	1001	162.350	0010	1000	1011	1010
161.860	0010	1000	0101	1000	162.025	0010	1000	0111	1001	162.190	0010	1000	1001	1010	162.355	0010	1000	1011	1011

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
162.360	0010	1000	1011	1100	162.525	0010	1000	1101	1101	162.690	0010	1000	1111	1110	162.855	0010	1001	0001	1111
162.365	0010	1000	1011	1101	162.530	0010	1000	1101	1110	162.695	0010	1000	1111	1111	162.860	0010	1001	0010	0000
162.370	0010	1000	1011	1110	162.535	0010	1000	1101	1111	162.700	0010	1001	0000	0000	162.865	0010	1001	0010	0001
162.375	0010	1000	1011	1111	162.540	0010	1000	1110	0000	162.705	0010	1001	0000	0001	162.870	0010	1001	0010	0010
162.380	0010	1000	1100	0000	162.545	0010	1000	1110	0001	162.710	0010	1001	0000	0010	162.875	0010	1001	0010	0011
162.385	0010	1000	1100	0001	162.550	0010	1000	1110	0010	162.715	0010	1001	0000	0011	162.880	0010	1001	0010	0100
162.390	0010	1000	1100	0010	162.555	0010	1000	1110	0011	162.720	0010	1001	0000	0100	162.885	0010	1001	0010	0101
162.395	0010	1000	1100	0011	162.560	0010	1000	1110	0100	162.725	0010	1001	0000	0101	162.890	0010	1001	0010	0110
162.400	0010	1000	1100	0100	162.565	0010	1000	1110	0101	162.730	0010	1001	0000	0110	162.895	0010	1001	0010	0111
162.405	0010	1000	1100	0101	162.570	0010	1000	1110	0110	162.735	0010	1001	0000	0111	162.900	0010	1001	0010	1000
162.410	0010	1000	1100	0110	162.575	0010	1000	1110	0111	162.740	0010	1001	0000	1000	162.905	0010	1001	0010	1001
162.415	0010	1000	1100	0111	162.580	0010	1000	1110	1000	162.745	0010	1001	0000	1001	162.910	0010	1001	0010	1010
162.420	0010	1000	1100	1000	162.585	0010	1000	1110	1001	162.750	0010	1001	0000	1010	162.915	0010	1001	0010	1011
162.425	0010	1000	1100	1001	162.590	0010	1000	1110	1010	162.755	0010	1001	0000	1011	162.920	0010	1001	0010	1100
162.430	0010	1000	1100	1010	162.595	0010	1000	1110	1011	162.760	0010	1001	0000	1100	162.925	0010	1001	0010	1101
162.435	0010	1000	1100	1011	162.600	0010	1000	1110	1100	162.765	0010	1001	0000	1101	162.930	0010	1001	0010	1110
162.440	0010	1000	1100	1100	162.605	0010	1000	1110	1101	162.770	0010	1001	0000	1110	162.935	0010	1001	0010	1111
162.445	0010	1000	1100	1101	162.610	0010	1000	1110	1110	162.775	0010	1001	0000	1111	162.940	0010	1001	0011	0000
162.450	0010	1000	1100	1110	162.615	0010	1000	1110	1111	162.780	0010	1001	0001	0000	162.945	0010	1001	0011	0001
162.455	0010	1000	1100	1111	162.620	0010	1000	1111	0000	162.785	0010	1001	0001	0001	162.950	0010	1001	0011	0010
162.460	0010	1000	1101	0000	162.625	0010	1000	1111	0001	162.790	0010	1001	0001	0010	162.955	0010	1001	0011	0011
162.465	0010	1000	1101	0001	162.630	0010	1000	1111	0010	162.795	0010	1001	0001	0011	162.960	0010	1001	0011	0100
162.470	0010	1000	1101	0010	162.635	0010	1000	1111	0011	162.800	0010	1001	0001	0100	162.965	0010	1001	0011	0101
162.475	0010	1000	1101	0011	162.640	0010	1000	1111	0100	162.805	0010	1001	0001	0101	162.970	0010	1001	0011	0110
162.480	0010	1000	1101	0100	162.645	0010	1000	1111	0101	162.810	0010	1001	0001	0110	162.975	0010	1001	0011	0111
162.485	0010	1000	1101	0101	162.650	0010	1000	1111	0110	162.815	0010	1001	0001	0111	162.980	0010	1001	0011	1000
162.490	0010	1000	1101	0110	162.655	0010	1000	1111	0111	162.820	0010	1001	0001	1000	162.985	0010	1001	0011	1001
162.495	0010	1000	1101	0111	162.660	0010	1000	1111	1000	162.825	0010	1001	0001	1001	162.990	0010	1001	0011	1010
162.500	0010	1000	1101	1000	162.665	0010	1000	1111	1001	162.830	0010	1001	0001	1010	162.995	0010	1001	0011	1011
162.505	0010	1000	1101	1001	162.670	0010	1000	1111	1010	162.835	0010	1001	0001	1011	163.000	0010	1001	0011	1100
162.510	0010	1000	1101	1010	162.675	0010	1000	1111	1011	162.840	0010	1001	0001	1100	163.005	0010	1001	0011	1101
162.515	0010	1000	1101	1011	162.680	0010	1000	1111	1100	162.845	0010	1001	0001	1101	163.010	0010	1001	0011	1110
162.520	0010	1000	1101	1100	162.685	0010	1000	1111	1101	162.850	0010	1001	0001	1110	163.015	0010	1001	0011	1111

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
163.020	0010	1001	0100	0000	163.185	0010	1001	0110	0001	163.350	0010	1001	1000	0010	163.515	0010	1001	1010	0011
163.025	0010	1001	0100	0001	163.190	0010	1001	0110	0010	163.355	0010	1001	1000	0011	163.520	0010	1001	1010	0100
163.030	0010	1001	0100	0010	163.195	0010	1001	0110	0011	163.360	0010	1001	1000	0100	163.525	0010	1001	1010	0101
163.035	0010	1001	0100	0011	163.200	0010	1001	0110	0100	163.365	0010	1001	1000	0101	163.530	0010	1001	1010	0110
163.040	0010	1001	0100	0100	163.205	0010	1001	0110	0101	163.370	0010	1001	1000	0110	163.535	0010	1001	1010	0111
163.045	0010	1001	0100	0101	163.210	0010	1001	0110	0110	163.375	0010	1001	1000	0111	163.540	0010	1001	1010	1000
163.050	0010	1001	0100	0110	163.215	0010	1001	0110	0111	163.380	0010	1001	1000	1000	163.545	0010	1001	1010	1001
163.055	0010	1001	0100	0111	163.220	0010	1001	0110	1000	163.385	0010	1001	1000	1001	163.550	0010	1001	1010	1010
163.060	0010	1001	0100	1000	163.225	0010	1001	0110	1001	163.390	0010	1001	1000	1010	163.555	0010	1001	1010	1011
163.065	0010	1001	0100	1001	163.230	0010	1001	0110	1010	163.395	0010	1001	1000	1011	163.560	0010	1001	1010	1100
163.070	0010	1001	0100	1010	163.235	0010	1001	0110	1011	163.400	0010	1001	1000	1100	163.565	0010	1001	1010	1101
163.075	0010	1001	0100	1011	163.240	0010	1001	0110	1100	163.405	0010	1001	1000	1101	163.570	0010	1001	1010	1110
163.080	0010	1001	0100	1100	163.245	0010	1001	0110	1101	163.410	0010	1001	1000	1110	163.575	0010	1001	1010	1111
163.085	0010	1001	0100	1101	163.250	0010	1001	0110	1110	163.415	0010	1001	1000	1111	163.580	0010	1001	1011	0000
163.090	0010	1001	0100	1110	163.255	0010	1001	0110	1111	163.420	0010	1001	1001	0000	163.585	0010	1001	1011	0001
163.095	0010	1001	0100	1111	163.260	0010	1001	0111	0000	163.425	0010	1001	1001	0001	163.590	0010	1001	1011	0010
163.100	0010	1001	0101	0000	163.265	0010	1001	0111	0001	163.430	0010	1001	1001	0010	163.595	0010	1001	1011	0011
163.105	0010	1001	0101	0001	163.270	0010	1001	0111	0010	163.435	0010	1001	1001	0011	163.600	0010	1001	1011	0100
163.110	0010	1001	0101	0010	163.275	0010	1001	0111	0011	163.440	0010	1001	1001	0100	163.605	0010	1001	1011	0101
163.115	0010	1001	0101	0011	163.280	0010	1001	0111	0100	163.445	0010	1001	1001	0101	163.610	0010	1001	1011	0110
163.120	0010	1001	0101	0100	163.285	0010	1001	0111	0101	163.450	0010	1001	1001	0110	163.615	0010	1001	1011	0111
163.125	0010	1001	0101	0101	163.290	0010	1001	0111	0110	163.455	0010	1001	1001	0111	163.620	0010	1001	1011	1000
163.130	0010	1001	0101	0110	163.295	0010	1001	0111	0111	163.460	0010	1001	1001	1000	163.625	0010	1001	1011	1001
163.135	0010	1001	0101	0111	163.300	0010	1001	0111	1000	163.465	0010	1001	1001	1001	163.630	0010	1001	1011	1010
163.140	0010	1001	0101	1000	163.305	0010	1001	0111	1001	163.470	0010	1001	1001	1010	163.635	0010	1001	1011	1011
163.145	0010	1001	0101	1001	163.310	0010	1001	0111	1010	163.475	0010	1001	1001	1011	163.640	0010	1001	1011	1100
163.150	0010	1001	0101	1010	163.315	0010	1001	0111	1011	163.480	0010	1001	1001	1100	163.645	0010	1001	1011	1101
163.155	0010	1001	0101	1011	163.320	0010	1001	0111	1100	163.485	0010	1001	1001	1101	163.650	0010	1001	1011	1110
163.160	0010	1001	0101	1100	163.325	0010	1001	0111	1101	163.490	0010	1001	1001	1110	163.655	0010	1001	1011	1111
163.165	0010	1001	0101	1101	163.330	0010	1001	0111	1110	163.495	0010	1001	1001	1111	163.660	0010	1001	1100	0000
163.170	0010	1001	0101	1110	163.335	0010	1001	0111	1111	163.500	0010	1001	1010	0000	163.665	0010	1001	1100	0001
163.175	0010	1001	0101	1111	163.340	0010	1001	1000	0000	163.505	0010	1001	1010	0001	163.670	0010	1001	1100	0010
163.180	0010	1001	0110	0000	163.345	0010	1001	1000	0001	163.510	0010	1001	1010	0010	163.675	0010	1001	1100	0011

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
163.680	0010	1001	1100	0100	163.845	0010	1001	1110	0101	164.010	0010	1010	0000	0110	164.175	0010	1010	0010	0111
163.685	0010	1001	1100	0101	163.850	0010	1001	1110	0110	164.015	0010	1010	0000	0111	164.180	0010	1010	0010	1000
163.690	0010	1001	1100	0110	163.855	0010	1001	1110	0111	164.020	0010	1010	0000	1000	164.185	0010	1010	0010	1001
163.695	0010	1001	1100	0111	163.860	0010	1001	1110	1000	164.025	0010	1010	0000	1001	164.190	0010	1010	0010	1010
163.700	0010	1001	1100	1000	163.865	0010	1001	1110	1001	164.030	0010	1010	0000	1010	164.195	0010	1010	0010	1011
163.705	0010	1001	1100	1001	163.870	0010	1001	1110	1010	164.035	0010	1010	0000	1011	164.200	0010	1010	0010	1100
163.710	0010	1001	1100	1010	163.875	0010	1001	1110	1011	164.040	0010	1010	0000	1100	164.205	0010	1010	0010	1101
163.715	0010	1001	1100	1011	163.880	0010	1001	1110	1100	164.045	0010	1010	0000	1101	164.210	0010	1010	0010	1110
163.720	0010	1001	1100	1100	163.885	0010	1001	1110	1101	164.050	0010	1010	0000	1110	164.215	0010	1010	0010	1111
163.725	0010	1001	1100	1101	163.890	0010	1001	1110	1110	164.055	0010	1010	0000	1111	164.220	0010	1010	0011	0000
163.730	0010	1001	1100	1110	163.895	0010	1001	1110	1111	164.060	0010	1010	0001	0000	164.225	0010	1010	0011	0001
163.735	0010	1001	1100	1111	163.900	0010	1001	1111	0000	164.065	0010	1010	0001	0001	164.230	0010	1010	0011	0010
163.740	0010	1001	1101	0000	163.905	0010	1001	1111	0001	164.070	0010	1010	0001	0010	164.235	0010	1010	0011	0011
163.745	0010	1001	1101	0001	163.910	0010	1001	1111	0010	164.075	0010	1010	0001	0011	164.240	0010	1010	0011	0100
163.750	0010	1001	1101	0010	163.915	0010	1001	1111	0011	164.080	0010	1010	0001	0100	164.245	0010	1010	0011	0101
163.755	0010	1001	1101	0011	163.920	0010	1001	1111	0100	164.085	0010	1010	0001	0101	164.250	0010	1010	0011	0110
163.760	0010	1001	1101	0100	163.925	0010	1001	1111	0101	164.090	0010	1010	0001	0110	164.255	0010	1010	0011	0111
163.765	0010	1001	1101	0101	163.930	0010	1001	1111	0110	164.095	0010	1010	0001	0111	164.260	0010	1010	0011	1000
163.770	0010	1001	1101	0110	163.935	0010	1001	1111	0111	164.100	0010	1010	0001	1000	164.265	0010	1010	0011	1001
163.775	0010	1001	1101	0111	163.940	0010	1001	1111	1000	164.105	0010	1010	0001	1001	164.270	0010	1010	0011	1010
163.780	0010	1001	1101	1000	163.945	0010	1001	1111	1001	164.110	0010	1010	0001	1010	164.275	0010	1010	0011	1011
163.785	0010	1001	1101	1001	163.950	0010	1001	1111	1010	164.115	0010	1010	0001	1011	164.280	0010	1010	0011	1100
163.790	0010	1001	1101	1010	163.955	0010	1001	1111	1011	164.120	0010	1010	0001	1100	164.285	0010	1010	0011	1101
163.795	0010	1001	1101	1011	163.960	0010	1001	1111	1100	164.125	0010	1010	0001	1101	164.290	0010	1010	0011	1110
163.800	0010	1001	1101	1100	163.965	0010	1001	1111	1101	164.130	0010	1010	0001	1110	164.295	0010	1010	0011	1111
163.805	0010	1001	1101	1101	163.970	0010	1001	1111	1110	164.135	0010	1010	0001	1111	164.300	0010	1010	0100	0000
163.810	0010	1001	1101	1110	163.975	0010	1001	1111	1111	164.140	0010	1010	0010	0000	164.305	0010	1010	0100	0001
163.815	0010	1001	1101	1111	163.980	0010	1010	0000	0000	164.145	0010	1010	0010	0001	164.310	0010	1010	0100	0010
163.820	0010	1001	1110	0000	163.985	0010	1010	0000	0001	164.150	0010	1010	0010	0010	164.315	0010	1010	0100	0011
163.825	0010	1001	1110	0001	163.990	0010	1010	0000	0010	164.155	0010	1010	0010	0011	164.320	0010	1010	0100	0100
163.830	0010	1001	1110	0010	163.995	0010	1010	0000	0011	164.160	0010	1010	0010	0100	164.325	0010	1010	0100	0101
163.835	0010	1001	1110	0011	164.000	0010	1010	0000	0100	164.165	0010	1010	0010	0101	164.330	0010	1010	0100	0110
163.840	0010	1001	1110	0100	164.005	0010	1010	0000	0101	164.170	0010	1010	0010	0110	164.335	0010	1010	0100	0111

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
164.340	0010	1010	0100	1000	164.505	0010	1010	0110	1001	164.670	0010	1010	1000	1010	164.835	0010	1010	1010	1011
164.345	0010	1010	0100	1001	164.510	0010	1010	0110	1010	164.675	0010	1010	1000	1011	164.840	0010	1010	1010	1100
164.350	0010	1010	0100	1010	164.515	0010	1010	0110	1011	164.680	0010	1010	1000	1100	164.845	0010	1010	1010	1101
164.355	0010	1010	0100	1011	164.520	0010	1010	0110	1100	164.685	0010	1010	1000	1101	164.850	0010	1010	1010	1110
164.360	0010	1010	0100	1100	164.525	0010	1010	0110	1101	164.690	0010	1010	1000	1110	164.855	0010	1010	1010	1111
164.365	0010	1010	0100	1101	164.530	0010	1010	0110	1110	164.695	0010	1010	1000	1111	164.860	0010	1010	1011	0000
164.370	0010	0010	0100	1110	164.535	0010	1010	0110	1111	164.700	0010	1010	1001	0000	164.865	0010	1010	1011	0001
164.375	0010	1010	0100	1111	164.540	0010	1010	0111	0000	164.705	0010	1010	1001	0001	164.870	0010	1010	1011	0010
164.380	0010	1010	0101	0000	164.545	0010	1010	0111	0001	164.710	0010	1010	1001	0010	164.875	0010	1010	1011	0011
164.385	0010	1010	0101	0001	164.550	0010	1010	0111	0010	164.715	0010	1010	1001	0011	164.880	0010	1010	1011	0100
164.390	0010	1010	0101	0010	164.555	0010	1010	0111	0011	164.720	0010	1010	1001	0100	164.885	0010	1010	1011	0101
164.395	0010	1010	0101	0011	164.560	0010	1010	0111	0100	164.725	0010	1010	1001	0101	164.890	0010	1010	1011	0110
164.400	0010	1010	0101	0100	164.565	0010	1010	0111	0101	164.730	0010	1010	1001	0110	164.895	0010	1010	1011	0111
164.405	0010	1010	0101	0101	164.570	0010	1010	0111	0110	164.735	0010	1010	1001	0111	164.900	0010	1010	1011	1000
164.410	0010	1010	0101	0110	164.575	0010	1010	0111	0111	164.740	0010	1010	1001	1000	164.905	0010	1010	1011	1001
164.415	0010	1010	0101	0111	164.580	0010	1010	0111	1000	164.745	0010	1010	1001	1001	164.910	0010	1010	1011	1010
164.420	0010	1010	0101	1000	164.585	0010	1010	0111	1001	164.750	0010	1010	1001	1010	164.915	0010	1010	1011	1011
164.425	0010	1010	0101	1001	164.590	0010	1010	0111	1010	164.755	0010	1010	1001	1011	164.920	0010	1010	1011	1100
164.430	0010	1010	0101	1010	164.595	0010	1010	0111	1011	164.760	0010	1010	1001	1100	164.925	0010	1010	1011	1101
164.435	0010	1010	0101	1011	164.600	0010	1010	0111	1100	164.765	0010	1010	1001	1101	164.930	0010	1010	1011	1110
164.440	0010	1010	0101	1100	164.605	0010	1010	0111	1101	164.770	0010	1010	1001	1110	164.935	0010	1010	1011	1111
164.445	0010	1010	0101	1101	164.610	0010	1010	0111	1110	164.775	0010	1010	1001	1111	164.940	0010	1010	1100	0000
164.450	0010	1010	0101	1110	164.615	0010	1010	0111	1111	164.780	0010	1010	1010	0000	164.945	0010	1010	1100	0001
164.455	0010	1010	0101	1111	164.620	0010	1010	1000	0000	164.785	0010	1010	1010	0001	164.950	0010	1010	1100	0010
164.460	0010	1010	0110	0000	164.625	0010	1010	1000	0001	164.790	0010	1010	1010	0010	164.955	0010	1010	1100	0011
164.465	0010	1010	0110	0001	164.630	0010	1010	1000	0010	164.795	0010	1010	1010	0011	164.960	0010	1010	1100	0100
164.470	0010	1010	0110	0010	164.635	0010	1010	1000	0011	164.800	0010	1010	1010	0100	164.965	0010	1010	1100	0101
164.475	0010	1010	0110	0011	164.640	0010	1010	1000	0100	164.805	0010	1010	1010	0101	164.970	0010	1010	1100	0110
164.480	0010	1010	0110	0100	164.645	0010	1010	1000	0101	164.810	0010	1010	1010	0110	164.975	0010	1010	1100	0111
164.485	0010	1010	0110	0101	164.650	0010	1010	1000	0110	164.815	0010	1010	1010	0111	164.980	0010	1010	1100	1000
164.490	0010	1010	0110	0110	164.655	0010	1010	1000	0111	164.820	0010	1010	1010	1000	164.985	0010	1010	1100	1001
164.495	0010	1010	0110	0111	164.660	0010	1010	1000	1000	164.825	0010	1010	1010	1001	164.990	0010	1010	1100	1010
164.500	0010	1010	0110	1000	164.665	0010	1010	1000	1001	164.830	0010	1010	1010	1010	164.995	0010	1010	1100	1011

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
165.000	0010	1010	1100	1100	165.165	0010	1010	1110	1101	165.330	0010	1011	0000	1110	165.495	0010	1011	0010	1111
165.005	0010	1010	1100	1101	165.170	0010	1010	1110	1110	165.335	0010	1011	0000	1111	165.500	0010	1011	0011	0000
165.010	0010	1010	1100	1110	165.175	0010	1010	1110	1111	165.340	0010	1011	0001	0000	165.505	0010	1011	0011	0001
165.015	0010	1010	1100	1111	165.180	0010	1010	1111	0000	165.345	0010	1011	0001	0001	165.510	0010	1011	0011	0010
165.020	0010	1010	1101	0000	165.185	0010	1010	1111	0001	165.350	0010	1011	0001	0010	165.515	0010	1011	0011	0011
165.025	0010	1010	1101	0001	165.190	0010	1010	1111	0010	165.355	0010	1011	0001	0011	165.520	0010	1011	0011	0100
165.030	0010	1010	1101	0010	165.195	0010	1010	1111	0011	165.360	0010	1011	0001	0100	165.525	0010	1011	0011	0101
165.035	0010	1010	1101	0011	165.200	0010	1010	1111	0100	165.365	0010	1011	0001	0101	165.530	0010	1011	0011	0110
165.040	0010	1010	1101	0100	165.205	0010	1010	1111	0101	165.370	0010	1011	0001	0110	165.535	0010	1011	0011	0111
165.045	0010	1010	1101	0101	165.210	0010	1010	1111	0110	165.375	0010	1011	0001	0111	165.540	0010	1011	0011	1000
165.050	0010	1010	1101	0110	165.215	0010	1010	1111	0111	165.380	0010	1011	0001	1000	165.545	0010	1011	0011	1001
165.055	0010	1010	1101	0111	165.220	0010	1010	1111	1000	165.385	0010	1011	0001	1001	165.550	0010	1011	0011	1010
165.060	0010	1010	1101	1000	165.225	0010	1010	1111	1001	165.390	0010	1011	0001	1010	165.555	0010	1011	0011	1011
165.065	0010	1010	1101	1001	165.230	0010	1010	1111	1010	165.395	0010	1011	0001	1011	165.560	0010	1011	0011	1100
165.070	0010	1010	1101	1010	165.235	0010	1010	1111	1011	165.400	0010	1011	0001	1100	165.565	0010	1011	0011	1101
165.075	0010	1010	1101	1011	165.240	0010	1010	1111	1100	165.405	0010	1011	0001	1101	165.570	0010	1011	0011	1110
165.080	0010	1010	1101	1100	165.245	0010	1010	1111	1101	165.410	0010	1011	0001	1110	165.575	0010	1011	0011	1111
165.085	0010	1010	1101	1101	165.250	0010	1010	1111	1110	165.415	0010	1011	0001	1111	165.580	0010	1011	0100	0000
165.090	0010	1010	1101	1110	165.255	0010	1010	1111	1111	165.420	0010	1011	0010	0000	165.585	0010	1011	0100	0001
165.095	0010	1010	1101	1111	165.260	0010	1011	0000	0000	165.425	0010	1011	0010	0001	165.590	0010	1011	0100	0010
165.100	0010	1010	1110	0000	165.265	0010	1011	0000	0001	165.430	0010	1011	0010	0010	165.595	0010	1011	0100	0011
165.105	0010	1010	1110	0001	165.270	0010	1011	0000	0010	165.435	0010	1011	0010	0011	165.600	0010	1011	0100	0100
165.110	0010	1010	1110	0010	165.275	0010	1011	0000	0011	165.440	0010	1011	0010	0100	165.605	0010	1011	0100	0101
165.115	0010	1010	1110	0011	165.280	0010	1011	0000	0100	165.445	0010	1011	0010	0101	165.610	0010	1011	0100	0110
165.120	0010	1010	1110	0100	165.285	0010	1011	0000	0101	165.450	0010	1011	0010	0110	165.615	0010	1011	0100	0111
165.125	0010	1010	1110	0101	165.290	0010	1011	0000	0110	165.455	0010	1011	0010	0111	165.620	0010	1011	0100	1000
165.130	0010	1010	1110	0110	165.295	0010	1011	0000	0111	165.460	0010	1011	0010	1000	165.625	0010	1011	0100	1001
165.135	0010	1010	1110	0111	165.300	0010	1011	0000	1000	165.465	0010	1011	0010	1001	165.630	0010	1011	0100	1010
165.140	0010	1010	1110	1000	165.305	0010	1011	0000	1001	165.470	0010	1011	0010	1010	165.635	0010	1011	0100	1011
165.145	0010	1010	1110	1001	165.310	0010	1011	0000	1010	165.475	0010	1011	0010	1011	165.640	0010	1011	0100	1100
165.150	0010	1010	1110	1010	165.315	0010	1011	0000	1011	165.480	0010	1011	0010	1100	165.645	0010	1011	0100	1101
165.155	0010	1010	1110	1011	165.320	0010	1011	0000	1100	165.485	0010	1011	0010	1101	165.650	0010	1011	0100	1110
165.160	0010	1010	1110	1100	165.325	0010	1011	0000	1101	165.490	0010	1011	0010	1110	165.655	0010	1011	0100	1111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
165.660	0010 1011 0101 0000	165.825	0010 1011 0111 0001	165.990	0010 1011 1001 0010	166.155	0010 1011 1011 0011
165.665	0010 1011 0101 0001	165.830	0010 1011 0111 0010	165.995	0010 1011 1001 0011	166.160	0010 1011 1011 0100
165.670	0010 1011 0101 0010	165.835	0010 1011 0111 0011	166.000	0010 1011 1001 0100	166.165	0010 1011 1011 0101
165.675	0010 1011 0101 0011	165.840	0010 1011 0111 0100	166.005	0010 1011 1001 0101	166.170	0010 1011 1011 0110
165.680	0010 1011 0101 0100	165.845	0010 1011 0111 0101	166.010	0010 1011 1001 0110	166.175	0010 1011 1011 0111
165.685	0010 1011 0101 0101	165.850	0010 1011 0111 0110	166.015	0010 1011 1001 0111	166.180	0010 1011 1011 1000
165.690	0010 1011 0101 0110	165.855	0010 1011 0111 0111	166.020	0010 1011 1001 1000	166.185	0010 1011 1011 1001
165.695	0010 1011 0101 0111	165.860	0010 1011 0111 1000	166.025	0010 1011 1001 1001	166.190	0010 1011 1011 1010
165.700	0010 1011 0101 1000	165.865	0010 1011 0111 1001	166.030	0010 1011 1001 1010	166.195	0010 1011 1011 1011
165.705	0010 1011 0101 1001	165.870	0010 1011 0111 1010	166.035	0010 1011 1001 1011	166.200	0010 1011 1011 1100
165.710	0010 1011 0101 1010	165.875	0010 1011 0111 1011	166.040	0010 1011 1001 1100	166.205	0010 1011 1011 1101
165.715	0010 1011 0101 1011	165.880	0010 1011 0111 1100	166.045	0010 1011 1001 1101	166.210	0010 1011 1011 1110
165.720	0010 1011 0101 1100	165.885	0010 1011 0111 1101	166.050	0010 1011 1001 1110	166.215	0010 1011 1011 1111
165.725	0010 1011 0101 1101	165.890	0010 1011 0111 1110	166.055	0010 1011 1001 1111	166.220	0010 1011 1100 0000
165.730	0010 1011 0101 1110	165.895	0010 1011 0111 1111	166.060	0010 1011 1010 0000	166.225	0010 1011 1100 0001
165.735	0010 1011 0101 1111	165.900	0010 1011 1000 0000	166.065	0010 1011 1010 0001	166.230	0010 1011 1100 0010
165.740	0010 1011 0110 0000	165.905	0010 1011 1000 0001	166.070	0010 1011 1010 0010	166.235	0010 1011 1100 0011
165.745	0010 1011 0110 0001	165.910	0010 1011 1000 0010	166.075	0010 1011 1010 0011	166.240	0010 1011 1100 0100
165.750	0010 1011 0110 0010	165.915	0010 1011 1000 0011	166.080	0010 1011 1010 0100	166.245	0010 1011 1100 0101
165.755	0010 1011 0110 0011	165.920	0010 1011 1000 0100	166.085	0010 1011 1010 0101	166.250	0010 1011 1100 0110
165.760	0010 1011 0110 0100	165.925	0010 1011 1000 0101	166.090	0010 1011 1010 0110	166.255	0010 1011 1100 0111
165.765	0010 1011 0110 0101	165.930	0010 1011 1000 0110	166.095	0010 1011 1010 0111	166.260	0010 1011 1100 1000
165.770	0010 1011 0110 0110	165.935	0010 1011 1000 0111	166.100	0010 1011 1010 1000	166.265	0010 1011 1100 1001
165.775	0010 1011 0110 0111	165.940	0010 1011 1000 1000	166.105	0010 1011 1010 1001	166.270	0010 1011 1100 1010
165.780	0010 1011 0110 1000	165.945	0010 1011 1000 1001	166.110	0010 1011 1010 1010	166.275	0010 1011 1100 1011
165.785	0010 1011 0110 1001	165.950	0010 1011 1000 1010	166.115	0010 1011 1010 1011	166.280	0010 1011 1100 1100
165.790	0010 1011 0110 1010	165.955	0010 1011 1000 1011	166.120	0010 1011 1010 1100	166.285	0010 1011 1100 1101
165.795	0010 1011 0110 1011	165.960	0010 1011 1000 1100	166.125	0010 1011 1010 1101	166.290	0010 1011 1100 1110
165.800	0010 1011 0110 1100	165.965	0010 1011 1000 1101	166.130	0010 1011 1010 1110	166.295	0010 1011 1100 1111
165.805	0010 1011 0110 1101	165.970	0010 1011 1000 1110	166.135	0010 1011 1010 1111	166.300	0010 1011 1101 0000
165.810	0010 1011 0110 1110	165.975	0010 1011 1000 1111	166.140	0010 1011 1011 0000	166.305	0010 1011 1101 0001
165.815	0010 1011 0110 1111	165.980	0010 1011 1001 0000	166.145	0010 1011 1011 0001	166.310	0010 1011 1101 0010
165.820	0010 1011 0111 0000	165.985	0010 1011 1001 0001	166.150	0010 1011 1011 0010	166.315	0010 1011 1101 0011

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
166.320	0010	1011	1101	0100	166.485	0010	1011	1111	0101	166.650	0010	1100	0001	0110	166.815	0010	1100	0011	0111
166.325	0010	1011	1101	0101	166.490	0010	1011	1111	0110	166.655	0010	1100	0001	0111	166.820	0010	1100	0011	1000
166.330	0010	1011	1101	0110	166.495	0010	1011	1111	0111	166.660	0010	1100	0001	1000	166.825	0010	1100	0011	1001
166.335	0010	1011	1101	0111	166.500	0010	1011	1111	1000	166.665	0010	1100	0001	1001	166.830	0010	1100	0011	1010
166.340	0010	1011	1101	1000	166.505	0010	1011	1111	1001	166.670	0010	1100	0001	1010	166.835	0010	1100	0011	1011
166.345	0010	1011	1101	1001	166.510	0010	1011	1111	1010	166.675	0010	1100	0001	1011	166.840	0010	1100	0011	1100
166.350	0010	1011	1101	1010	166.515	0010	1011	1111	1011	166.680	0010	1100	0001	1100	166.845	0010	1100	0011	1101
166.355	0010	1011	1101	1011	166.520	0010	1011	1111	1100	166.685	0010	1100	0001	1101	166.850	0010	1100	0011	1110
166.360	0010	1011	1101	1100	166.525	0010	1011	1111	1101	166.690	0010	1100	0001	1110	166.855	0010	1100	0011	1111
166.365	0010	1011	1101	1101	166.530	0010	1011	1111	1110	166.695	0010	1100	0001	1111	166.860	0010	1100	0100	0000
166.370	0010	1011	1101	1110	166.535	0010	1011	1111	1111	166.700	0010	1100	0010	0000	166.865	0010	1100	0100	0001
166.375	0010	1011	1101	1111	166.540	0010	1100	0000	0000	166.705	0010	1100	0010	0001	166.870	0010	1100	0100	0010
166.380	0010	1011	1110	0000	166.545	0010	1100	0000	0001	166.710	0010	1100	0010	0010	166.875	0010	1100	0100	0011
166.385	0010	1011	1110	0001	166.550	0010	1100	0000	0010	166.715	0010	1100	0010	0011	166.880	0010	1100	0100	0100
166.390	0010	1011	1110	0010	166.555	0010	1100	0000	0011	166.720	0010	1100	0010	0100	166.885	0010	1100	0100	0101
166.395	0010	1011	1110	0011	166.560	0010	1100	0000	0100	166.725	0010	1100	0010	0101	166.890	0010	1100	0100	0110
166.400	0010	1011	1110	0100	166.565	0010	1100	0000	0101	166.730	0010	1100	0010	0110	166.895	0010	1100	0100	0111
166.405	0010	1011	1110	0101	166.570	0010	1100	0000	0110	166.735	0010	1100	0010	0111	166.900	0010	1100	0100	1000
166.410	0010	1011	1110	0110	166.575	0010	1100	0000	0111	166.740	0010	1100	0010	1000	166.905	0010	1100	0100	1001
166.415	0010	1011	1110	0111	166.580	0010	1100	0000	1000	166.745	0010	1100	0010	1001	166.910	0010	1100	0100	1010
166.420	0010	1011	1110	1000	166.585	0010	1100	0000	1001	166.750	0010	1100	0010	1010	166.915	0010	1100	0100	1011
166.425	0010	1011	1110	1001	166.590	0010	1100	0000	1010	166.755	0010	1100	0010	1011	166.920	0010	1100	0100	1100
166.430	0010	1011	1110	1010	166.595	0010	1100	0000	1011	166.760	0010	1100	0010	1100	166.925	0010	1100	0100	1101
166.435	0010	1011	1110	1011	166.600	0010	1100	0000	1100	166.765	0010	1100	0010	1101	166.930	0010	1100	0100	1110
166.440	0010	1011	1110	1100	166.605	0010	1100	0000	1101	166.770	0010	1100	0010	1110	166.935	0010	1100	0100	1111
166.445	0010	1011	1110	1101	166.610	0010	1100	0000	1110	166.775	0010	1100	0010	1111	166.940	0010	1100	0101	0000
166.450	0010	1011	1110	1110	166.615	0010	1100	0000	1111	166.780	0010	1100	0011	0000	166.945	0010	1100	0101	0001
166.455	0010	1011	1110	1111	166.620	0010	1100	0001	0000	166.785	0010	1100	0011	0001	166.950	0010	1100	0101	0010
166.460	0010	1011	1111	0000	166.625	0010	1100	0001	0001	166.790	0010	1100	0011	0010	166.955	0010	1100	0101	0011
166.465	0010	1011	1111	0001	166.630	0010	1100	0001	0010	166.795	0010	1100	0011	0011	166.960	0010	1100	0101	0100
166.470	0010	1011	1111	0010	166.635	0010	1100	0001	0011	166.800	0010	1100	0011	0100	166.965	0010	1100	0101	0101
166.475	0010	1011	1111	0011	166.640	0010	1100	0001	0100	166.805	0010	1100	0011	0101	166.970	0010	1100	0101	0110
166.480	0010	1011	1111	0100	166.645	0010	1100	0001	0101	166.810	0010	1100	0011	0110	166.975	0010	1100	0101	0111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
166.980	0010 1100 0101 1000	167.145	0010 1100 0111 1001	167.310	0010 1100 1001 1010	167.475	0010 1100 1011 1011
166.985	0010 1100 0101 1001	167.150	0010 1100 0111 1010	167.315	0010 1100 1001 1011	167.480	0010 1100 1011 1100
166.990	0010 1100 0101 1010	167.155	0010 1100 0111 1011	167.320	0010 1100 1001 1100	167.485	0010 1100 1011 1101
166.995	0010 1100 0101 1011	167.160	0010 1100 0111 1100	167.325	0010 1100 1001 1101	167.490	0010 1100 1011 1110
167.000	0010 1100 0101 1100	167.165	0010 1100 0111 1101	167.330	0010 1100 1001 1110	167.495	0010 1100 1011 1111
167.005	0010 1100 0101 1101	167.170	0010 1100 0111 1110	167.335	0010 1100 1001 1111	167.500	0010 1100 1100 0000
167.010	0010 1100 0101 1110	167.175	0010 1100 0111 1111	167.340	0010 1100 1010 0000	167.505	0010 1100 1100 0001
167.015	0010 1100 0101 1111	167.180	0010 1100 1000 0000	167.345	0010 1100 1010 0001	167.510	0010 1100 1100 0010
167.020	0010 1100 0110 0000	167.185	0010 1100 1000 0001	167.350	0010 1100 1010 0010	167.515	0010 1100 1100 0011
167.025	0010 1100 0110 0001	167.190	0010 1100 1000 0010	167.355	0010 1100 1010 0011	167.520	0010 1100 1100 0100
167.030	0010 1100 0110 0010	167.195	0010 1100 1000 0011	167.360	0010 1100 1010 0100	167.525	0010 1100 1100 0101
167.035	0010 1100 0110 0011	167.200	0010 1100 1000 0100	167.365	0010 1100 1010 0101	167.530	0010 1100 1100 0110
167.040	0010 1100 0110 0100	167.205	0010 1100 1000 0101	167.370	0010 1100 1010 0110	167.535	0010 1100 1100 0111
167.045	0010 1100 0110 0101	167.210	0010 1100 1000 0110	167.375	0010 1100 1010 0111	167.540	0010 1100 1100 1000
167.050	0010 1100 0110 0110	167.215	0010 1100 1000 0111	167.380	0010 1100 1010 1000	167.545	0010 1100 1100 1001
167.055	0010 1100 0110 0111	167.220	0010 1100 1000 1000	167.385	0010 1100 1010 1001	167.550	0010 1100 1100 1010
167.060	0010 1100 0110 1000	167.225	0010 1100 1000 1001	167.390	0010 1100 1010 1010	167.555	0010 1100 1100 1011
167.065	0010 1100 0110 1001	167.230	0010 1100 1000 1010	167.395	0010 1100 1010 1011	167.560	0010 1100 1100 1100
167.070	0010 1100 0110 1010	167.235	0010 1100 1000 1011	167.400	0010 1100 1010 1100	167.565	0010 1100 1100 1101
167.075	0010 1100 0110 1011	167.240	0010 1100 1000 1100	167.405	0010 1100 1010 1101	167.570	0010 1100 1100 1110
167.080	0010 1100 0110 1100	167.245	0010 1100 1000 1101	167.410	0010 1100 1010 1110	167.575	0010 1100 1100 1111
167.085	0010 1100 0110 1101	167.250	0010 1100 1000 1110	167.415	0010 1100 1010 1111	167.580	0010 1100 1101 0000
167.090	0010 1100 0110 1110	167.255	0010 1100 1000 1111	167.420	0010 1100 1011 0000	167.585	0010 1100 1101 0001
167.095	0010 1100 0110 1111	167.260	0010 1100 1001 0000	167.425	0010 1100 1011 0001	167.590	0010 1100 1101 0010
167.100	0010 1100 0111 0000	167.265	0010 1100 1001 0001	167.430	0010 1100 1011 0010	167.595	0010 1100 1101 0011
167.105	0010 1100 0111 0001	167.270	0010 1100 1001 0010	167.435	0010 1100 1011 0011	167.600	0010 1100 1101 0100
167.110	0010 1100 0111 0010	167.275	0010 1100 1001 0011	167.440	0010 1100 1011 0100	167.605	0010 1100 1101 0101
167.115	0010 1100 0111 0011	167.280	0010 1100 1001 0100	167.445	0010 1100 1011 0101	167.610	0010 1100 1101 0110
167.120	0010 1100 0111 0100	167.285	0010 1100 1001 0101	167.450	0010 1100 1011 0110	167.615	0010 1100 1101 0111
167.125	0010 1100 0111 0101	167.290	0010 1100 1001 0110	167.455	0010 1100 1011 0111	167.620	0010 1100 1101 1000
167.130	0010 1100 0111 0110	167.295	0010 1100 1001 0111	167.460	0010 1100 1011 1000	167.625	0010 1100 1101 1001
167.135	0010 1100 0111 0111	167.300	0010 1100 1001 1000	167.465	0010 1100 1011 1001	167.630	0010 1100 1101 1010
167.140	0010 1100 0111 1000	167.305	0010 1100 1001 1001	167.470	0010 1100 1011 1010	167.635	0010 1100 1101 1011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
167.640	0010 1100 1101 1100	167.805	0010 1100 1111 1101	167.970	0010 1101 0001 1110	168.135	0010 1101 0011 1111
167.645	0010 1100 1101 1101	167.810	0010 1100 1111 1110	167.975	0010 1101 0001 1111	168.140	0010 1101 0100 0000
167.650	0010 1100 1101 1110	167.815	0010 1100 1111 1111	167.980	0010 1101 0010 0000	168.145	0010 1101 0100 0001
167.655	0010 1100 1101 1111	167.820	0010 1101 0000 0000	167.985	0010 1101 0010 0001	168.150	0010 1101 0100 0010
167.660	0010 1100 1110 0000	167.825	0010 1101 0000 0001	167.990	0010 1101 0010 0010	168.155	0010 1101 0100 0011
167.665	0010 1100 1110 0001	167.830	0010 1101 0000 0010	167.995	0010 1101 0010 0011	168.160	0010 1101 0100 0100
167.670	0010 1100 1110 0010	167.835	0010 1101 0000 0011	168.000	0010 1101 0010 0100	168.165	0010 1101 0100 0101
167.675	0010 1100 1110 0011	167.840	0010 1101 0000 0100	168.005	0010 1101 0010 0101	168.170	0010 1101 0100 0110
167.680	0010 1100 1110 0100	167.845	0010 1101 0000 0101	168.010	0010 1101 0010 0110	168.175	0010 1101 0100 0111
167.685	0010 1100 1110 0101	167.850	0010 1101 0000 0110	168.015	0010 1101 0010 0111	168.180	0010 1101 0100 1000
167.690	0010 1100 1110 0110	167.855	0010 1101 0000 0111	168.020	0010 1101 0010 1000	168.185	0010 1101 0100 1001
167.695	0010 1100 1110 0111	167.860	0010 1101 0000 1000	168.025	0010 1101 0010 1001	168.190	0010 1101 0100 1010
167.700	0010 1100 1110 1000	167.865	0010 1101 0000 1001	168.030	0010 1101 0010 1010	168.195	0010 1101 0100 1011
167.705	0010 1100 1110 1001	167.870	0010 1101 0000 1010	168.035	0010 1101 0010 1011	168.200	0010 1101 0100 1100
167.710	0010 1100 1110 1010	167.875	0010 1101 0000 1011	168.040	0010 1101 0010 1100	168.205	0010 1101 0100 1101
167.715	0010 1100 1110 1011	167.880	0010 1101 0000 1100	168.045	0010 1101 0010 1101	168.210	0010 1101 0100 1110
167.720	0010 1100 1110 1100	167.885	0010 1101 0000 1101	168.050	0010 1101 0010 1110	168.215	0010 1101 0100 1111
167.725	0010 1100 1110 1101	167.890	0010 1101 0000 1110	168.055	0010 1101 0010 1111	168.220	0010 1101 0101 0000
167.730	0010 1100 1110 1110	167.895	0010 1101 0000 1111	168.060	0010 1101 0011 0000	168.225	0010 1101 0101 0001
167.735	0010 1100 1110 1111	167.900	0010 1101 0001 0000	168.065	0010 1101 0011 0001	168.230	0010 1101 0101 0010
167.740	0010 1100 1111 0000	167.905	0010 1101 0001 0001	168.070	0010 1101 0011 0010	168.235	0010 1101 0101 0011
167.745	0010 1100 1111 0001	167.910	0010 1101 0001 0010	168.075	0010 1101 0011 0011	168.240	0010 1101 0101 0100
167.750	0010 1100 1111 0010	167.915	0010 1101 0001 0011	168.080	0010 1101 0011 0100	168.245	0010 1101 0101 0101
167.755	0010 1100 1111 0011	167.920	0010 1101 0001 0100	168.085	0010 1101 0011 0101	168.250	0010 1101 0101 0110
167.760	0010 1100 1111 0100	167.925	0010 1101 0001 0101	168.090	0010 1101 0011 0110	168.255	0010 1101 0101 0111
167.765	0010 1100 1111 0101	167.930	0010 1101 0001 0110	168.095	0010 1101 0011 0111	168.260	0010 1101 0101 1000
167.770	0010 1100 1111 0110	167.935	0010 1101 0001 0111	168.100	0010 1101 0011 1000	168.265	0010 1101 0101 1001
167.775	0010 1100 1111 0111	167.940	0010 1101 0001 1000	168.105	0010 1101 0011 1001	168.270	0010 1101 0101 1010
167.780	0010 1100 1111 1000	167.945	0010 1101 0001 1001	168.110	0010 1101 0011 1010	168.275	0010 1101 0101 1011
167.785	0010 1100 1111 1001	167.950	0010 1101 0001 1010	168.115	0010 1101 0011 1011	168.280	0010 1101 0101 1100
167.790	0010 1100 1111 1010	167.955	0010 1101 0001 1011	168.120	0010 1101 0011 1100	168.285	0010 1101 0101 1101
167.795	0010 1100 1111 1011	167.960	0010 1101 0001 1100	168.125	0010 1101 0011 1101	168.290	0010 1101 0101 1110
167.800	0010 1100 1111 1100	167.965	0010 1101 0001 1101	168.130	0010 1101 0011 1110	168.295	0010 1101 0101 1111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
168.300	0010 1101 0110 0000	168.465	0010 1101 1000 0001	168.630	0010 1101 1010 0010	168.795	0010 1101 1100 0011
168.305	0010 1101 0110 0001	168.470	0010 1101 1000 0010	168.635	0010 1101 1010 0011	168.800	0010 1101 1100 0100
168.310	0010 1101 0110 0010	168.475	0010 1101 1000 0011	168.640	0010 1101 1010 0100	168.805	0010 1101 1100 0101
168.315	0010 1101 0110 0011	168.480	0010 1101 1000 0100	168.645	0010 1101 1010 0101	168.810	0010 1101 1100 0110
168.320	0010 1101 0110 0100	168.485	0010 1101 1000 0101	168.650	0010 1101 1010 0110	168.815	0010 1101 1100 0111
168.325	0010 1101 0110 0101	168.490	0010 1101 1000 0110	168.655	0010 1101 1010 0111	168.820	0010 1101 1100 1000
168.330	0010 1101 0110 0110	168.495	0010 1101 1000 0111	168.660	0010 1101 1010 1000	168.825	0010 1101 1100 1001
168.335	0010 1101 0110 0111	168.500	0010 1101 1000 1000	168.665	0010 1101 1010 1001	168.830	0010 1101 1100 1010
168.340	0010 1101 0110 1000	168.505	0010 1101 1000 1001	168.670	0010 1101 1010 1010	168.835	0010 1101 1100 1011
168.345	0010 1101 0110 1001	168.510	0010 1101 1000 1010	168.675	0010 1101 1010 1011	168.840	0010 1101 1100 1100
168.350	0010 1101 0110 1010	168.515	0010 1101 1000 1011	168.680	0010 1101 1010 1100	168.845	0010 1101 1100 1101
168.355	0010 1101 0110 1011	168.520	0010 1101 1000 1100	168.685	0010 1101 1010 1101	168.850	0010 1101 1100 1110
168.360	0010 1101 0110 1100	168.525	0010 1101 1000 1101	168.690	0010 1101 1010 1110	168.855	0010 1101 1100 1111
168.365	0010 1101 0110 1101	168.530	0010 1101 1000 1110	168.695	0010 1101 1010 1111	168.860	0010 1101 1101 0000
168.370	0010 1101 0110 1110	168.535	0010 1101 1000 1111	168.700	0010 1101 1011 0000	168.865	0010 1101 1101 0001
168.375	0010 1101 0110 1111	168.540	0010 1101 1001 0000	168.705	0010 1101 1011 0001	168.870	0010 1101 1101 0010
168.380	0010 1101 0111 0000	168.545	0010 1101 1001 0001	168.710	0010 1101 1011 0010	168.875	0010 1101 1101 0011
168.385	0010 1101 0111 0001	168.550	0010 1101 1001 0010	168.715	0010 1101 1011 0011	168.880	0010 1101 1101 0100
168.390	0010 1101 0111 0010	168.555	0010 1101 1001 0011	168.720	0010 1101 1011 0100	168.885	0010 1101 1101 0101
168.395	0010 1101 0111 0011	168.560	0010 1101 1001 0100	168.725	0010 1101 1011 0101	168.890	0010 1101 1101 0110
168.400	0010 1101 0111 0100	168.565	0010 1101 1001 0101	168.730	0010 1101 1011 0110	168.895	0010 1101 1101 0111
168.405	0010 1101 0111 0101	168.570	0010 1101 1001 0110	168.735	0010 1101 1011 0111	168.900	0010 1101 1101 1000
168.410	0010 1101 0111 0110	168.575	0010 1101 1001 0111	168.740	0010 1101 1011 1000	168.905	0010 1101 1101 1001
168.415	0010 1101 0111 0111	168.580	0010 1101 1001 1000	168.745	0010 1101 1011 1001	168.910	0010 1101 1101 1010
168.420	0010 1101 0111 1000	168.585	0010 1101 1001 1001	168.750	0010 1101 1011 1010	168.915	0010 1101 1101 1011
168.425	0010 1101 0111 1001	168.590	0010 1101 1001 1010	168.755	0010 1101 1011 1011	168.920	0010 1101 1101 1100
168.430	0010 1101 0111 1010	168.595	0010 1101 1001 1011	168.760	0010 1101 1011 1100	168.925	0010 1101 1101 1101
168.435	0010 1101 0111 1011	168.600	0010 1101 1001 1100	168.765	0010 1101 1011 1101	168.930	0010 1101 1101 1110
168.440	0010 1101 0111 1100	168.605	0010 1101 1001 1101	168.770	0010 1101 1011 1110	168.935	0010 1101 1101 1111
168.445	0010 1101 0111 1101	168.610	0010 1101 1001 1110	168.775	0010 1101 1011 1111	168.940	0010 1101 1110 0000
168.450	0010 1101 0111 1110	168.615	0010 1101 1001 1111	168.780	0010 1101 1100 0000	168.945	0010 1101 1110 0001
168.455	0010 1101 0111 1111	168.620	0010 1101 1010 0000	168.785	0010 1101 1100 0001	168.950	0010 1101 1110 0010
168.460	0010 1101 1000 0000	168.625	0010 1101 1010 0001	168.790	0010 1101 1100 0010	168.955	0010 1101 1110 0011

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
168.960	0010 1101 1110 0100	169.125	0010 1110 0000 0101	169.290	0010 1110 0010 0110	169.455	0010 1110 0100 0111
168.965	0010 1101 1110 0101	169.130	0010 1110 0000 0110	169.295	0010 1110 0010 0111	169.460	0010 1110 0100 1000
168.970	0010 1101 1110 0110	169.135	0010 1110 0000 0111	169.300	0010 1110 0010 1000	169.465	0010 1110 0100 1001
168.975	0010 1101 1110 0111	169.140	0010 1110 0000 1000	169.305	0010 1110 0010 1001	169.470	0010 1110 0100 1010
168.980	0010 1101 1110 1000	169.145	0010 1110 0000 1001	169.310	0010 1110 0010 1010	169.475	0010 1110 0100 1011
168.985	0010 1101 1110 1001	169.150	0010 1110 0000 1010	169.315	0010 1110 0010 1011	169.480	0010 1110 0100 1100
168.990	0010 1101 1110 1010	169.155	0010 1110 0000 1011	169.320	0010 1110 0010 1100	169.485	0010 1110 0100 1101
168.995	0010 1101 1110 1011	169.160	0010 1110 0000 1100	169.325	0010 1110 0010 1101	169.490	0010 1110 0100 1110
169.000	0010 1101 1110 1100	169.165	0010 1110 0000 1101	169.330	0010 1110 0010 1110	169.495	0010 1110 0100 1111
169.005	0010 1101 1110 1101	169.170	0010 1110 0000 1110	169.335	0010 1110 0010 1111	169.500	0010 1110 0101 0000
169.010	0010 1101 1110 1110	169.175	0010 1110 0000 1111	169.340	0010 1110 0011 0000	169.505	0010 1110 0101 0001
169.015	0010 1101 1110 1111	169.180	0010 1110 0001 0000	169.345	0010 1110 0011 0001	169.510	0010 1110 0101 0010
169.020	0010 1101 1111 0000	169.185	0010 1110 0001 0001	169.350	0010 1110 0011 0010	169.515	0010 1110 0101 0011
169.025	0010 1101 1111 0001	169.190	0010 1110 0001 0010	169.355	0010 1110 0011 0011	169.520	0010 1110 0101 0100
169.030	0010 1101 1111 0010	169.195	0010 1110 0001 0011	169.360	0010 1110 0011 0100	169.525	0010 1110 0101 0101
169.035	0010 1101 1111 0011	169.200	0010 1110 0001 0100	169.365	0010 1110 0011 0101	169.530	0010 1110 0101 0110
169.040	0010 1101 1111 0100	169.205	0010 1110 0001 0101	169.370	0010 1110 0011 0110	169.535	0010 1110 0101 0111
169.045	0010 1101 1111 0101	169.210	0010 1110 0001 0110	169.375	0010 1110 0011 0111	169.540	0010 1110 0101 1000
169.050	0010 1101 1111 0110	169.215	0010 1110 0001 0111	169.380	0010 1110 0011 1000	169.545	0010 1110 0101 1001
169.055	0010 1101 1111 0111	169.220	0010 1110 0001 1000	169.385	0010 1110 0011 1001	169.550	0010 1110 0101 1010
169.060	0010 1101 1111 1000	169.225	0010 1110 0001 1001	169.390	0010 1110 0011 1010	169.555	0010 1110 0101 1011
169.065	0010 1101 1111 1001	169.230	0010 1110 0001 1010	169.395	0010 1110 0011 1011	169.560	0010 1110 0101 1100
169.070	0010 1101 1111 1010	169.235	0010 1110 0001 1011	169.400	0010 1110 0011 1100	169.565	0010 1110 0101 1101
169.075	0010 1101 1111 1011	169.240	0010 1110 0001 1100	169.405	0010 1110 0011 1101	169.570	0010 1110 0101 1110
169.080	0010 1101 1111 1100	169.245	0010 1110 0001 1101	169.410	0010 1110 0011 1110	169.575	0010 1110 0101 1111
169.085	0010 1101 1111 1101	169.250	0010 1110 0001 1110	169.415	0010 1110 0011 1111	169.580	0010 1110 0110 0000
169.090	0010 1101 1111 1110	169.255	0010 1110 0001 1111	169.420	0010 1110 0100 0000	169.585	0010 1110 0110 0001
169.095	0010 1101 1111 1111	169.260	0010 1110 0010 0000	169.425	0010 1110 0100 0001	169.590	0010 1110 0110 0010
169.100	0010 1110 0000 0000	169.265	0010 1110 0010 0001	169.430	0010 1110 0100 0010	169.595	0010 1110 0110 0011
169.105	0010 1110 0000 0001	169.270	0010 1110 0010 0010	169.435	0010 1110 0100 0011	169.600	0010 1110 0110 0100
169.110	0010 1110 0000 0010	169.275	0010 1110 0010 0011	169.440	0010 1110 0100 0100	169.605	0010 1110 0110 0101
169.115	0010 1110 0000 0011	169.280	0010 1110 0010 0100	169.445	0010 1110 0100 0101	169.610	0010 1110 0110 0110
169.120	0010 1110 0000 0100	169.285	0010 1110 0010 0101	169.450	0010 1110 0100 0110	169.615	0010 1110 0110 0111

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
169.620	0010 1110 0110 1000	169.720	0010 1110 0111 1100	169.820	0010 1110 1001 0000	169.920	0010 1110 1010 0100
169.625	0010 1110 0110 1001	169.725	0010 1110 0111 1101	169.825	0010 1110 1001 0001	169.925	0010 1110 1010 0101
169.630	0010 1110 0110 1010	169.730	0010 1110 0111 1110	169.830	0010 1110 1001 0010	169.930	0010 1110 1010 0110
169.635	0010 1110 0110 1011	169.735	0010 1110 0111 1111	169.835	0010 1110 1001 0011	169.935	0010 1110 1010 0111
169.640	0010 1110 0110 1100	169.740	0010 1110 1000 0000	169.840	0010 1110 1001 0100	169.940	0010 1110 1010 1000
169.645	0010 1110 0110 1101	169.745	0010 1110 1000 0001	169.845	0010 1110 1001 0101	169.945	0010 1110 1010 1001
169.650	0010 1110 0110 1110	169.750	0010 1110 1000 0010	169.850	0010 1110 1001 0110	169.950	0010 1110 1010 1010
169.655	0010 1110 0110 1111	169.755	0010 1110 1000 0011	169.855	0010 1110 1001 0111	169.955	0010 1110 1010 1011
169.660	0010 1110 0111 0000	169.760	0010 1110 1000 0100	169.860	0010 1110 1001 1000	169.960	0010 1110 1010 1100
169.665	0010 1110 0111 0001	169.765	0010 1110 1000 0101	169.865	0010 1110 1001 1001	169.965	0010 1110 1010 1101
169.670	0010 1110 0111 0010	169.770	0010 1110 1000 0110	169.870	0010 1110 1001 1010	169.970	0010 1110 1010 1110
169.675	0010 1110 0111 0011	169.775	0010 1110 1000 0111	169.875	0010 1110 1001 1011	169.975	0010 1110 1010 1111
169.680	0010 1110 0111 0100	169.780	0010 1110 1000 1000	169.880	0010 1110 1001 1100	169.980	0010 1110 1011 0000
169.685	0010 1110 0111 0101	169.785	0010 1110 1000 1001	169.885	0010 1110 1001 1101	169.985	0010 1110 1011 0001
169.690	0010 1110 0111 0110	169.790	0010 1110 1000 1010	169.890	0010 1110 1001 1110	169.990	0010 1110 1011 0010
169.695	0010 1110 0111 0111	169.795	0010 1110 1000 1011	169.895	0010 1110 1001 1111	169.995	0010 1110 1011 0011
169.700	0010 1110 0111 1000	169.800	0010 1110 1000 1100	169.900	0010 1110 1010 0000	170.000	0010 1110 1011 0100
169.705	0010 1110 0111 1001	169.805	0010 1110 1000 1101	169.905	0010 1110 1010 0001		
169.710	0010 1110 0111 1010	169.810	0010 1110 1000 1110	169.910	0010 1110 1010 0010		
169.715	0010 1110 0111 1011	169.815	0010 1110 1000 1111	169.915	0010 1110 1010 0011		

UHF BAND 451.200 to 470.000 MHz

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
451.200	0001 0000 0000 0100	451.950	0001 0000 1001 1010	452.750	0001 0001 0011 1010	453.550	0001 0001 1101 1010
451.225	0001 0000 0000 1001	451.975	0001 0000 1001 1111	452.775	0001 0001 0011 1111	453.575	0001 0001 1101 1111
451.250	0001 0000 0000 1110	452.000	0001 0000 1010 0100	452.800	0001 0001 0100 0100	453.600	0001 0001 1110 0100
451.275	0001 0000 0001 0011	452.025	0001 0000 1010 1001	452.825	0001 0001 0100 1001	453.625	0001 0001 1110 1001
451.300	0001 0000 0001 1000	452.050	0001 0000 1010 1110	452.850	0001 0001 0100 1110	453.650	0001 0001 1110 1110
451.325	0001 0000 0001 1101	452.075	0001 0000 1011 0011	452.875	0001 0001 0101 0011	453.675	0001 0001 1111 0011
451.350	0001 0000 0010 0010	452.100	0001 0000 1011 1000	452.900	0001 0001 0101 1000	453.700	0001 0001 1111 1000
451.375	0001 0000 0010 0111	452.125	0001 0000 1011 1101	452.925	0001 0001 0101 1101	453.725	0001 0001 1111 1101
451.400	0001 0000 0010 1100	452.150	0001 0000 1100 0010	452.950	0001 0001 0110 0010	453.750	0001 0010 0000 0010
451.425	0001 0000 0011 0001	452.175	0001 0000 1100 0111	452.975	0001 0001 0110 0111	453.775	0001 0010 0000 0111
451.450	0001 0000 0011 0110	452.200	0001 0000 1100 1100	453.000	0001 0001 0110 1100	453.800	0001 0010 0000 1100
451.475	0001 0000 0011 1011	452.225	0001 0000 1101 0001	453.025	0001 0001 0111 0001	453.825	0001 0010 0001 0001
451.500	0001 0000 0100 0000	452.250	0001 0000 1101 0110	453.050	0001 0001 0111 0110	453.850	0001 0010 0001 0110
451.525	0001 0000 0100 0101	452.275	0001 0000 1101 1011	453.075	0001 0001 0111 1011	453.875	0001 0010 0001 1011
451.550	0001 0000 0100 1010	452.300	0001 0000 1110 0000	453.100	0001 0001 1000 0000	453.900	0001 0010 0010 0000
451.575	0001 0000 0100 1111	452.325	0001 0000 1110 0101	453.125	0001 0001 1000 0101	453.925	0001 0010 0010 0101
451.600	0001 0000 0101 0100	452.350	0001 0000 1110 1010	453.150	0001 0001 1000 1010	453.950	0001 0010 0010 1010
451.625	0001 0000 0101 1001	452.375	0001 0000 1110 1111	453.175	0001 0001 1000 1111	453.975	0001 0010 0010 1111
451.650	0001 0000 0101 1110	452.400	0001 0000 1111 0100	453.200	0001 0001 1001 0100	454.000	0001 0010 0011 0100
451.675	0001 0000 0110 0011	452.425	0001 0000 1111 1001	453.225	0001 1001 1001 1001	454.025	0001 0010 0011 1001
451.700	0001 0000 0110 1000	452.450	0001 0000 1111 1110	453.250	0001 0001 1001 1110	454.050	0001 0010 0011 1110
451.725	0001 0000 0110 1101	452.475	0001 0001 0000 0011	453.275	0001 0001 1010 0011	454.075	0001 0010 0100 0011
451.750	0001 0000 0111 0010	452.500	0001 0001 0000 1000	453.300	0001 0001 1010 1000	454.100	0001 0010 0100 1000
451.775	0001 0000 0111 1011	452.525	0001 0001 0000 1101	453.325	0001 0001 1010 1101	454.125	0001 0010 0100 1101
451.800	0001 0000 0111 1100	452.550	0001 0001 0001 0010	453.350	0001 0001 1011 0010	454.150	0001 0010 0101 0010
451.825	0001 0000 1000 0001	452.575	0001 0001 0001 0111	453.375	0001 0001 1011 0111	454.175	0001 0010 0101 0111
451.850	0001 0000 1000 0110	452.600	0001 0001 0001 1100	453.400	0001 0001 1011 1100	454.200	0001 0010 0101 1100
451.875	0001 0000 1000 1011	452.625	0001 0001 0010 0001	453.425	0001 0001 1100 0001	454.225	0001 0010 0110 0001
451.900	0001 0000 1001 0000	452.650	0001 0001 0010 0110	453.450	0001 0001 1100 0110	454.250	0001 0010 0110 0110
451.925	0001 0000 1001 0101	452.675	0001 0001 0010 1011	453.475	0001 0001 1100 1011	454.275	0001 0010 0110 1011
		452.700	0001 0001 0011 0000	453.500	0001 0001 1101 0000	454.300	0001 0010 0111 0000
		452.725	0001 0001 0011 0101	453.525	0001 0001 1101 0101	454.325	0001 0010 0111 0101

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
454.350	0001 0010 0111 1010	455.175	0001 0011 0001 1111	456.000	0001 0011 1100 0100	456.825	0001 0100 0110 1001
454.375	0001 0010 0111 1111	455.200	0001 0011 0010 0100	456.025	0001 0011 1100 1001	456.850	0001 0100 0110 1110
454.400	0001 0010 1000 0100	455.225	0001 0011 0010 1001	456.050	0001 0011 1100 1110	456.875	0001 0100 0111 0011
454.425	0001 0010 1000 1001	455.250	0001 0011 0010 1110	456.075	0001 0011 1101 0011	456.900	0001 0100 0111 1000
454.450	0001 0010 1000 1110	455.275	0001 0011 0011 0011	456.100	0001 0011 1101 1000	456.925	0001 0100 0111 1101
454.475	0001 0010 1001 0011	455.300	0001 0011 0011 1000	456.125	0001 0011 1101 1101	456.950	0001 0100 1000 0010
454.500	0001 0010 1001 1000	455.325	0001 0011 0011 1101	456.150	0001 0011 1110 0010	456.975	0001 0100 1000 0111
454.525	0001 0010 1001 1101	455.350	0001 0011 0100 0010	456.175	0001 0011 1110 0111	457.000	0001 0100 1000 1100
454.550	0001 0010 1010 0010	455.375	0001 0011 0100 0111	456.200	0001 0011 1110 1100	457.025	0001 0100 1001 0001
454.575	0001 0010 1010 0111	455.400	0001 0011 0100 1100	456.225	0001 0011 1111 0001	457.050	0001 0100 1001 0110
454.600	0001 0010 1010 1100	455.425	0001 0011 0101 0001	456.250	0001 0011 1111 0110	457.075	0001 0100 1001 1011
454.625	0001 0010 1011 0001	455.450	0001 0011 0101 0110	456.275	0001 0011 1111 1011	457.100	0001 0100 1010 0000
454.650	0001 0010 1011 0110	455.475	0001 0011 0101 1011	456.300	0001 0100 0000 0000	457.125	0001 0100 1010 0101
454.675	0001 0010 1011 1011	455.500	0001 0011 0110 0000	456.325	0001 0100 0000 0101	457.150	0001 0100 1010 1010
454.700	0001 0010 1100 0000	455.525	0001 0011 0110 0101	456.350	0001 0100 0000 1010	457.175	0001 0100 1010 1111
454.725	0001 0010 1100 0101	455.550	0001 0011 0110 1010	456.375	0001 0100 0000 1111	457.200	0001 0100 1011 0100
454.750	0001 0010 1100 1010	455.575	0001 0011 0110 1111	456.400	0001 0100 0001 0100	457.225	0001 0100 1011 1001
454.775	0001 0010 1100 1111	455.600	0001 0011 0111 0100	456.425	0001 0100 0001 1001	457.250	0001 0100 1011 1110
454.800	0001 0010 1101 0100	455.625	0001 0011 0111 1001	456.450	0001 0100 0001 1110	457.275	0001 0100 1100 0011
454.825	0001 0010 1101 1001	455.650	0001 0011 0111 1110	456.475	0001 0100 0010 0011	457.300	0001 0100 1100 1000
454.850	0001 0010 1101 1110	455.675	0001 0011 1000 0011	456.500	0001 0100 0010 1000	457.325	0001 0100 1100 1101
454.875	0001 0010 1110 0011	455.700	0001 0011 1000 1000	456.525	0001 0100 0010 1101	457.350	0001 0100 1101 0010
454.900	0001 0010 1110 1000	455.725	0001 0011 1000 1101	456.550	0001 0100 0011 0010	457.375	0001 0100 1101 0111
454.925	0001 0010 1110 1101	455.750	0001 0011 1001 0010	456.575	0001 0100 0011 0111	457.400	0001 0100 1101 1100
454.950	0001 0010 1111 0010	455.775	0001 0011 1001 0111	456.600	0001 0100 0011 1100	457.425	0001 0100 1110 0001
454.975	0001 0010 1111 0111	455.800	0001 0011 1001 1100	456.625	0001 0100 0100 0001	457.450	0001 0100 1110 0110
455.000	0001 0010 1111 1100	455.825	0001 0011 1010 0001	456.650	0001 0100 0100 0110	457.475	0001 0100 1110 1011
455.025	0001 0011 0000 0001	455.850	0001 0011 1010 0110	456.675	0001 0100 0100 1011	457.500	0001 0100 1111 0000
455.050	0001 0011 0000 0110	455.875	0001 0011 1010 1011	456.700	0001 0100 0101 0000	457.525	0001 0100 1111 0101
455.075	0001 0011 0000 1011	455.900	0001 0011 1011 0000	456.725	0001 0100 0101 0101	457.550	0001 0100 1111 1010
455.100	0001 0011 0001 0000	455.925	0001 0011 1011 0101	456.750	0001 0100 0101 1010	457.575	0001 0100 1111 1111
455.125	0001 0011 0001 0101	455.950	0001 0011 1011 1010	456.775	0001 0100 0101 1111	457.600	0001 0101 0000 0100
455.150	0001 0011 0001 1010	455.975	0001 0011 1011 1111	456.800	0001 0100 0110 0100	457.625	0001 0101 0000 1001

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
457.650	0001 0101 0000 1110	458.475	0001 0101 1011 0011	459.300	0001 0110 0101 1000	460.125	0001 0110 1111 1101
457.675	0001 0101 0001 0011	458.500	0001 0101 1011 1000	459.325	0001 0110 0101 1101	460.150	0001 0111 0000 0010
457.700	0001 0101 0001 1000	458.525	0001 0101 1011 1101	459.350	0001 0110 0110 0010	460.175	0001 0111 0000 0111
457.725	0001 0101 0001 1101	458.550	0001 0101 1100 0010	459.375	0001 0110 0110 0111	460.200	0001 0111 0000 1100
457.750	0001 0101 0010 0010	458.575	0001 0101 1100 0111	459.400	0001 0110 0110 1100	460.225	0001 0111 0001 0001
457.775	0001 0101 0010 0111	458.600	0001 0101 1100 1100	459.425	0001 0110 0111 0001	460.250	0001 0111 0001 0110
457.800	0001 0101 0010 1100	458.625	0001 0101 1101 0001	459.450	0001 0110 0111 0110	460.275	0001 0111 0001 1011
457.825	0001 0101 0011 0001	458.650	0001 0101 1101 0110	459.475	0001 0110 0111 1011	460.300	0001 0111 0010 0000
457.850	0001 0101 0011 0110	458.675	0001 0101 1101 1011	459.500	0001 0110 1000 0000	460.325	0001 0111 0010 0101
457.875	0001 0101 0011 1011	458.700	0001 0101 1110 0000	459.525	0001 0110 1000 0101	460.350	0001 0111 0010 1010
457.900	0001 0101 0100 0000	458.725	0001 0101 1110 0101	459.550	0001 0110 1000 1010	460.375	0001 0111 0010 1111
457.925	0001 0101 0100 0101	458.750	0001 0101 1110 1010	459.575	0001 0110 1000 1111	460.400	0001 0111 0011 0100
457.950	0001 0101 0100 1010	458.775	0001 0101 1110 1111	459.600	0001 0110 1001 0100	460.425	0001 0111 0011 1001
457.975	0001 0101 0100 1111	458.800	0001 0101 1111 0100	459.625	0001 0110 1001 1001	460.450	0001 0111 0011 1110
458.000	0001 0101 0101 0100	458.825	0001 0101 1111 1001	459.650	0001 0110 1001 1110	460.475	0001 0111 0100 0011
458.025	0001 0101 0101 1001	458.850	0001 0101 1111 1110	459.675	0001 0110 1010 0011	460.500	0001 0111 0100 1000
458.050	0001 0101 0101 1110	458.875	0001 0110 0000 0011	459.700	0001 0110 1010 1000	460.525	0001 0111 0100 1101
458.075	0001 0101 0110 0011	458.900	0001 0110 0000 1000	459.725	0001 0110 1010 1101	460.550	0001 0111 0101 0010
458.100	0001 0101 0110 1000	458.925	0001 0110 0000 1101	459.750	0001 0110 1011 0010	460.575	0001 0111 0101 0111
458.125	0001 0101 0110 1101	458.950	0001 0110 0001 0010	459.775	0001 0110 1011 0111	460.600	0001 0111 0101 1100
458.150	0001 0101 0111 0010	458.975	0001 0110 0001 0111	459.800	0001 0110 1011 1100	460.625	0001 0111 0110 0001
458.175	0001 0101 0111 0111	459.000	0001 0110 0001 1100	459.825	0001 0110 1100 0001	460.650	0001 0111 0110 0110
458.200	0001 0101 0111 1100	459.025	0001 0110 0010 0001	459.850	0001 0110 1100 0110	460.675	0001 0111 0110 1011
458.225	0001 0101 1000 0001	459.050	0001 0110 0010 0110	459.875	0001 0110 1100 1011	460.700	0001 0111 0111 0000
458.250	0001 0101 1000 0110	459.075	0001 0110 0010 1011	459.900	0001 0110 1101 0000	460.725	0001 0111 0111 0101
458.275	0001 0101 1000 1011	459.100	0001 0110 0011 0000	459.925	0001 0110 1101 0101	460.750	0001 0111 0111 1010
458.300	0001 0101 1001 0000	459.125	0001 0110 0011 0101	459.950	0001 0110 1101 1010	460.775	0001 0111 0111 1111
458.325	0001 0101 1001 0101	459.150	0001 0110 0011 1010	459.975	0001 0110 1101 1111	460.800	0001 0111 1000 0100
458.350	0001 0101 1001 1010	459.175	0001 0110 0011 1111	460.000	0001 0110 1110 0100	460.825	0001 0111 1000 1001
458.375	0001 0101 1001 1111	459.200	0001 0110 0100 0100	460.025	0001 0110 1110 1001	460.850	0001 0111 1000 1110
458.400	0001 0101 1010 0100	459.225	0001 0110 0100 1001	460.050	0001 0110 1110 1110	460.875	0001 0111 1001 0011
458.425	0001 0101 1010 1001	459.250	0001 0110 0100 1110	460.075	0001 0110 1111 0011	460.900	0001 0111 1001 1000
458.450	0001 0101 1010 1110	459.275	0001 0110 0101 0011	460.100	0001 0110 1111 1000	460.925	0001 0111 1001 1101

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
460.950	0001 0111 1010 0010	461.775	0001 1000 0100 0111	462.600	0001 1000 1110 1100	463.425	0001 1001 1001 0001
460.975	0001 0111 1010 0111	461.800	0001 1000 0100 1100	462.625	0001 1000 1111 0001	463.450	0001 1001 1001 0110
461.000	0001 0111 1010 1100	461.825	0001 1000 0101 0001	462.650	0001 1000 1111 0110	463.475	0001 1001 1001 1011
461.025	0001 0111 1011 0001	461.850	0001 1000 0101 0110	462.675	0001 1000 1111 1011	463.500	0001 1001 1010 0000
461.050	0001 0111 1011 0110	461.875	0001 1000 0101 1011	462.700	0001 1001 0000 0000	463.525	0001 1001 1010 0101
461.075	0001 0111 1011 1011	461.900	0001 1000 0110 0000	462.725	0001 1001 0000 0101	463.550	0001 1001 1010 1010
461.100	0001 0111 1100 0000	461.925	0001 1000 0110 0101	462.750	0001 1001 0000 1010	463.575	0001 1001 1010 1111
461.125	0001 0111 1100 0101	461.950	0001 1000 0110 1010	462.775	0001 1001 0000 1111	463.600	0001 1001 1011 0100
461.150	0001 0111 1100 1010	461.975	0001 1000 0110 1111	462.800	0001 1001 0001 0100	463.625	0001 1001 1011 1001
461.175	0001 0111 1100 1111	462.000	0001 1000 0111 0100	462.825	0001 1001 0001 1001	463.650	0001 1001 1011 1110
461.200	0001 0111 1101 0100	462.025	0001 1000 0111 1001	462.850	0001 1001 0001 1110	463.675	0001 1001 1100 0011
461.225	0001 0111 1101 1001	462.050	0001 1000 0111 1110	462.875	0001 1001 0010 0011	463.700	0001 1001 1100 1000
461.250	0001 0111 1101 1110	462.075	0001 1000 1000 0011	462.900	0001 1001 0010 1000	463.725	0001 1001 1100 1101
461.275	0001 0111 1110 0011	462.100	0001 1000 1000 1000	462.925	0001 1001 0010 1101	463.750	0001 1001 1101 0010
461.300	0001 0111 1110 1000	462.125	0001 1000 1000 1101	462.950	0001 1001 0011 0010	463.775	0001 1001 1101 0111
461.325	0001 0111 1110 1101	462.150	0001 1000 1001 0010	462.975	0001 1001 0011 0111	463.800	0001 1001 1101 1100
461.350	0001 0111 1111 0010	462.175	0001 1000 1001 0111	463.000	0001 1001 0011 1100	463.825	0001 1001 1110 0001
461.375	0001 0111 1111 0111	462.200	0001 1000 1001 1100	463.025	0001 1001 0100 0001	463.850	0001 1001 1110 0110
461.400	0001 0111 1111 1100	462.225	0001 1000 1010 0001	463.050	0001 1001 0100 0110	463.875	0001 1001 1110 1011
461.425	0001 1000 0000 0001	462.250	0001 1000 1010 0110	463.075	0001 1001 0100 1011	463.900	0001 1001 1111 0000
461.450	0001 1000 0000 0110	462.275	0001 1000 1010 1011	463.100	0001 1001 0101 0000	463.925	0001 1001 1111 0101
461.475	0001 1000 0000 1011	462.300	0001 1000 1011 0000	463.125	0001 1001 0101 0101	463.950	0001 1001 1111 1010
461.500	0001 1000 0001 0000	462.325	0001 1000 1011 0101	463.150	0001 1001 0101 1010	463.975	0001 1001 1111 1111
461.525	0001 1000 0001 0101	462.350	0001 1000 1011 1010	463.175	0001 1001 0101 1111	464.000	0001 1010 0000 0100
461.550	0001 1000 0001 1010	462.375	0001 1000 1011 1111	463.200	0001 1001 0110 0100	464.025	0001 1010 0000 1001
461.575	0001 1000 0001 1111	462.400	0001 1000 1100 0100	463.225	0001 1001 0110 1001	464.050	0001 1010 0000 1110
461.600	0001 1000 0010 0100	462.425	0001 1000 1100 1001	463.250	0001 1001 0110 1110	464.075	0001 1010 0001 0011
461.625	0001 1000 0010 1001	462.450	0001 1000 1100 1110	463.275	0001 1001 0111 0011	464.100	0001 1010 0001 1000
461.650	0001 1000 0010 1110	462.475	0001 1000 1101 0011	463.300	0001 1001 0111 1000	464.125	0001 1010 0001 1101
461.675	0001 1000 0011 0011	462.500	0001 1000 1101 1000	463.325	0001 1001 0111 1101	464.150	0001 1010 0010 0010
461.700	0001 1000 0011 1000	462.525	0001 1000 1101 1101	463.350	0001 1001 1000 0010	464.175	0001 1010 0010 0111
461.725	0001 1000 0011 1101	462.550	0001 1000 1110 0010	463.375	0001 1001 1000 0111	464.200	0001 1010 0010 1100
461.750	0001 1000 0100 0010	462.575	0001 1000 1110 0111	463.400	0001 1001 1000 1100	464.225	0001 1010 0011 0001

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
464.250	0001 1010 0011 0110	465.075	0001 1010 1101 1011	465.900	0001 1011 1000 0000	466.725	0001 1100 0010 0101
464.275	0001 1010 0011 1011	465.100	0001 1010 1110 0000	465.925	0001 1011 1000 0101	466.750	0001 1100 0010 1010
464.300	0001 1010 0100 0000	465.125	0001 1010 1110 0101	465.950	0001 1011 1000 1010	466.775	0001 1100 0010 1111
464.325	0001 1010 0100 0101	465.150	0001 1010 1110 1010	465.975	0001 1011 1000 1111	466.800	0001 1100 0011 0100
464.350	0001 1010 0100 1010	465.175	0001 1010 1110 1111	466.000	0001 1011 1001 0100	466.825	0001 1100 0011 1001
464.375	0001 1010 0100 1111	465.200	0001 1010 1111 0100	466.025	0001 1011 1001 1001	466.850	0001 1100 0011 1110
464.400	0001 1010 0101 0100	465.225	0001 1010 1111 1001	466.050	0001 1011 1001 1110	466.875	0001 1100 0100 0011
464.425	0001 1010 0101 1001	465.250	0001 1010 1111 1110	466.075	0001 1011 1010 0011	466.900	0001 1100 0100 1000
464.450	0001 1010 0101 1110	465.275	0001 1011 0000 0011	466.100	0001 1011 1010 1000	466.925	0001 1100 0100 1101
464.475	0001 1010 0110 0011	465.300	0001 1011 0000 1000	466.125	0001 1011 1010 1101	466.950	0001 1100 0101 0010
464.500	0001 1010 0110 1000	465.325	0001 1011 0000 1101	466.150	0001 1011 1011 0010	466.975	0001 1100 0101 0111
464.525	0001 1010 0110 1101	465.350	0001 1011 0001 0010	466.175	0001 1011 1011 0111	467.000	0001 1100 0101 1100
464.550	0001 1010 0111 0010	465.375	0001 1011 0001 0111	466.200	0001 1011 1011 1100	467.025	0001 1100 0110 0001
464.575	0001 1010 0111 0111	465.400	0001 1011 0001 1100	466.225	0001 1011 1100 0001	467.050	0001 1100 0110 0110
464.600	0001 1010 0111 1100	465.425	0001 1011 0010 0001	466.250	0001 1011 1100 0110	467.075	0001 1100 0110 1011
464.625	0001 1010 1000 0001	465.450	0001 1011 0010 0110	466.275	0001 1011 1100 1011	467.100	0001 1100 0111 0000
464.650	0001 1010 1000 0110	465.475	0001 1011 0010 1011	466.300	0001 1011 1101 0000	467.125	0001 1100 0111 0101
464.675	0001 1010 1000 1011	465.500	0001 1011 0011 0000	466.325	0001 1011 1101 0101	467.150	0001 1100 0111 1010
464.700	0001 1010 1001 0000	465.525	0001 1011 0011 0101	466.350	0001 1011 1101 1010	467.175	0001 1100 0111 1111
464.725	0001 1010 1001 0101	465.550	0001 1011 0011 1010	466.375	0001 1011 1101 1111	467.200	0001 1100 1000 0100
464.750	0001 1010 1001 1010	465.575	0001 1011 0011 1111	466.400	0001 1011 1110 0100	467.225	0001 1100 1000 1001
464.775	0001 1010 1001 1111	465.600	0001 1011 0100 0100	466.425	0001 1011 1110 1001	467.250	0001 1100 1000 1110
464.800	0001 1010 1010 0100	465.625	0001 1011 0100 1001	466.450	0001 1011 1110 1110	467.275	0001 1100 1001 0011
464.825	0001 1010 1010 1001	465.650	0001 1011 0100 1110	466.475	0001 1011 1111 0011	467.300	0001 1100 1001 1000
464.850	0001 1010 1010 1110	465.675	0001 1011 0101 0011	466.500	0001 1011 1111 1000	467.325	0001 1100 1001 1101
464.875	0001 1010 1011 0011	465.700	0001 1011 0101 1000	466.525	0001 1011 1111 1101	467.350	0001 1100 1010 0010
464.900	0001 1010 1011 1000	465.725	0001 1011 0101 1101	466.550	0001 1100 0000 0010	467.375	0001 1100 1010 0111
464.925	0001 1010 1011 1101	465.750	0001 1011 0110 0010	466.575	0001 1100 0000 0111	467.400	0001 1100 1010 1100
464.950	0001 1010 1100 0010	465.775	0001 1011 0110 0111	466.600	0001 1100 0000 1100	467.425	0001 1100 1011 0001
464.975	0001 1010 1100 0111	465.800	0001 1011 0110 1100	466.625	0001 1100 0001 0001	467.450	0001 1100 1011 0110
465.000	0001 1010 1100 1100	465.825	0001 1011 0111 0001	466.650	0001 1100 0001 0110	467.475	0001 1100 1011 1011
465.025	0001 1010 1101 0001	465.850	0001 1011 0111 0110	466.675	0001 1100 0001 1011	467.500	0001 1100 1100 0000
465.050	0001 1010 1101 0110	465.875	0001 1011 0111 1011	466.700	0001 1100 0010 0000	467.525	0001 1100 1100 0101

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
467.550	0001 1100 1100 1010	468.175	0001 1101 0100 0111	468.800	0001 1101 1100 0100	469.425	0001 1110 0100 0001
467.575	0001 1100 1100 1111	468.200	0001 1101 0100 1100	468.825	0001 1101 1100 1001	469.450	0001 1110 0100 0110
467.600	0001 1100 1101 0100	468.225	0001 1101 0101 0001	468.850	0001 1101 1100 1110	469.475	0001 1110 0100 1011
467.625	0001 1100 1101 1001	468.250	0001 1101 0101 0110	468.875	0001 1101 1101 0011	469.500	0001 1110 0101 0000
467.650	0001 1100 1101 1110	468.275	0001 1101 0101 1011	468.900	0001 1101 1101 1000	469.525	0001 1110 0101 0101
467.675	0001 1100 1110 0011	468.300	0001 1101 0110 0000	468.925	0001 1101 1101 1101	469.550	0001 1110 0101 1010
467.700	0001 1100 1110 1000	468.325	0001 1101 0110 0101	468.950	0001 1101 1110 0010	469.575	0001 1110 0101 1111
467.725	0001 1100 1110 1101	468.350	0001 1101 0110 1010	468.975	0001 1101 1110 0111	469.600	0001 1110 0110 0100
467.750	0001 1100 1111 0010	468.375	0001 1101 0110 1111	469.000	0001 1101 1110 1100	469.625	0001 1110 0110 1001
467.775	0001 1100 1111 0111	468.400	0001 1101 0111 0100	469.025	0001 1101 1111 0001	469.650	0001 1110 0110 1110
467.800	0001 1100 1111 1100	468.425	0001 1101 0111 1001	469.050	0001 1101 1111 0110	469.675	0001 1110 0111 0011
467.825	0001 1101 0000 0001	468.450	0001 1101 0111 1110	469.075	0001 1101 1111 1011	469.700	0001 1110 0111 1000
467.850	0001 1101 0000 0110	468.475	0001 1101 1000 0011	469.100	0001 1110 0000 0000	469.725	0001 1110 0111 1101
467.875	0001 1101 0000 1011	468.500	0001 1101 1000 1000	469.125	0001 1110 0000 0101	469.750	0001 1110 1000 0010
467.900	0001 1101 0001 0000	468.525	0001 1101 1000 1101	469.150	0001 1110 0000 1010	469.775	0001 1110 1000 0111
467.925	0001 1101 0001 0101	468.550	0001 1101 1001 0010	469.175	0001 1110 0000 1111	469.800	0001 1110 1000 1100
467.950	0001 1101 0001 1010	468.575	0001 1101 1001 0111	469.200	0001 1110 0001 0100	469.825	0001 1110 1001 0001
467.975	0001 1101 0001 1111	468.600	0001 1101 1001 1100	469.225	0001 1110 0001 1001	469.850	0001 1110 1001 0110
468.000	0001 1101 0010 0100	468.625	0001 1101 1010 0001	469.250	0001 1110 0001 1110	469.875	0001 1110 1001 1011
468.025	0001 1101 0010 1001	468.650	0001 1101 1010 0110	469.275	0001 1110 0010 0011	469.900	0001 1110 1010 0000
468.050	0001 1101 0010 1110	468.675	0001 1101 1010 1011	469.300	0001 1110 0010 1000	469.925	0001 1110 1010 0101
468.075	0001 1101 0011 0011	468.700	0001 1101 1011 0000	469.325	0001 1110 0010 1101	469.950	0001 1110 1010 1010
468.100	0001 1101 0011 1000	468.725	0001 1101 1011 0101	469.350	0001 1110 0011 0010	469.975	0001 1110 1010 1111
468.125	0001 1101 0011 1101	468.750	0001 1101 1011 1010	469.375	0001 1110 0011 0111	470.000	0001 1110 1011 0100
468.150	0001 1101 0100 0010	468.775	0001 1101 1011 1111	469.400	0001 1110 0011 1100		

490.000 to 508.000 MHz

Note: Reception is not possible without retuning
by a competent service technician.

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
490.000	0001 1110 1011 0100	490.725	0001 1110 0010 0011	491.450	0001 1101 1001 0010	492.175	0001 1101 0000 0001
490.025	0001 1110 1010 1111	490.750	0001 1110 0001 1110	491.475	0001 1101 1000 1101	492.200	0001 1100 1111 1100
490.050	0001 1110 1010 1010	490.775	0001 1110 0001 1001	491.500	0001 1101 1000 1000	492.225	0001 1100 1111 0111
490.075	0001 1110 1010 0101	490.800	0001 1110 0001 0100	491.525	0001 1101 1000 0011	492.250	0001 1100 1111 0010
490.100	0001 1110 1010 0000	490.825	0001 1110 0000 1111	491.550	0001 1101 0111 1110	492.275	0001 1100 1110 1101
490.125	0001 1110 1001 1011	490.850	0001 1110 0000 1010	491.575	0001 1101 0111 1001	492.300	0001 1100 1110 1000
490.150	0001 1110 1001 0110	490.875	0001 1110 0000 0101	491.600	0001 1101 0111 0100	492.325	0001 1100 1110 0011
490.175	0001 1110 1001 0001	490.900	0001 1110 0000 0000	491.625	0001 1101 0110 1111	492.350	0001 1100 1101 1110
490.200	0001 1110 1000 1100	490.925	0001 1101 1111 1011	491.650	0001 1101 0110 1010	492.375	0001 1100 1101 1001
490.225	0001 1110 1000 0111	490.950	0001 1101 1111 0110	491.675	0001 1101 0110 0101	492.400	0001 1100 1101 0100
490.250	0001 1110 1000 0010	490.975	0001 1101 1111 0001	491.700	0001 1101 0110 0000	492.425	0001 1100 1100 1111
490.275	0001 1110 0111 1101	491.000	0001 1101 1110 1100	491.725	0001 1101 0101 1011	492.450	0001 1100 1100 1010
490.300	0001 1110 0111 1000	491.025	0001 1101 1110 0111	491.750	0001 1101 0101 0110	492.475	0001 1100 1100 0101
490.325	0001 1110 0111 0011	491.050	0001 1101 1110 0010	491.775	0001 1101 0101 0001	492.500	0001 1100 1100 0000
490.350	0001 1110 0110 1110	491.075	0001 1101 1101 1101	491.800	0001 1101 0100 1100	492.525	0001 1100 1011 1011
490.375	0001 1110 0110 1001	491.100	0001 1101 1101 1000	491.825	0001 1101 0100 0111	492.550	0001 1100 1011 0110
490.400	0001 1110 0110 0100	491.125	0001 1101 1101 0011	491.850	0001 1101 0100 0010	492.575	0001 1100 1011 0001
490.425	0001 1110 0101 1111	491.150	0001 1101 1100 1110	491.875	0001 1101 0011 1101	492.600	0001 1100 1010 1100
490.450	0001 1110 0101 1010	491.175	0001 1101 1100 1001	491.900	0001 1101 0011 1000	492.625	0001 1100 1010 0111
490.475	0001 1110 0101 0101	491.200	0001 1101 1100 0100	491.925	0001 1101 0011 0011	492.650	0001 1100 1010 0010
490.500	0001 1110 0101 0000	491.225	0001 1101 1011 1111	491.950	0001 1101 0010 1110	492.675	0001 1100 1001 1101
490.525	0001 1110 0100 1011	491.250	0001 1101 1011 1010	491.975	0001 1101 0010 1001	492.700	0001 1100 1001 1000
490.550	0001 1110 0100 0110	491.275	0001 1101 1011 0101	492.000	0001 1101 0010 0100	492.725	0001 1100 1001 0011
490.575	0001 1110 0100 0001	491.300	0001 1101 1011 0000	492.025	0001 1101 0001 1111	492.750	0001 1100 1000 1110
490.600	0001 1110 0011 1100	491.325	0001 1101 1010 1011	492.050	0001 1101 0001 1010	492.775	0001 1100 1000 1001
490.625	0001 1110 0011 0111	491.350	0001 1101 1010 0110	492.075	0001 1101 0001 0101	492.800	0001 1100 1000 0100
490.650	0001 1110 0011 0010	491.375	0001 1101 1010 0001	492.100	0001 1101 0001 0000	492.825	0001 1100 0111 1111
490.675	0001 1110 0010 1101	491.400	0001 1101 1001 1100	492.125	0001 1101 0000 1011	492.850	0001 1100 0111 1010
490.700	0001 1110 0010 1000	491.425	0001 1101 1001 0111	492.150	0001 1101 0000 0110	492.875	0001 1100 0111 0101

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
492.900	0001 1100 0111 0000	493.725	0001 1011 1100 1011	494.550	0001 1011 0010 0110	495.375	0001 1010 1000 0001
492.925	0001 1100 0110 1011	493.750	0001 1011 1100 0110	494.575	0001 1011 0010 0001	495.400	0001 1010 0111 1100
492.950	0001 1100 0110 0110	493.775	0001 1011 1100 0001	494.600	0001 1011 0001 1100	495.425	0001 1010 0111 0111
492.975	0001 1100 0110 0001	493.800	0001 1011 1011 1100	494.625	0001 1011 0001 0111	495.450	0001 1010 0111 0010
493.000	0001 1100 0101 1100	493.825	0001 1011 1011 0111	494.650	0001 1011 0001 0010	495.475	0001 1010 0110 1101
493.025	0001 1100 0101 0111	493.850	0001 1011 1011 0010	494.675	0001 1011 0000 1101	495.500	0001 1010 0110 1000
493.050	0001 1100 0101 0010	493.875	0001 1011 1010 1101	494.700	0001 1011 0000 1000	495.525	0001 1010 0110 0011
493.075	0001 1100 0100 1101	493.900	0001 1011 1010 1000	494.725	0001 1011 0000 0011	495.550	0001 1010 0101 1110
493.100	0001 1100 0100 1000	493.925	0001 1011 1010 0011	494.750	0001 1010 1111 1110	495.575	0001 1010 0101 1001
493.125	0001 1100 0100 0011	493.950	0001 1011 1001 1110	494.775	0001 1010 1111 1001	495.600	0001 1010 0101 0100
493.150	0001 1100 0011 1110	493.975	0001 1011 1001 1001	494.800	0001 1010 1111 0100	495.625	0001 1010 0100 1111
493.175	0001 1100 0011 1001	494.000	0001 1011 1001 0100	494.825	0001 1010 1110 1111	495.650	0001 1010 0100 1010
493.200	0001 1100 0011 0100	494.025	0001 1011 1000 1111	494.850	0001 1010 1110 1010	495.675	0001 1010 0100 0101
493.225	0001 1100 0010 1111	494.050	0001 1011 1000 1010	494.875	0001 1010 1110 0101	495.700	0001 1010 0100 0000
493.250	0001 1100 0010 1010	494.075	0001 1011 1000 0101	494.900	0001 1010 1110 0000	495.725	0001 1010 0011 1011
493.275	0001 1100 0010 0101	494.100	0001 1011 1000 0000	494.925	0001 1010 1101 1011	495.750	0001 1010 0011 0110
493.300	0001 1100 0010 0000	494.125	0001 1011 0111 1011	494.950	0001 1010 1101 0110	495.775	0001 1010 0011 0001
493.325	0001 1100 0001 1011	494.150	0001 1011 0111 0110	494.975	0001 1010 1101 0001	495.800	0001 1010 0010 1100
493.350	0001 1100 0001 0110	494.175	0001 1011 0111 0001	495.000	0001 1010 1100 1100	495.825	0001 1010 0010 0111
493.375	0001 1100 0001 0001	494.200	0001 1011 0110 1100	495.025	0001 1010 1100 0111	495.850	0001 1010 0010 0010
493.400	0001 1100 0000 1100	494.225	0001 1011 0110 0111	495.050	0001 1010 1100 0010	495.875	0001 1010 0001 1101
493.425	0001 1100 0000 0111	494.250	0001 1011 0110 0010	495.075	0001 1010 1011 1101	495.900	0001 1010 0001 1000
493.450	0001 1100 0000 0010	494.275	0001 1011 0101 1101	495.100	0001 1010 1011 1000	495.925	0001 1010 0001 0011
493.475	0001 1011 1111 1101	494.300	0001 1011 0101 1000	495.125	0001 1010 1011 0011	495.950	0001 1010 0000 1110
493.500	0001 1011 1111 1000	494.325	0001 1011 0101 0011	495.150	0001 1010 1010 1110	495.975	0001 1010 0000 1001
493.525	0001 1011 1111 0011	494.350	0001 1011 0100 1110	495.175	0001 1010 1010 1001	496.000	0001 1010 0000 0100
493.550	0001 1011 1110 1110	494.375	0001 1011 0100 1001	495.200	0001 1010 1010 0100	496.025	0001 1001 1111 1111
493.575	0001 1011 1110 1001	494.400	0001 1011 0100 0100	495.225	0001 1010 1001 1111	496.050	0001 1001 1111 1010
493.600	0001 1011 1110 0100	494.425	0001 1011 0011 1111	495.250	0001 1010 1001 1010	496.075	0001 1001 1111 0101
493.625	0001 1011 1101 1111	494.450	0001 1011 0011 1010	495.275	0001 1010 1001 0101	496.100	0001 1001 1111 0000
493.650	0001 1011 1101 1010	494.475	0001 1011 0011 0101	495.300	0001 1010 1001 0000	496.125	0001 1001 1110 1011
493.675	0001 1011 1101 0101	494.500	0001 1011 0011 0000	495.325	0001 1010 1000 1011	496.150	0001 1001 1110 0110
493.700	0001 1011 1101 0000	494.525	0001 1011 0010 1011	495.350	0001 1010 1000 0110	496.175	0001 1001 1110 0001

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
496.200	0001	1001	1101	1100	497.025	0001	1001	0011	0111	497.850	0001	1000	1001	0010	498.675	0001	0111	1110	1101
496.225	0001	1001	1101	0111	497.050	0001	1001	0011	0010	497.875	0001	1000	1000	1101	498.700	0001	0111	1110	1000
496.250	0001	1001	1101	0010	497.075	0001	1001	0010	1101	497.900	0001	1000	1000	1000	498.725	0001	0111	1110	0011
496.275	0001	1001	1100	1101	497.100	0001	1001	0010	1000	497.925	0001	1000	1000	0011	498.750	0001	0111	1101	1110
496.300	0001	1001	1100	1000	497.125	0001	1001	0010	0011	497.950	0001	1000	0111	1110	498.775	0001	0111	1101	1001
496.325	0001	1001	1100	0011	497.150	0001	1001	0001	1110	497.975	0001	1000	0111	1001	498.800	0001	0111	1101	0100
496.350	0001	1001	1011	1110	497.175	0001	1001	0001	1001	498.000	0001	1000	0111	0100	498.825	0001	0111	1100	1111
496.375	0001	1001	1011	1001	497.200	0001	1001	0001	0100	498.025	0001	1000	0110	1111	498.850	0001	0111	1100	1010
496.400	0001	1001	1011	0100	497.225	0001	1001	0000	1111	498.050	0001	1000	0110	1010	498.875	0001	0111	1100	0101
496.425	0001	1001	1010	1111	497.250	0001	1001	0000	1010	498.075	0001	1000	0110	0101	498.900	0001	0111	1100	0000
496.450	0001	1001	1010	1010	497.275	0001	1001	0000	0101	498.100	0001	1000	0110	0000	498.925	0001	0111	1011	1011
496.475	0001	1001	1010	0101	497.300	0001	1001	0000	0000	498.125	0001	1000	0101	1011	498.950	0001	0111	1011	0110
496.500	0001	1001	1010	0000	497.325	0001	1000	1111	1011	498.150	0001	1000	0101	0110	498.975	0001	0111	1011	0001
496.525	0001	1001	1001	1011	497.350	0001	1000	1111	0110	498.175	0001	1000	0101	0001	499.000	0001	0111	1010	1100
496.550	0001	1001	1001	0110	497.375	0001	1000	1111	0001	498.200	0001	1000	0100	1100	499.025	0001	0111	1010	0111
496.575	0001	1001	1001	0001	497.400	0001	1000	1110	1100	498.225	0001	1000	0100	0111	499.050	0001	0111	1010	0010
496.600	0001	1001	1000	1100	497.425	0001	1000	1110	0111	498.250	0001	1000	0100	0010	499.075	0001	0111	1001	1101
496.625	0001	1001	1000	0111	497.450	0001	1000	1110	0010	498.275	0001	1000	0011	1101	499.100	0001	0111	1001	1000
496.650	0001	1001	1000	0010	497.475	0001	1000	1101	1101	498.300	0001	1000	0011	1000	499.125	0001	0111	1001	0011
496.675	0001	1001	0111	1101	497.500	0001	1000	1101	1000	498.325	0001	1000	0011	0011	499.150	0001	0111	1000	1110
496.700	0001	1001	0111	1000	497.525	0001	1000	1101	0011	498.350	0001	1000	0010	1110	499.175	0001	0111	1000	1001
496.725	0001	1001	0111	0011	497.550	0001	1000	1100	1110	498.375	0001	1000	0010	1001	499.200	0001	0111	1000	0100
496.750	0001	1001	0110	1110	497.575	0001	1000	1100	1001	498.400	0001	1000	0010	0100	499.225	0001	0111	0111	1111
496.775	0001	1001	0110	1001	497.600	0001	1000	1100	0100	498.425	0001	1000	0001	1111	499.250	0001	0111	0111	1010
496.800	0001	1001	0110	0100	497.625	0001	1000	1011	1111	498.450	0001	1000	0001	1010	499.275	0001	0111	0111	0101
496.825	0001	1001	0101	1111	497.650	0001	1000	1011	1010	498.475	0001	1000	0001	0101	499.300	0001	0111	0111	0000
496.850	0001	1001	0101	1010	497.675	0001	1000	1011	0101	498.500	0001	1000	0001	0000	499.325	0001	0111	0110	1011
496.875	0001	1001	0101	0101	497.700	0001	1000	1011	0000	498.525	0001	1000	0000	1011	499.350	0001	0111	0110	0110
496.900	0001	1001	0101	0000	497.725	0001	1000	1010	1011	498.550	0001	1000	0000	0110	499.375	0001	0111	0110	0001
496.925	0001	1001	0100	1011	497.750	0001	1000	1010	0110	498.575	0001	1000	0000	0001	499.400	0001	0111	0101	1100
496.950	0001	1001	0100	0110	497.775	0001	1000	1010	0001	498.600	0001	0111	1111	1100	499.425	0001	0111	0101	0111
496.975	0001	1001	0100	0001	497.800	0001	1000	1001	1100	498.625	0001	0111	1111	0111	499.450	0001	0111	0101	0010
497.000	0001	1001	0011	1100	497.825	0001	1000	1001	0111	498.650	0001	0111	1111	0010	499.475	0001	0111	0100	1101

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
499.500	0001 0111 0100 1000	500.325	0001 0110 1010 0011	501.150	0001 0101 1111 1110	501.975	0001 0101 0101 1001
499.525	0001 0111 0100 0011	500.350	0001 0110 1001 1110	501.175	0001 0101 1111 1001	502.000	0001 0101 0101 0100
499.550	0001 0111 0011 1110	500.375	0001 0110 1001 1001	501.200	0001 0101 1111 0100	502.025	0001 0101 0100 1111
499.575	0001 0111 0011 1001	500.400	0001 0110 1001 0100	501.225	0001 0101 1110 1111	502.050	0001 0101 0100 1010
499.600	0001 0111 0011 0100	500.425	0001 0110 1000 1111	501.250	0001 0101 1110 1010	502.075	0001 0101 0100 0101
499.625	0001 0111 0010 1111	500.450	0001 0110 1000 1010	501.275	0001 0101 1110 0101	502.100	0001 0101 0100 0000
499.650	0001 0111 0010 1010	500.475	0001 0110 1000 0101	501.300	0001 0101 1110 0000	502.125	0001 0101 0011 1011
499.675	0001 0111 0010 0101	500.500	0001 0110 1000 0000	501.325	0001 0101 1101 1011	502.150	0001 0101 0011 0110
499.700	0001 0111 0010 0000	500.525	0001 0110 0111 1011	501.350	0001 0101 1101 0110	502.175	0001 0101 0011 0001
499.725	0001 0111 0001 1011	500.550	0001 0110 0111 0110	501.375	0001 0101 1101 0001	502.200	0001 0101 0010 1100
499.750	0001 0111 0001 0110	500.575	0001 0110 0111 0001	501.400	0001 0101 1100 1100	502.225	0001 0101 0010 0111
499.775	0001 0111 0001 0001	500.600	0001 0110 0110 1100	501.425	0001 0101 1100 0111	502.250	0001 0101 0010 0010
499.800	0001 0111 0000 1100	500.625	0001 0110 0110 0111	501.450	0001 0101 1100 0010	502.275	0001 0101 0001 1101
499.825	0001 0111 0000 0111	500.650	0001 0110 0110 0010	501.475	0001 0101 1011 1101	502.300	0001 0101 0001 1000
499.850	0001 0111 0000 0010	500.675	0001 0110 0101 1101	501.500	0001 0101 1011 1000	502.325	0001 0101 0001 0011
499.875	0001 0110 1111 1101	500.700	0001 0110 0101 1000	501.525	0001 0101 1011 0011	502.350	0001 0101 0000 1110
499.900	0001 0110 1111 1000	500.725	0001 0110 0101 0011	501.550	0001 0101 1010 1110	502.375	0001 0101 0000 1001
499.925	0001 0110 1111 0011	500.750	0001 0110 0100 1110	501.575	0001 0101 1010 1001	502.400	0001 0101 0000 0100
499.950	0001 0110 1110 1110	500.775	0001 0110 0100 1001	501.600	0001 0101 1010 0100	502.425	0001 0100 1111 1111
499.975	0001 0110 1110 1001	500.800	0001 0110 0100 0100	501.625	0001 0101 1001 1111	502.450	0001 0100 1111 1010
500.000	0001 0110 1110 0100	500.825	0001 0110 0011 1111	501.650	0001 0101 1001 1010	502.475	0001 0100 1111 0101
500.025	0001 0110 1101 1111	500.850	0001 0110 0011 1010	501.675	0001 0101 1001 0101	502.500	0001 0100 1111 0000
500.050	0001 0110 1101 1010	500.875	0001 0110 0011 0101	501.700	0001 0101 1001 0000	502.525	0001 0100 1110 1011
500.075	0001 0110 1101 0101	500.900	0001 0110 0011 0000	501.725	0001 0101 1000 1011	502.550	0001 0100 1110 0110
500.100	0001 0110 1101 0000	500.925	0001 0110 0010 1011	501.750	0001 0101 1000 0110	502.575	0001 0100 1110 0001
500.125	0001 0110 1100 1011	500.950	0001 0110 0010 0110	501.775	0001 0101 1000 0001	502.600	0001 0100 1101 1100
500.150	0001 0110 1100 0110	500.975	0001 0110 0010 0001	501.800	0001 0101 0111 1100	502.625	0001 0100 1101 0111
500.175	0001 0110 1100 0001	501.000	0001 0110 0001 1100	501.825	0001 0101 0111 0111	502.650	0001 0100 1101 0010
500.200	0001 0110 1011 1100	501.025	0001 0110 0001 0111	501.850	0001 0101 0111 0010	502.675	0001 0100 1100 1101
500.225	0001 0110 1011 0111	501.050	0001 0110 0001 0010	501.875	0001 0101 0110 1101	502.700	0001 0100 1100 1000
500.250	0001 0110 1011 0010	501.075	0001 0110 0000 1101	501.900	0001 0101 0110 1000	502.725	0001 0100 1100 0011
500.275	0001 0110 1010 1101	501.100	0001 0110 0000 1000	501.925	0001 0101 0110 0011	502.750	0001 0100 1011 1110
500.300	0001 0110 1010 1000	501.125	0001 0110 0000 0011	501.950	0001 0101 0101 1110	502.775	0001 0100 1011 1001

Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE	Fre- quency	CODE
502.800	0001 0100 1011 0100	503.625	0001 0100 0000 1111	504.450	0001 0011 0110 1010	505.275	0001 0010 1100 0101
502.825	0001 0100 1010 1111	503.650	0001 0100 0000 1010	504.475	0001 0011 0110 0101	505.300	0001 0010 1100 0000
502.850	0001 0100 1010 1010	503.675	0001 0100 0000 0101	504.500	0001 0011 0110 0000	505.325	0001 0010 1011 1011
502.875	0001 0100 1010 0101	503.700	0001 0100 0000 0000	504.525	0001 0011 0101 1011	505.350	0001 0010 1011 0110
502.900	0001 0100 1010 0000	503.725	0001 0011 1111 1011	504.550	0001 0011 0101 0110	505.375	0001 0010 1011 0001
502.925	0001 0100 1001 1011	503.750	0001 0011 1111 0110	504.575	0001 0011 0101 0001	505.400	0001 0010 1010 1100
502.950	0001 0100 1001 0110	503.775	0001 0011 1111 0001	504.600	0001 0011 0100 1100	505.425	0001 0010 1010 0111
502.975	0001 0100 1001 0001	503.800	0001 0011 1110 1100	504.625	0001 0011 0100 0111	505.450	0001 0010 1010 0010
503.000	0001 0100 1000 1100	503.825	0001 0011 1110 0111	504.650	0001 0011 0100 0010	505.475	0001 0010 1001 1101
503.025	0001 0100 1000 0111	503.850	0001 0011 1110 0010	504.675	0001 0011 0011 1101	505.500	0001 0010 1001 1000
503.050	0001 0100 1000 0010	503.875	0001 0011 1101 1101	504.700	0001 0011 0011 1000	505.525	0001 0010 1001 0011
503.075	0001 0100 0111 1101	503.900	0001 0011 1101 1000	504.725	0001 0011 0011 0011	505.550	0001 0010 1000 1110
503.100	0001 0100 0111 1000	503.925	0001 0011 1101 0011	504.750	0001 0011 0010 1110	505.575	0001 0010 1000 1001
503.125	0001 0100 0111 0011	503.950	0001 0011 1100 1110	504.775	0001 0011 0010 1001	505.600	0001 0010 1000 0100
503.150	0001 0100 0110 1110	503.975	0001 0011 1100 1001	504.800	0001 0011 0010 0100	505.625	0001 0010 0111 1111
503.175	0001 0100 0110 1001	504.000	0001 0011 1100 0100	504.825	0001 0011 0001 1111	505.650	0001 0010 0111 1010
503.200	0001 0100 0110 0100	504.025	0001 0011 1011 1111	504.850	0001 0011 0001 1010	505.675	0001 0010 0111 0101
503.225	0001 0100 0101 1111	504.050	0001 0011 1011 1010	504.875	0001 0011 0001 0101	505.700	0001 0010 0111 0000
503.250	0001 0100 0101 1010	504.075	0001 0011 1011 0101	504.900	0001 0011 0001 0000	505.725	0001 0010 0110 1011
503.275	0001 0100 0101 0101	504.100	0001 0011 1011 0000	504.925	0001 0011 0000 1011	505.750	0001 0010 0110 0110
503.300	0001 0100 0101 0000	504.125	0001 0011 1010 1011	504.950	0001 0011 0000 0110	505.775	0001 0010 0110 0001
503.325	0001 0100 0100 1011	504.150	0001 0011 1010 0110	504.975	0001 0011 0000 0001	505.800	0001 0010 0101 1100
503.350	0001 0100 0100 0110	504.175	0001 0011 1010 0001	505.000	0001 0010 1111 1100	505.825	0001 0010 0101 0111
503.375	0001 0100 0100 0001	504.200	0001 0011 1001 1100	505.025	0001 0010 1111 0111	505.850	0001 0010 0101 0010
503.400	0001 0100 0011 1100	504.225	0001 0011 1001 0111	505.050	0001 0010 1111 0010	505.875	0001 0010 0100 1101
503.425	0001 0100 0011 0111	504.250	0001 0011 1001 0010	505.075	0001 0010 1110 1101	505.900	0001 0010 0100 1000
503.450	0001 0100 0011 0010	504.275	0001 0011 1000 1101	505.100	0001 0010 1110 1000	505.925	0001 0010 0100 0011
503.475	0001 0100 0010 1101	504.300	0001 0011 1000 1000	505.125	0001 0010 1110 0011	505.950	0001 0010 0011 1110
503.500	0001 0100 0010 1000	504.325	0001 0011 1000 0011	505.150	0001 0010 1101 1110	505.975	0001 0010 0011 1001
503.525	0001 0100 0010 0011	504.350	0001 0011 0111 1110	505.175	0001 0010 1101 1001	506.000	0001 0010 0011 0100
503.550	0001 0100 0001 1110	504.375	0001 0011 0111 1001	505.200	0001 0010 1101 0100	506.025	0001 0010 0010 1111
503.575	0001 0100 0001 1001	504.400	0001 0011 0111 0100	505.225	0001 0010 1100 1111	506.050	0001 0010 0010 1010
503.600	0001 0100 0001 0100	504.425	0001 0011 0110 1111	505.250	0001 0010 1100 1010	506.075	0001 0010 0010 0101

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
506.100	0001	0010	0010	0000	505.925	0001	0010	0100	0011	506.750	0001	0001	1001	1110	507.575	0001	0000	1111	1001
506.125	0001	0010	0001	1011	505.950	0001	0010	0011	1110	506.775	0001	0001	1001	1001	507.600	0001	0000	1111	0100
506.150	0001	0010	0001	0110	505.975	0001	0010	0011	1001	506.800	0001	0001	1001	0100	507.625	0001	0000	1110	1111
506.175	0001	0010	0001	0001	506.000	0001	0010	0011	0100	506.825	0001	0001	1000	1111	507.650	0001	0000	1110	1010
506.200	0001	0010	0000	1100	506.025	0001	0010	0010	1111	506.850	0001	0001	1000	1010	507.675	0001	0000	1110	0101
506.225	0001	0010	0000	0111	506.050	0001	0010	0010	1010	506.875	0001	0001	1000	0101	507.700	0001	0000	1110	0000
506.250	0001	0010	0000	0010	506.075	0001	0010	0010	0101	506.900	0001	0001	1000	0000	507.725	0001	0000	1101	1011
506.275	0001	0001	1111	1101	506.100	0001	0010	0010	0000	506.925	0001	0001	0111	1011	507.750	0001	0000	1101	0110
506.300	0001	0001	1111	1000	506.125	0001	0010	0001	1011	506.950	0001	0001	0111	0110	507.775	0001	0000	1101	0001
506.325	0001	0001	1111	0011	506.150	0001	0010	0001	0110	506.975	0001	0001	0111	0001	507.800	0001	0000	1100	1100
506.350	0001	0001	1110	1110	506.175	0001	0010	0001	0001	507.000	0001	0001	0110	1100	507.825	0001	0000	1100	0111
506.375	0001	0001	1110	1001	506.200	0001	0010	0000	1100	507.025	0001	0001	0110	0111	507.850	0001	0000	1100	0010
506.400	0001	0001	1110	0100	506.225	0001	0010	0000	0111	507.050	0001	0001	0110	0010	507.875	0001	0000	1011	1101
506.425	0001	0001	1101	1111	506.250	0001	0010	0000	0010	507.075	0001	0001	0101	1101	507.900	0001	0000	1011	1000
506.450	0001	0001	1101	1010	506.275	0001	0001	1111	1101	507.100	0001	0001	0101	1000	507.925	0001	0000	1011	0011
506.475	0001	0001	1101	0101	506.300	0001	0001	1111	1000	507.125	0001	0001	0101	0011	507.950	0001	0000	1010	1110
506.500	0001	0001	1101	0000	506.325	0001	0001	1111	0011	507.150	0001	0001	0100	1110	507.975	0001	0000	1010	1001
506.525	0001	0001	1100	1011	506.350	0001	0001	1110	1110	507.175	0001	0001	0100	1001	508.000	0001	0000	1010	0100
506.550	0001	0001	1100	0110	506.375	0001	0001	1110	1001	507.200	0001	0001	0100	0100	508.025	0001	0000	1001	1111
506.575	0001	0010	1000	1001	506.400	0001	0001	1110	0100	507.225	0001	0001	0011	1111	508.050	0001	0000	1001	1010
506.600	0001	0010	1000	0100	506.425	0001	0001	1101	1111	507.250	0001	0001	0011	1010	508.075	0001	0000	1001	0101
506.625	0001	0010	0111	1111	506.450	0001	0001	1101	1010	507.275	0001	0001	0011	0101	508.100	0001	0000	1001	0000
506.650	0001	0010	0111	1010	506.475	0001	0001	1101	0101	507.300	0001	0001	0011	0000	508.125	0001	0000	1000	1011
506.675	0001	0010	0111	0101	506.500	0001	0001	1101	0000	507.325	0001	0001	0010	1011	508.150	0001	0000	1000	0110
506.700	0001	0010	0111	0000	506.525	0001	0001	1100	1011	507.350	0001	0001	0010	0110	508.175	0001	0000	1000	0001
506.725	0001	0010	0110	1011	506.550	0001	0001	1100	0110	507.375	0001	0001	0010	0001	508.200	0001	0000	0111	1100
506.750	0001	0010	0110	0110	506.575	0001	0001	1100	0001	507.400	0001	0001	0001	1100	508.225	0001	0000	0111	0111
506.775	0001	0010	0110	0001	506.600	0001	0001	1011	1100	507.425	0001	0001	0001	0111	508.250	0001	0000	0111	0010
506.800	0001	0010	0101	1100	506.625	0001	0001	1011	0111	507.450	0001	0001	0001	0010	508.275	0001	0000	0110	1101
506.825	0001	0010	0101	0111	506.650	0001	0001	1011	0010	507.475	0001	0001	0000	1101	508.300	0001	0000	0110	1000
506.850	0001	0010	0101	0010	506.675	0001	0001	1010	1101	507.500	0001	0001	0000	1000	508.325	0001	0000	0110	0011
506.875	0001	0010	0100	1101	506.700	0001	0001	1010	1000	507.525	0001	0001	0000	0011	508.350	0001	0000	0101	1110
506.900	0001	0010	0100	1000	506.725	0001	0001	1010	0011	507.550	0001	0000	1111	1110	508.375	0001	0000	0101	1001

Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE				Fre- quency	CODE			
508.400	0001	0000	0101	0100	508.525	0001	0000	0011	1011	508.650	0001	0000	0010	0010	508.775	0001	0000	0000	1001
508.425	0001	0000	0100	1111	508.550	0001	0000	0011	0110	508.675	0001	0000	0001	1101	508.800	0001	0000	0000	0100
508.450	0001	0000	0100	1010	508.575	0001	0000	0011	0001	508.700	0001	0000	0001	1000	508.825	0001	0000	0000	0000
508.475	0001	0000	0100	0101	508.600	0001	0000	0010	1100	508.725	0001	0000	0001	0011					
508.500	0001	0000	0100	0000	508.625	0001	0000	0010	0111	508.750	0001	0000	0000	1110					