

| パーツ No. | MX-6S | MX-7S | MX-21S | MX-3.5S | MX-28S | MX-14S | MX-18S | MX-24S |
|---------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| Q 3 | 2SC 2053 | 2SC 1959 | 2SC 1959 | 2SC 1959 | 2SC 1959 | 2SC 1959 | 2SC 1959 | 2SC 1959 |
| X 1 | 12.9922 MHz | 9.1899 MHz | 16.2670 MHz | 14.8370 MHz | 13.2775 MHz | 12.7640 MHz | 14.6990 MHz | 12.0747 MHz |
| X 3 | 11.2720 MHz | 11.2720 MHz | 11.2750 MHz | 11.2720 MHz | 11.2750 MHz | 11.2750 MHz | 11.2750 MHz | 11.2750 MHz |
| D 31 | 1S1588 | 1S1588 | N C | 1S1588 | N C | N C | N C | N C |
| D 33 | ジャンパ | " | 1S1588 | " | 1S1588 | 1S1588 | 1S1588 | 1S1588 |
| CH 2 | 100 | 330 | 330 | 331 | 330 | 330 μH | 33 μH | 330 μH |
| CH 3 | " | " | " | " | " | 330 " | 33 μH | 330 μH |
| CH 4 | " | " | " | " | " | 330 " | 33 μH | 330 μH |
| TC 2 | トリマ | 470 P | トリマ | 470 P | トリマ | トリマ | トリマ | トリマ |
| TC 3 | " | 440 P | " | 680 P | " | " | " | " |
| TC 4 | " | 300 P | 100 P | N C | 68 P | 68 PF | 22 PF | 100 PF |
| TC 5 | " | 330 P | 220 P | 560 P | 100 P | 350 PF | 82 PF | 220 PF |
| R 21 | 330 Ω | 330 Ω | 330 Ω | 100 Ω | 330 Ω | 330 Ω | 330 Ω | 330 Ω |
| R 22 | " | N C | N C | 330 Ω | 330 Ω | 330 Ω | 330 Ω | N C |
| R 24 | 22 Ω | 51 Ω | 51 Ω | 51 Ω | 51 Ω | 51 Ω | 51 Ω | 51 Ω |
| R 26 | 220 Ω | 100 Ω | 100 Ω | 100 Ω | 100 Ω | 100 Ω | 100 Ω | 100 Ω |
| R 42 | 2.7 K | 2.2 K | 2.2 K | 2.2 K | 2.2 K | 100 Ω | 100 Ω | 100 Ω |
| R 44 | 330 Ω | 220 Ω | 220 Ω | 220 Ω | 220 Ω | 2.2 kΩ | 2.2 kΩ | 2.2 kΩ |
| R 81 | N C | 1 K | 1 K | 1 K | 1 K | 220 Ω | 220 Ω | 220 Ω |
| R 83 | " | N C | " | N C | " | 1 kΩ | 1 kΩ | 1 kΩ |
| R 84 | ジャンパ | ジャンパ | ジャンパ | 180 Ω | ジャンパ | 1 kΩ | 1 kΩ | 1 kΩ |
| C 10 | 33 P | 103 | 103 | 103 | 103 | ジャンパ | ジャンパ | ジャンパ |
| C 13 | N C | 10 P | N C | 10 P | N C | 103 | 103 | 103 |
| C 14 | 100 P | 100 P | 47 P | 100 P | 100 P | 6 PF | N C | N C |
| C 15 | 30 P | 220 P | 100 P | " | 30 P | 100 PF | ジャンパ | ジャンパ |
| C 19 | 47 P | 56 P | 56 P | 82 P | 39 P | 220 PF | ジャンパ | ジャンパ |
| C 20 | 1 P | 1 P | 1 P | 2 P | 1 P | 100 PF | 68 PF | 56 PF |
| C 22 | 47 P | 56 P | 56 P | 82 P | 39 P | 1 PF | 1 PF | 1 PF |
| C 28 | 22 P | 150 P | 33 P | 180 P | 18 P | 100 PF | 68 PF | 56 PF |
| C 31 | 18 P | 120 P | " | " | 18 P | 82 PF | 47 PF | 33 PF |
| C 32 | 100 P | 100 P | 100 P | 330 P | 100 P | 82 PF | 47 PF | 33 PF |
| C 66 | 33 P | 150 P | 47 P | 180 P | 22 P | 82 PF | 47 PF | 33 PF |
| C 94 | 47 P | 300 P | 120 P | 560 P | 82 P | 100 PF | 100 PF | 700 PF |
| C 103 | 33 P | 150 P | 33 P | 180 P | 18 P | 82 PF | 47 PF | 47 PF |
| C 112 | 12 P | 12 P | 22 P | 12 P | 22 P | 180 PF | 120 PF | 120 PF |
| C 129 | 472 | N C | 472 | N C | 472 | 82 PF | 47 PF | 22 PF * |
| C 131 | 10 P | 15 P | 10 P | 15 P | 10 P | 22 PF | 22 PF | 22 PF |
| C 133 | 47 P | N C | N C | N C | 82 P | 472 | 472 | 472 |
| C 135 | 39 P | 220 P | 82 P | 330 P | 68 P | 15 PF | 15 PF | 10 PF |
| C 136 | 22 P | 150 P | 56 P | 270 P | 47 P | N C | N C | N C |
| C 138 | 39 P | 220 P | 100 P | 470 P | 82 P | 20 PF | 100 PF | 82 PF |
| C 139 | " | 300 P | " | " | 82 P | 120 PF | 100 PF | 56 PF |
| C 140 | 4 P | 33 P | 12 P | 56 P | 10 P | 150 PF | 82 PF | 100 PF |
| C 142 | N C | 22 P | N C | 100 P | N C | 33 PF | 10 PF | 12 PF |
| C 143 | " | 0.5 P | 1 P | 0.5 P | 0.5 P | N C | N C | N C |
| C 144 | " | N C | 39 P | N C | 22 P | 0.5 PF | 0.5 PF | 1 PF |
| | | | | | | 68 PF | 47 PF | 39 PF |
| ⑨ | ⑩に接続 | ⑩に接続 | ⑨に接続 | ⑩に接続 | ⑨に接続 | ⑤⑩に接続 | ⑤⑩に接続 | ⑤⑩に接続 |

2ch: 14.7245 MHz. { L15 2巻線C
* L16 "
2ch: 12.09146 MHz